

MAMAZING B0CXXRN2QS

MAMAZING Lightweight Baby Travel Stroller Instruction Manual

MODEL: B0CXXRN2QS

Brand: MAMAZING

Introduction

Thank you for choosing the MAMAZING Lightweight Baby Travel Stroller. This manual provides essential information for the safe and efficient use, assembly, operation, and maintenance of your stroller. Please read all instructions carefully before use and retain this manual for future reference.

The MAMAZING stroller is designed for convenience and portability, featuring a carbon fiber frame for lightweight durability, a compact one-handed folding mechanism, and airplane-friendly dimensions, making it ideal for travel and daily use.

Safety Information


- Always use the 5-point harness to secure your child in the stroller.
- Ensure the stroller is fully open and locked before placing a child inside.
- Engage the foot-operated brake system when the stroller is stationary.
- Do not overload the storage basket; maximum weight capacity is 4.4 pounds.
- Never leave your child unattended in the stroller.
- This stroller is suitable for babies aged 6 months up to 50 pounds (maximum height of 39.4 inches).
- The stroller meets or exceeds the highest safety standards set by the CPSC and ASTM.

Keep Your Baby Comfortable

Multi-Position Recline



Extendable Canopy (UPF 50+)



Adjustable Footrest



Image: Child safely secured in the stroller with the 5-point harness and bumper bar engaged.

Setup and Assembly

The MAMAZING stroller is designed for quick and easy setup. It features a one-handed folding and unfolding system.

1. **Unfolding:** To unfold the stroller, ensure the safety latch is disengaged. Hold the handle and press the release button, then gently pull upwards until the frame locks into place with an audible click. Verify all locking mechanisms are secure before use.
2. **Attaching/Adjusting Bumper Bar:** The bumper bar can be easily attached or removed by aligning it with the designated slots on the frame and pressing until it clicks.
3. **Adjusting Footrest:** The footrest can be adjusted to different positions to accommodate your child's comfort.

Fit for Every Trip

As small as a 21" carry-on suitcase



Image: Demonstration of the stroller's one-handed folding mechanism.

Operating Instructions

1. **Folding:** To fold the stroller, ensure the canopy is retracted and the footrest is in its lowest position. Locate the folding mechanism (usually a button or lever on the handle), press it, and push the handle downwards until the stroller collapses into its compact form. Secure the safety latch.
2. **Reclining the Seat:** The seat offers multiple recline positions for your child's comfort. Adjust the recline strap or lever located behind the seat to achieve the desired angle.
3. **Canopy Adjustment:** The UPF 50+ canopy can be extended or retracted to provide optimal sun protection. It also features a mesh window for ventilation and easy viewing of your child.
4. **Brake System:** The foot-operated brake is located on the rear wheels. Press down on the brake pedal to engage and lift up to release. Always engage the brake when the stroller is stationary.
5. **Storage Basket:** The spacious under-seat basket provides convenient storage for essentials. Do not exceed the

maximum weight limit of 4.4 pounds.

Folds with Just One Hand



Image: Visual guide to adjusting the stroller's recline, canopy, and footrest for child comfort.

Safe and Secure



Image: The generous under-seat storage basket, suitable for diaper bags and other essentials.

Maintenance

- **Cleaning Fabric:** Use a mild soap and warm water solution to spot clean fabric components. Do not use bleach or harsh detergents. Allow to air dry completely.
- **Cleaning Frame:** Wipe the carbon fiber frame with a soft, damp cloth. Avoid abrasive cleaners.
- **Wheel Maintenance:** Regularly check wheels for debris and clear as needed. Lubricate moving parts with a silicone-based lubricant if necessary.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight when not in use. Use the provided travel bag for protection during transport or long-term storage.

Troubleshooting

- **Stroller not unfolding/folding smoothly:** Ensure all locking mechanisms are disengaged. Check for any obstructions in the folding joints. Apply a small amount of silicone lubricant to moving parts if resistance persists.
- **Wheels not turning smoothly:** Remove any debris (hair, lint, dirt) from around the wheel axles. Lubricate with a silicone spray.
- **Brake not engaging:** Check for obstructions around the brake mechanism. Ensure the brake pedal is fully depressed.
- **Harness issues:** Ensure straps are not twisted and buckles are clean. Adjust straps for a snug fit.

Specifications

Feature	Specification
Brand	MAMAZING
Model	B0CXXRN2QS
Color	Green, No organizer & cushion
Material	Polyester, Faux Leather, Cotton, Carbon Fiber
Frame Material	Carbon Fiber
Age Range (Description)	6 months up to 50 lbs (Max Height of 39.4 Inches)
Item Weight	11.6 Pounds
Folded Size	H20.6 x W18.5 x D11 inch
Item Dimensions L x W x H	29.9"L x 19.3"W x 39.4"H
Basket Weight Capacity Maximum	4.4 Pounds
Harness Type	5 Point
Has Stroller Brake System	Yes
Specification Met	ASTM

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official MAMAZING website. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question