

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [U-MAX](#) /
- › [U-MAX 3-Piece Outdoor Wicker Sectional Sofa Set Instruction Manual](#)

U-MAX B0CXXSDQSC

U-MAX 3-Piece Outdoor Wicker Sectional Sofa Set Instruction Manual

Model: B0CXXSDQSC

[Overview](#) [Safety Information](#) [Package Contents](#) [Assembly Instructions](#) [Usage](#)
[Guidelines](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. PRODUCT OVERVIEW

The U-MAX 3-Piece Outdoor Wicker Sectional Sofa Set is designed for both outdoor and indoor use, providing a comfortable seating arrangement. This set includes two single sofas and one love seat, featuring soft, thick cushions with waterproof polyester fabric. The design incorporates brown rattan with khaki cushions, ergonomic curved armrests, and a durable construction suitable for various weather conditions.



Image 1: The complete U-MAX 3-Piece Outdoor Wicker Sectional Sofa Set, featuring two single chairs and one love seat with khaki cushions.

2. IMPORTANT SAFETY INFORMATION

- Always keep the sofa away from direct sunlight and rain when not in use to prolong its lifespan.
- Do not expose the sofa to open flames or high heat sources.

- Supervise children and pets around the sofa to prevent entrapment risks.
- Always follow the assembly instructions carefully to ensure the sofa's stability and safety.
- Ensure all components are securely fastened before use.


3. PACKAGE CONTENTS

Your U-MAX 3-Piece Outdoor Wicker Sectional Sofa Set will arrive in two separate boxes. Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.


- **Box A:** Two (2) Single Sofa Chairs
- **Box B:** One (1) Love Seat
- All necessary hardware for assembly.
- Detailed instruction manual.

Package Details

You will receive 2 boxes, and they may not arrive on the same day.
Please wait patiently or contact us if you only receive one.



Box A
two single chairs
29.3 x 26 x 23.6 inch
G.W. 66.8 lbs



Box B
one love chair
45.3 x 29 x 11.8 inch
G.W. 47 lbs

Image 2: Illustration of package contents, indicating two boxes for the single chairs and love seat.

4. ASSEMBLY INSTRUCTIONS

Assembly of the U-MAX 3-Piece Outdoor Wicker Sectional Sofa Set typically takes approximately 40 minutes. All required hardware and tools are included in the package. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the boxes and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included parts list in your manual to identify each component (e.g., chair frames, seat bases, cushions, hardware).
3. **Assemble Single Chairs:**
 - Attach the backrest to the seat base using the provided screws and Allen wrench.

- Secure the armrests to the assembled backrest and seat base.
- Ensure all screws are tightened, but do not overtighten.

4. Assemble Love Seat:

- Repeat the steps for the single chairs to assemble the love seat frame.

5. **Place Cushions:** Once the frames are fully assembled and stable, place the seat and back cushions onto the chairs and love seat.

6. **Final Check:** Double-check all connections to ensure they are secure and stable before using the furniture.




Image 3: Detailed view highlighting the close-knit hand-woven wicker, 3.9-inch thick cushions, and full-range ergonomic armrests, which contribute to comfort and durability.

5. USAGE GUIDELINES

This outdoor wicker sectional sofa set is designed for comfortable seating in various environments. To ensure optimal

performance and longevity, please observe the following:

- **Weight Capacity:** Each seat has a weight capacity of 330 pounds. Do not exceed this limit.
- **Placement:** Position the furniture on a flat, stable surface. While suitable for outdoor use, consider placing it under a covered area or using a furniture cover during harsh weather conditions to protect it from extreme elements.
- **Movement:** When moving the furniture, lift it rather than dragging it to prevent damage to the legs or frame.
- **Cushion Care:** The cushions are made with waterproof polyester fabric. While resistant to light moisture, it is recommended to bring them indoors during heavy rain or prolonged periods of non-use to maintain their quality.



Image 4: The U-MAX 3-Piece Outdoor Wicker Sectional Sofa Set arranged on a patio, demonstrating its suitable outdoor placement.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and extend the life of your U-MAX outdoor furniture set.

Frame Care:


- **Cleaning:** Wipe the wicker and metal frame with a soft, damp cloth and mild soap. Rinse thoroughly with clean water and dry completely to prevent water spots or mildew.
- **Protection:** For prolonged outdoor exposure, consider using a weather-resistant furniture cover when the set is not in use.
- **Inspection:** Periodically check all bolts and connections to ensure they remain tight. Tighten if necessary.

Cushion Care:

- **Cleaning:** The cushion covers are made from waterproof polyester fabric and are removable for cleaning. Spot

clean with a mild soap solution and a soft brush. For deeper cleaning, unzip and remove covers, then hand wash or machine wash on a gentle cycle with cold water. Air dry only; do not tumble dry.

- **Storage:** Store cushions in a dry, protected area when not in use or during inclement weather to prevent fading and mildew.



COMFORTABLE WATERPROOF POLYESTER FABRIC
is easy to clean and makes excellent skin touching feeling

STRONG AND SMOOTH YKK ZIPPER
lets cushion easy to change and wash

SPECIAL-DESIGNED FEET
guarantee stability and add removability

Image 5: Features such as the comfortable waterproof polyester fabric, strong YKK zipper for easy cushion cover removal, and special-designed feet for stability and removability.

7. TROUBLESHOOTING

If you encounter any issues with your U-MAX sofa set, please refer to the following common solutions:

Problem	Possible Cause	Solution
Wobbly Furniture	Loose connections or uneven surface.	Ensure all bolts are tightened. Move the furniture to a flat, even surface.

Problem	Possible Cause	Solution
Cushions appear flat or misshapen	Prolonged use or improper storage.	Fluff cushions regularly. Store cushions indoors when not in use to help maintain their shape.
Wicker appears damaged or unraveling	Impact damage or excessive wear.	Minor unraveling can sometimes be re-woven. For significant damage, contact customer support for repair options.
Difficulty during assembly	Incorrect part orientation or missing hardware.	Review the instruction manual carefully. Ensure parts are oriented correctly. Contact customer support if hardware is missing.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	U-MAX
Model Number	BOCXXSDQSC
Type	Sectional Sofa Set
Number of Pieces	3 (2 Single Chairs, 1 Love Seat)
Seating Capacity	4
Color	Brown (Rattan), Khaki (Cushions)
Frame Material	Powder Coated Steel, Stainless Steel Aluminum
Wicker Material	Tightly woven resin wicker (PE Rattan)
Upholstery Fabric Type	Waterproof Polyester
Cushion Fill Material	Foam
Item Weight	113.8 Pounds
Love Sofa Dimensions (L x W x H)	49.5" x 28.5" x 31.5"
Single Seat Dimensions (L x W x H)	27.4" x 28.5" x 31.5"
Seat Cushion Thickness	3.9"
Assembly Required	Yes
Special Features	Ergonomic Curved Armrests, Concealed Storage Design, Removable Cushion Covers



Specifications —

Materials: PE Rattan, Steel Frame, Polyester Fabric, Sponge
 Rattan Color: Deep Brown
 Cushions Color: Light Khaki
 Each Seat Weight Capacity: 330 Pounds

Item Size

Love Sofa Dimension: 49.5"(L) x 28.5"(W) x 31.5"(H)
 Single Seat Dimension: 27.4"(L) x 28.5"(W) x 31.5"(H)
 Seat Cushion Thickness: 3.9"
 Love Sofa Width: 43.5"
 Single Seat Width: 21"
 Seat Height: 15.7"
 Seat Depth: 22.5"

All cushions included
 All necessary hardware & instructions

Image 6: Visual representation of the dimensions for the love seat and single chairs, along with key specifications.

9. WARRANTY AND CUSTOMER SUPPORT

U-MAX is committed to providing high-quality products and excellent customer service. For any questions, concerns, or assistance with your product, please contact our professional services team.

- **Customer Service:** Our team is available to help within 24 hours. Please refer to your purchase documentation for specific contact details or visit the official U-MAX website.
- **Warranty Information:** Specific warranty details may vary. Please retain your proof of purchase for any warranty claims.