ALLIMITY CV-BF21-SH

ALLIMITY BF21 Replaced Remote Control User Manual

Model: CV-BF21-SH

Introduction

This user manual provides comprehensive instructions for the ALLIMITY BF21 Replaced Remote Control, designed as a direct replacement for the original Nakamichi BF21 soundbar remote. Please read this manual carefully before using the remote control to ensure proper operation and longevity.



Image: Top-down view of the ALLIMITY BF21 Replaced Remote Control. It is a black, rectangular remote with various circular and oval buttons. The power button is red and located at the top left.

Package Contents

- 1 x ALLIMITY BF21 Replaced Remote Control
- *Note: Batteries are not included.*

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the

markings inside the compartment.

4. Close the battery compartment cover securely.





Image: Rear view of the remote control with the battery cover removed, showing the two AAA battery slots. A detached battery cover is shown next to it.

Initial Use

This replacement remote control is pre-programmed and does not require any setup or programming. Once batteries are installed, it is ready for immediate use with your Nakamichi BF21 soundbar.

Operating Instructions

Point the remote control directly at the Nakamichi BF21 soundbar's infrared receiver for optimal performance.

Button Functions





Image: A detailed, straight-on view of the remote control, highlighting the layout and labels of all buttons.

Button	Function
Power (Red Button)	Turns the soundbar On or Off.
MUTE	Mutes or unmutes the sound.
VOL+	Increases the volume.
VOL-	Decreases the volume.
◀◀ (Previous)	Skips to the previous track/chapter.
▶▶ (Next)	Skips to the next track/chapter.
▶▶ / PAIR (Play/Pause/Pair)	Plays or pauses media. Long press for Bluetooth pairing mode.
AUX	Selects Auxiliary input source.
OPTICAL	Selects Optical input source.
BT (Bluetooth)	Selects Bluetooth input source.
SOURCE	Cycles through available input sources.

Button	Function
MOVIE	Activates Movie sound mode (EQ preset).
MUSIC	Activates Music sound mode (EQ preset).
NEWS	Activates News sound mode (EQ preset).
EQ	Cycles through Equalizer presets.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace with new alkaline batteries of the correct type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Environment:** Keep the remote control away from direct sunlight, heat sources, and excessive moisture.

Troubleshooting

Problem	Possible Cause / Solution
Remote control not working.	◦ **Batteries:** Check if batteries are inserted correctly (+/-). Replace with new batteries if they are depleted. ◦ **Line of Sight:** Ensure there are no obstructions between the remote and the soundbar's IR receiver. ◦ **Distance:** Make sure you are within the effective operating range of the soundbar.
Buttons are unresponsive.	◦ **Batteries:** Batteries may be low. Replace them. ◦ **Dirt/Debris:** Clean the remote control, especially around the buttons, to ensure no debris is preventing proper contact.
Remote works intermittently.	◦ **Batteries:** Batteries may be nearing depletion. Replace them. ◦ **Interference:** Ensure no strong light sources (e.g., direct sunlight, fluorescent lights) are interfering with the IR signal.

Specifications

Feature	Detail
Model Number	CV-BF21-SH
Compatibility	Nakamichi BF21 Soundbar
Dimensions (L x W x H)	6.5 x 1.38 x 0.72 inches (16.5 x 3.5 x 1.8 cm)

Feature	Detail
Item Weight	1.13 ounces (32 grams)
Color	Black
Power Source	2 x AAA Alkaline Batteries (not included)
Special Feature	Wireless (Infrared)





Image: The remote control shown with its length (14.6 cm / 5.75 in), width (3.8 cm / 1.5 in), and thickness (1 cm / 0.4 in) clearly labeled with red measurement lines.

Warranty and Support

For any issues or inquiries regarding your ALLIMITY BF21 Replaced Remote Control, please contact the seller or manufacturer through the platform where the purchase was made. Keep your purchase receipt as proof of purchase for any warranty claims.
This product is designed as a direct replacement and typically does not require extensive technical support beyond basic troubleshooting as outlined in this manual.

© 2025 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question