

[Manuals.plus](#) /

› [Rowenta](#) /

› Rowenta Turbo Silence Extreme + Stand Fan User Manual

Rowenta VU5890F0

Rowenta Turbo Silence Extreme + Stand Fan User Manual

Model: VU5890F0 | Brand: Rowenta

INTRODUCTION

Thank you for choosing the Rowenta Turbo Silence Extreme+ Stand Fan. This manual provides important information for the safe and efficient operation, maintenance, and troubleshooting of your fan. Please read it thoroughly before first use and keep it for future reference.

SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of fire, electric shock, or injury:

- Ensure the voltage indicated on the fan's rating label matches your mains supply voltage.
- Do not operate the fan with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Unplug the fan from the power outlet when not in use, before cleaning, or before performing any maintenance.
- Do not insert fingers or any other objects through the fan guard when it is operating.
- Keep the fan away from water or other liquids. Do not use it in bathrooms or other damp environments.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Place the fan on a stable, flat surface to prevent it from tipping over.

PRODUCT OVERVIEW & COMPONENTS

The Rowenta Turbo Silence Extreme+ Stand Fan is designed to provide powerful yet quiet cooling for your home or office. It features Effitech motor technology for energy efficiency, 16 speed settings, and 3 automatic modes for personalized comfort.



Image: The Rowenta Turbo Silence Extreme+ Stand Fan shown with its accompanying remote control.

Included Components:

- Fan Unit (Motor, Blades, Guards)
- Base
- Telescopic Pole
- Remote Control
- Power Cord

ASSEMBLY

Follow these steps to assemble your Rowenta Turbo Silence Extreme+ Stand Fan:

1. Carefully unpack all components from the box.
2. Attach the telescopic pole to the fan base, ensuring it is securely fastened.
3. Mount the fan motor unit onto the top of the telescopic pole.
4. Assemble the front and rear fan guards, ensuring the blades are correctly positioned within the guards. Secure the guards with the provided fasteners.
5. Ensure all connections are tight and secure before plugging in the fan.

OPERATING INSTRUCTIONS

Power On/Off:

Plug the fan into a suitable power outlet. Press the power button on the control panel or remote control to turn the fan on or off.

Speed Adjustment:

The fan offers 16 selectable speeds. Use the '+' and '-' buttons on the control panel or remote control to increase or decrease the fan speed to your desired level of airflow.



Image: The fan demonstrating personalized refreshment with its 16 speed levels.

Automatic Modes:

Select from 3 automatic modes using the 'Mode' button:

- **Night Mode:** Automatically reduces fan speed for quiet operation during sleep.
- **Silent Mode:** Provides optimal balance between noise level and performance, operating at a very low 32 dB(A).
- **Natural Breeze Mode:** Simulates natural wind patterns by varying fan speed.



BESONDERS LEISE
bei nur 32 dB(A)

Image: The fan operating particularly quietly, ideal for bedrooms, with a noise level of only 32 dB(A).

Oscillation:

Press the oscillation button to activate or deactivate the automatic 120° oscillation feature, which distributes air across a wider area.

Timer Function:

Set the fan to turn off automatically after a set period, up to 12 hours, using the timer button.

Remote Control:

The compact remote control allows you to conveniently adjust all fan settings from a distance.

BENUTZERKOMFORT

kompakte Fernbedienung



Image: A hand holding the compact remote control, highlighting user comfort and convenience.

Height Adjustment:

Adjust the fan's height by loosening the height adjustment knob on the telescopic pole, setting the desired height, and then tightening the knob securely.

MAINTENANCE AND CLEANING

Regular cleaning will help maintain your fan's performance and extend its lifespan.

- Always unplug the fan from the power outlet before cleaning.
- Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- For thorough cleaning of the fan blades, carefully remove the front guard according to the assembly instructions in reverse. Clean the blades with a soft cloth and reassemble the guard securely.
- Ensure all parts are completely dry before plugging the fan back in.

TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; Power outlet fault; Fan damaged.	Ensure fan is securely plugged in; Test outlet with another device; Contact customer support if damaged.
Weak airflow.	Low speed setting; Dirty blades/guards.	Increase speed setting; Clean fan blades and guards.
Unusual noise.	Loose parts; Obstruction in fan blades.	Check for loose components and tighten; Ensure no objects are obstructing the blades.

TECHNICAL SPECIFICATIONS

Below are the technical specifications for the Rowenta Turbo Silence Extreme+ Stand Fan:

Feature	Specification
Model Number	VU5890F0
Product Dimensions	43 x 46 x 134 cm
Product Weight	4.48 Kilograms
Noise Level	32 dB(A)
Number of Speeds	16
Automatic Modes	Night, Silent, Natural Breeze
Oscillation Angle	Up to 120°
Timer	Up to 12 hours
Power Source	Corded Electric
Special Features	Adjustable Height, Oscillating, Remote Controlled

EFFITECH-MOTOR


65 %

**ENERGIEEINSPARUNG
FÜR DIESELBE LEISTUNG**

19 W vs. 55 W VENTILATOR für 50 m³/min*

*Intern gemessene Luftstromleistung, gemäss der Norm EN/IEC 60879:2019 und eingestellt auf 50 m³/min, im Vergleich zum VU5640F2

Image: The Effitech Motor, highlighting 65% energy savings for the same performance.



145 cm

50 cm



60 cm

Image: Detailed dimensions of the Rowenta Turbo Silence Extreme+ Stand Fan.

WARRANTY AND CUSTOMER SUPPORT

Your Rowenta Turbo Silence Extreme+ Stand Fan is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. For technical assistance, spare parts, or warranty claims, please contact Rowenta customer support. You can find contact information on the official Rowenta website or in your product documentation. When contacting support, please have your

model number (VU5890F0) and purchase date ready.

For additional information or to explore other Rowenta products, visit the official Rowenta store: [Rowenta Store on Amazon](#)

© 2024 Rowenta. All rights reserved.