

VersLife C8EU

VersLife C8 Corded Stick Vacuum Cleaner User Manual

Model: C8EU

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the VersLife C8 Corded Stick Vacuum Cleaner. Retain this manual for future reference.

- Ensure the power supply voltage matches the rating label on the vacuum cleaner.
- Do not use the vacuum cleaner to pick up water or other liquids, hot ashes, burning cigarettes, or sharp objects.
- Always unplug the vacuum cleaner from the power outlet before cleaning or performing any maintenance.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the vacuum cleaner with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer or a qualified service agent.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Use only manufacturer-recommended attachments.
- Store the vacuum cleaner indoors in a dry place.

2. PACKAGE CONTENTS

Carefully unpack your VersLife C8 Corded Stick Vacuum Cleaner and check that all items are present and in good condition.

- Main Vacuum Unit (Motor and Dust Cup)
- Extension Tube
- Floor Brush
- Crevice Tool
- Brush Tool
- Washable HEPA Filter (pre-installed, with one spare)
- User Manual



Image 2.1: All components of the VersLife C8 Corded Stick Vacuum Cleaner, including the main unit, extension tube, floor brush, crevice tool, brush tool, and two washable HEPA filters.

3. PRODUCT OVERVIEW

The VersLife C8 is a versatile 4-in-1 corded stick vacuum cleaner designed for efficient cleaning of various surfaces. It can be configured as a stick vacuum for floors or as a handheld vacuum for upholstery, stairs, and tight spaces.



Image 3.1: The VersLife C8 vacuum cleaner shown in its full stick configuration with the floor brush, and in various handheld configurations with the crevice tool and brush tool attached.

4. ASSEMBLY

4.1 Assembling the Stick Vacuum

1. Insert the extension tube into the main vacuum unit until it clicks securely into place.
2. Attach the floor brush to the other end of the extension tube, ensuring it is firmly connected.
3. The stick vacuum is now ready for use on hard floors and carpets.

4.2 Assembling the Handheld Vacuum

1. For handheld use, detach the extension tube from the main vacuum unit by pressing the release button (if applicable) and pulling.
2. Attach either the crevice tool or the brush tool directly to the main vacuum unit until it clicks securely.
3. The handheld vacuum is suitable for cleaning upholstery, car interiors, stairs, and hard-to-reach areas.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- Plug the power cord into a suitable electrical outlet (220V).
- Press the power button located on the main vacuum unit to turn the appliance on.
- Press the power button again to turn the appliance off.
- Always unplug the vacuum cleaner after use.

5.2 Using the Vacuum

- **For Floors:** Use the stick vacuum configuration with the floor brush for effective cleaning of hard floors and low-pile carpets. Move the vacuum slowly over the surface to allow for thorough suction.
- **For Above-Floor Cleaning:** Use the handheld configuration with the crevice tool for narrow gaps, corners, and edges. Use the brush tool for dusting surfaces, upholstery, and pet hair.
- The 5-meter long cable provides ample reach for cleaning larger areas without frequently changing power outlets.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

6.1 Emptying the Dust Cup

1. Ensure the vacuum cleaner is unplugged.
2. Locate the dust cup release button on the main unit and press it to detach the dust cup.
3. Hold the dust cup over a trash bin and open the bottom lid to empty the collected debris.
4. Close the lid and reattach the dust cup to the main unit until it clicks into place.

6.2 Cleaning the Filters

The VersLife C8 features a washable HEPA filter. Clean the filter regularly (after every 3-5 uses or as needed) to maintain suction power.

1. Unplug the vacuum cleaner and remove the dust cup.
2. Twist and pull out the HEPA filter from the dust cup.
3. Tap the filter gently to remove loose dust.
4. Rinse the HEPA filter under cold running water until the water runs clear. Do not use detergents or hot water.
5. Allow the filter to air dry completely for at least 24 hours before reinserting it. *Do not use the vacuum cleaner with a wet filter.*
6. Reinsert the dry filter into the dust cup and reattach the dust cup to the main unit.
7. A spare HEPA filter is provided for convenience, allowing you to use the vacuum while one filter is drying.



Image 6.1: Close-up view of the washable HEPA filters, illustrating their design and the recommendation for rinsing with water.

7. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	No power supply; Power cord not plugged in; Power button not pressed.	Check power outlet; Ensure cord is securely plugged in; Press power button firmly.

Problem	Possible Cause	Solution
Low suction power	Dust cup full; Filter clogged; Obstruction in nozzle/hose.	Empty dust cup; Clean or replace HEPA filter; Remove any obstructions.
Unusual noise	Obstruction in brush/nozzle; Filter improperly installed.	Check for and remove obstructions; Ensure filter is correctly seated.
Dust escaping from vacuum	Dust cup not properly closed; Filter damaged or missing.	Ensure dust cup is securely closed; Check and replace filter if damaged or missing.

8. SPECIFICATIONS

Feature	Specification
Model	C8EU
Power	600W
Suction Power	20Kpa
Voltage	220V
Dust Cup Capacity	0.5 Pounds (approx. 0.23 Liters)
Noise Level	70 dB
Cable Length	5 meters
Filter Type	Washable HEPA Filter
Product Dimensions	45.47 x 17.27 x 21.59 cm (Main Unit)
Item Weight	1.5 Kilograms

9. WARRANTY AND SUPPORT

VersLife products are manufactured to high-quality standards. For warranty information, technical support, or service inquiries, please refer to the contact details provided with your purchase documentation or visit the official VersLife website.

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question