

[Manuals.plus](#) /

> [AIKE](#) /

> AIKE Wall Mount Liquid Soap Dispenser Instruction Manual

AIKE AK1006

AIKE Wall Mount Liquid Soap Dispenser Instruction Manual

Model: AK1006 | Brand: AIKE

PRODUCT OVERVIEW

The AIKE Wall Mount Liquid Soap Dispenser, model AK1006, is engineered for commercial and high-traffic environments. Its robust construction and large capacity minimize the need for frequent refills, ensuring continuous availability of soap. The dispenser is designed for ease of use and secure operation.





Image: Front view of the AIKE Wall Mount Liquid Soap Dispenser in silver.

WHAT'S INCLUDED (PACKING LIST)

Please verify that all components are present in the package before proceeding with installation.

- Soap Dispenser x 1
- Key x 1
- User Manual x 1
- Screw x 4
- Nail-Free Sticker x 1
- Expansion Anchor x 4



Image: Contents of the AIKE soap dispenser package, including the dispenser, key, manual, screws, nail-free sticker, and expansion anchors.

INSTALLATION GUIDE

The AIKE soap dispenser offers two installation methods: drilled mounting for maximum security and adhesive mounting for convenience.


Drilled Installation

1. **Remove the container and mark the holes:** Open the dispenser and remove the internal soap container. Hold the dispenser against the wall at the desired height and use a pencil to mark the positions for drilling.
2. **Drill holes and insert expansion anchors:** Use an appropriate drill bit to drill holes at the marked positions. Insert the provided expansion anchors into the drilled holes.
3. **Hang the dispenser and fix with screws:** Align the dispenser with the drilled holes and secure it to the wall using the provided screws. Ensure it is firmly attached.
4. **Reinstall the container and lock the dispenser:** Place the soap container back into the dispenser. Close the dispenser

and use the key to lock it securely.


DRILLED INSTALLATION

1




Remove the container and mark the holes on the wall

2




Drill holes accordingly and insert expansion anchor

3



Hang the dispenser on the wall and fix it with screws

4



Reinstall the container and lock the dispenser

Image: Visual guide for drilled installation, showing steps from marking to securing the dispenser.

Adhesive Installation

1. **Prepare the wall surface:** Ensure the wall surface is clean, dry, and free from any dust, oil, or stains.
2. **Remove protective film:** Peel off the protective film from the back of the adhesive mounting plate.
3. **Press firmly to secure:** Press the adhesive plate firmly against the prepared wall surface. Apply pressure evenly to eliminate air bubbles and ensure a strong bond.
4. **Wait and secure the dispenser:** Allow the adhesive to cure for a recommended period (typically 24 hours) before installing the dispenser onto the adhesive plate. This ensures maximum adhesion.


ADHESIVE INSTALLATION

1




Prepare the Wall Surface: Ensure the wall is dry and free from any stains

2




Remove Protective Film Peel off the protective film from the back of the mounting plate

3



Press Firmly to Secure: Eliminate the bubbles and ensure it stays securely in place

4



Wait and Secure the Dispenser: Wait a while before installing the dispenser

Image: Visual guide for adhesive installation, showing steps from surface preparation to mounting the dispenser.

OPERATION

To dispense soap, simply place your hand under the dispenser's nozzle and press the large push panel. The manual pump mechanism will deliver a measured amount of liquid soap.



Image: A hand demonstrating how to press the large button for soap dispensing.

MAINTENANCE

Refilling the Dispenser

The AIKE dispenser features a 27-ounce (800ml) large capacity reservoir, reducing the frequency of refills. To refill:

1. Unlock the top cover using the provided key.
2. Carefully lift the cover to expose the internal reservoir.
3. Pour liquid soap directly into the reservoir, ensuring not to overfill.
4. Close the cover and lock it securely.

27FL.OZ

LARGE CAPACITY

ALLOWS THIS DISPENSER FOR LONG-TERM USE WITHOUT THE NEED FOR FREQUENT REFILLS



Image: Internal view of the dispenser highlighting its 27 fl. oz. large capacity for liquid soap.

Cleaning and Care

Regular cleaning will ensure optimal performance and hygiene. The dispenser's fingerprint-resistant and stain-resistant coating simplifies maintenance.

- Wipe the exterior with a soft, damp cloth and mild soap. Avoid abrasive cleaners.
- For the internal pump, if clogging occurs, the replaceable pump allows for easy maintenance or replacement, extending the product's lifespan.



WASHROOM SOLUTION FOR SMALL BUSINESS

AK2630 Air Wiper Hand Dryer | AK1006 Manual Soap Dispenser

Image: Close-up views illustrating the lock design, fingerprint-resistant coating, and replaceable pump mechanism.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dispenser not dispensing soap.	Reservoir is empty.	Refill the soap reservoir.
Dispenser not dispensing soap.	Pump is clogged.	Clean the pump mechanism. If severely clogged or damaged, consider replacing the pump.
Dispenser is loose on the wall.	Screws are loose (drilled installation).	Tighten the mounting screws.
Dispenser is loose on the wall.	Adhesive not fully cured or surface not clean (adhesive installation).	Ensure wall surface is clean and dry before applying adhesive. Allow sufficient curing time (24 hours) before mounting the dispenser. Reapply new adhesive if necessary.

Problem	Possible Cause	Solution
Soap leaks from dispenser.	Reservoir cap not sealed properly or pump assembly is loose.	Ensure the reservoir cap is tightly closed and the pump assembly is correctly seated.

SPECIFICATIONS

Feature	Detail
Model Number	AK1006
Brand	AIKE
Color	Silver
Material	Plastic (ABS Polycarbonate)
Liquid Volume Capacity	27 fl. oz. (800 ml)
Product Dimensions (L x W x H)	4.84" x 3.86" x 9.45"
Item Weight	1.37 pounds
Installation Type	Wall Mount (Adhesive or Drilled)

WARRANTY AND SUPPORT

AIKE provides a **1-year manufacturer's warranty** for this product. This warranty covers defects in materials and workmanship under normal use.

For any concerns, questions, or support needs regarding your AIKE Wall Mount Liquid Soap Dispenser, please feel free to reach out to our customer support team. Contact information can typically be found on the product packaging or the official AIKE website.

AIKE is committed to addressing any issues you may encounter and ensuring your satisfaction with our products.

© 2024 AIKE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question