Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LPKRPL TVST01

LPKRPL TVST01 Modern TV Stand Instruction Manual

Model: TVST01

1. Introduction

Thank you for choosing the LPKRPL TVST01 Modern TV Stand. This manual provides detailed instructions for assembly, setup, operation, and maintenance of your new TV stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This TV stand is designed to accommodate televisions up to 77 inches and features fluted doors, ample storage, and a sleek modern aesthetic.



Image 1.1: The LPKRPL TVST01 Modern TV Stand, showcasing its grey finish, fluted doors, and gold metal base in a contemporary living room environment.

2. Safety Information

To ensure safe use of your TV stand, please observe the following precautions:

- **Weight Capacity:** Do not exceed the recommended weight capacity for the top surface or shelves. This unit is designed for TVs up to 77 inches. Ensure the weight of your television and other items does not exceed the stand's structural limits.
- **Stability:** Place the TV stand on a flat, level surface to prevent tipping. If necessary, use wall anchor straps (not included) to secure the unit to the wall, especially in homes with children or pets.
- **Assembly:** Assemble the unit according to the instructions provided. Do not skip steps or use unauthorized parts. Ensure all fasteners are securely tightened.

- **Children:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the TV stand.
- **Electrical Cords:** Route all electrical cords safely to prevent tripping hazards and damage to the cords.

3. Package Contents

Before beginning assembly, verify that all components and hardware are present and undamaged. If any parts are missing or damaged, please contact customer support.
While a detailed list of individual parts is not provided here, your package should contain:

- Main panels (top, bottom, side, back)
- Shelves and dividers
- Fluted doors and associated hardware (hinges, handles)
- Metal base frame
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly instructions leaflet

4. Assembly Instructions

Assembly typically requires two adults. Please follow the step-by-step instructions provided in the included assembly leaflet. General tools required may include a Phillips head screwdriver and a hammer.

General Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches. Identify each part using the diagrams in your assembly leaflet.
2. **Attach Cam Locks and Dowels:** Insert cam locks and wooden dowels into the designated holes on the panels as per the instructions.
3. **Assemble Main Frame:** Connect the side panels to the bottom and top panels using the cam locks and screws. Ensure all connections are secure.
4. **Install Shelves and Dividers:** Insert the internal shelves and dividers into their respective positions.
5. **Attach Back Panel:** Secure the back panel to the unit using the provided small nails or screws.
6. **Mount Doors:** Attach the hinges to the fluted doors and then mount the doors to the main frame. Adjust hinges as needed for proper alignment.
7. **Install Handles:** Secure the handles to the fluted doors.
8. **Attach Metal Base:** Carefully attach the gold metal base frame to the bottom of the TV stand.

Refer to the detailed diagrams in your assembly guide for specific part identification and fastening methods.




Image 4.1: Technical diagram illustrating the overall dimensions and internal compartment measurements of the LPKRPL TVST01 TV Stand.

5. Setup and Placement

Once assembled, position your LPKRPL TVST01 TV Stand in its desired location, ensuring it is on a stable and level surface.

- **Surface Preparation:** Ensure the floor or carpet beneath the stand is clean and free of debris to prevent wobbling.
- **TV Placement:** Carefully place your television on the top surface. This stand is designed for TVs up to 77 inches. Ensure the TV's base fits securely within the stand's dimensions and that the weight is evenly distributed.
- **Cable Management:** Utilize the open shelves and internal compartments to organize media devices and route cables neatly.



Image 5.1: The LPKRPL TVST01 TV Stand positioned in a living room, demonstrating its capacity to hold a large television and integrate with modern decor.

6. Operating Features

The LPKRPL TVST01 TV Stand offers various storage solutions for your media components and accessories.

- **Fluted Sliding Doors:** The central compartment features two fluted doors that slide smoothly along a track. Gently push or pull the doors to access the internal shelves. Avoid forcing the doors if they encounter resistance.
- **Open Shelves:** The stand includes open shelves for displaying decorative items or housing frequently accessed media devices.
- **Concealed Storage:** The side compartments and the area behind the sliding doors provide concealed storage for items you wish to keep out of sight.



Image 6.1: The LPKRPL TVST01 TV Stand with its fluted doors open, showcasing the ample internal storage capacity and adjustable shelves for various media components.

7. Maintenance and Care

Proper care will help maintain the appearance and longevity of your TV stand.

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the material.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat:** Do not place hot items directly on the surface without protective coasters.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Re-tighten if necessary.




Image 7.1: Detail view highlighting the durable particle board and MDF construction, resistant to scratches, and the painted metal base designed to prevent rust.

8. Troubleshooting

If you encounter any issues with your TV stand, refer to the following common solutions:

Problem	Possible Cause	Solution
Stand is wobbly or unstable.	Uneven floor surface; loose fasteners.	Move the stand to a level surface. Check and tighten all screws and connections.
Doors do not slide smoothly.	Debris in the track; misaligned doors.	Clean the sliding track. Check door alignment and adjust hinges if necessary.

Problem	Possible Cause	Solution
Parts do not fit together during assembly.	Incorrect orientation of parts; wrong parts used.	Review the assembly instructions and diagrams carefully. Ensure parts are oriented correctly and that you are using the right components for each step.

If the problem persists, please contact customer support for further assistance.

9. Product Specifications

Feature	Detail
Model Number	TVST01
Brand	LPKRPL
Color	Grey
Material	High-quality MDF, Particle Board
Overall Dimensions (W x D x H)	70.90" x 13.80" x 16.10"
Item Weight	65 pounds
TV Size Compatibility	Up to 77 inches
Product Care Instructions	Wipe with Damp Cloth



Image 9.1: A detailed view emphasizing the sleek modern aesthetic of the TV stand, featuring a luxurious faux marble tabletop and a gold metal frame base.

10. Warranty and Customer Support

LPKRPL stands behind the quality of its products. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For assistance with assembly, missing parts, or any other product-related inquiries, please contact LPKRPL customer support through the retailer where the product was purchased or visit the official LPKRPL brand store online.

Online Support: LPKRPL Brand Store

© 2024 LPKRPL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CY2KNS99

More documents and user manuals: **https://manuals.plus/**