

[Manuals.plus](#) /

› [TIQ mini](#) /

› TIQ mini F22 Pro Smart Phone User Manual

TIQ mini F22 Pro

TIQ mini F22 Pro Smart Phone User Manual

Model: F22 Pro

PRODUCT OVERVIEW

The TIQ mini F22 Pro is a compact and smart mobile phone designed for essential communication and modern app functionality. Running on Android 12.0, it features a 3.54-inch touch screen combined with a physical keypad, offering a unique blend of retro design and smart capabilities. It supports 4G connectivity, Wi-Fi, and Bluetooth, ensuring you stay connected.

This device is equipped with an 8-core MTK Helio G85 Chip, providing smooth performance for daily tasks and applications. It comes with 4GB RAM and 64GB internal storage, and has Google Playstore pre-installed, allowing access to a wide range of applications.



Figure 1: Front and back view of the TIQ mini F22 Pro Smart Phone, showcasing its compact design and physical keypad.

GETTING STARTED: SETUP

1. Package Contents

Before you begin, ensure all items are present in the package:

- TIQ mini F22 Pro Smart Phone
- Charging Cable (USB Type-C)
- User Manual (this document)
- Phone Case (included as mounting hardware)

2. Charging the Device

The F22 Pro has a 2120 mAh Lithium Ion battery. Connect the provided charging cable to the phone's USB-C port and plug the other end into a compatible 5V 2A power adapter (not included). The phone does not support fast charging. A full charge typically takes several hours. The battery indicator on the screen will show charging status.

3. Inserting SIM Card and Powering On

The F22 Pro supports 4G cellular technology. Locate the SIM card slot on the side of the device. Use the provided SIM ejector tool (if included) to open the tray. Insert your Nano-SIM card into the tray, ensuring proper orientation. Close the tray securely.

To power on the device, press and hold the Power button (usually located on the side) until the screen illuminates and the TIQ mini logo appears.

4. Initial Setup Wizard

Upon first power-on, the phone will guide you through an initial setup process. This includes:

- Language selection
- Connecting to a Wi-Fi network
- Setting up your Google account (essential for Google Playstore access)
- Setting date and time
- Setting up screen lock (PIN, pattern, or password)

OPERATING YOUR DEVICE

1. Navigation and Interface

The F22 Pro combines a touch screen with physical buttons. You can navigate the Android 12.0 interface using touch gestures on the 3.54-inch IPS display. The physical keypad allows for traditional dialing and text input. The central navigation button on the keypad can be used for scrolling and selection in certain menus.

2. Making Calls and Sending Messages

Use the physical keypad to dial numbers or select contacts from your phonebook. Press the green call button to initiate a call. To send messages, open the messaging application and use either the on-screen keyboard or the physical keypad for text input.

3. Connectivity (Wi-Fi, Bluetooth, Hotspot)

- **Wi-Fi:** Go to *Settings > Network & internet > Wi-Fi* to connect to available Wi-Fi networks.
- **Bluetooth:** Enable Bluetooth in *Settings > Connected devices > Connection preferences > Bluetooth* to pair with headphones, speakers, or other Bluetooth devices.
- **Hotspot:** Share your phone's 4G internet connection by enabling the Wi-Fi hotspot feature in *Settings > Network & internet > Hotspot & tethering > Wi-Fi hotspot*.



Figure 2: The F22 Pro supports 4G connectivity and comes with Google Playstore for app downloads.

4. Using Google Playstore and Applications

The F22 Pro comes with Google Playstore pre-installed, allowing you to download and install a wide variety of applications such as Facebook, Instagram, TikTok, WhatsApp, and more. Ensure you are logged into your Google account to access the Playstore.



Figure 3: The F22 Pro with Google Playstore, enabling access to popular applications.

5. Camera Functionality

The phone features an 8MP rear camera and a 2MP front camera (Sony Imx219 sensor). To take photos or record videos, open the Camera application. Tap the screen to focus, and press the shutter button to capture an image.

Record Your Beauty Moment

Sony Imx219

8MP Rear Camera

2MP Front Camera



Figure 4: Capturing moments with the F22 Pro's camera.

6. Versatile Usage

The F22 Pro is designed to be a versatile device, serving as a primary phone or a reliable backup. Its compact size and smart features make it suitable for various scenarios, from daily communication to managing work tasks or simply reducing screen time by offering a balanced interface.

A stand-alone or alternative phone for your life and work




Figure 5: The F22 Pro as a stand-alone or alternative phone for various life and work scenarios.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid using harsh chemicals or abrasive materials.
- **Software Updates:** Periodically check for system updates in *Settings > System > System update* to ensure your device has the latest features and security patches.
- **Battery Care:** To prolong battery life, avoid exposing the phone to extreme temperatures. It is recommended to keep the battery charge between 20% and 80% for optimal longevity.
- **Storage Management:** Regularly clear unnecessary files and uninstall unused applications to maintain optimal performance. You can check storage usage in *Settings > Storage*.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Phone does not power on.	Low battery; software crash.	Charge the phone for at least 30 minutes. If still unresponsive, perform a force restart by holding the Power button for 10-15 seconds.
Cannot connect to Wi-Fi.	Incorrect password; router issue; Wi-Fi disabled.	Ensure Wi-Fi is enabled. Verify the password. Restart your Wi-Fi router. Forget the network and reconnect.
Apps are slow or crashing.	Insufficient RAM/storage; app bug.	Close background apps. Clear app cache (<i>Settings > Apps > [App Name] > Storage & cache > Clear cache</i>). Free up storage. Update the app or the phone's OS.
Poor call quality.	Weak signal; network congestion.	Move to an area with better cellular reception. Try restarting the phone.

SPECIFICATIONS

Feature	Detail
Brand	TIQ mini
Model Name	F22 Pro
Operating System	Android 12.0
Processor	8-core MTK Helio G85 Chip (MediaTek Kompanio 800T)
RAM	4 GB
Internal Storage	64 GB
Display	3.54-inch IPS Touchscreen
Resolution	720 x 1440 pixels
Rear Camera	8 MP (Sony Imx219)
Front Camera	2 MP
Battery	2120 mAh Lithium Ion
Charging Input	5V 2A (Fast charging not supported)
Connectivity	4G, Wi-Fi, Bluetooth, Hotspot
Dimensions (L x W x H)	5.78 x 2.28 x 0.35 inches (14.68 x 5.79 x 0.89 cm)
Weight	0.26 LB (approx. 118 grams)
Human Interface Input	Touchscreen, Buttons

Light And Compact

You can easily put it in your pocket or hanbag



Figure 6: Physical dimensions and compact nature of the F22 Pro.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official TIQ mini website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.

For common questions and further assistance, you may also refer to the product's listing page on Amazon or contact the seller directly.

© 2024 TIQ mini. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question