#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Cheerble /
- > Cheerble Pumpless Cat Water Fountain E1 User Manual

#### **Cheerble CDY02**

# Cheerble Pumpless Cat Water Fountain E1 User Manual

Model: Elfin E1+ (CDY02)

## 1. Introduction

Thank you for choosing the Cheerble Pumpless Cat Water Fountain E1. This innovative pet water dispenser is designed to provide fresh, clean water for your cats and dogs with minimal maintenance. Featuring MagDrive™ technology, it eliminates the traditional water pump, making cleaning effortless and ensuring superior safety. This manual will guide you through the setup, operation, and maintenance of your new water fountain.



Image 1.1: The Cheerble Pumpless Cat Water Fountain E1, showcasing its sleek design and water level indicator.

## 2. SAFETY INFORMATION

Your pet's safety is our top priority. Please read and adhere to the following safety guidelines:

- **No Electrical Leakage:** The Cheerble E1 Water Fountain is designed with electronic components completely separate from the water source, significantly enhancing safety.
- Automatic Shut-off: The fountain automatically stops dispensing water when the water level is low to prevent damage and ensure safety.
- **BPA-Free Materials:** Constructed from BPA-free materials to ensure the health and well-being of your pets.
- Indoor Use Only: This product is intended for indoor use only.
- Chew-Proof Cable: The charging cable features a durable braided design to prevent pet bites and electric

shock.

• Magnetic Cable Management: Ensures no tangled cords, prevents pull-out by pets, and reduces risk of power port leakage.



Image 2.1: Illustration of the true water-electricity separation design, where all electronic components are housed in a smart base outside the water tank.




Image 2.2: Detail of the durable, braided chew-proof charging cable, designed for pet safety.

#### 3. PRODUCT OVERVIEW

# 3.1 Components

The Cheerble E1 Water Fountain comes with the following components:

- Pet Fountain E1 unit
- Filter
- User Manual
- USB Type-C Cable
- Power Adapter



Image 3.1: All components included in the Cheerble E1 Water Fountain package, neatly arranged.




Image 3.2: A visual representation of what is included in the box: the fountain unit, filter, user manual, USB-C cable, and power adapter.

- Pumpless Design (MagDrive™ Technology): Eliminates traditional water pumps for easy cleaning and no hidden blind spots.
- Multi-layer Filtration: Removes heavy metals, dirt, and other harmful substances for fresh, clean water.
- **Dual Mode Dispensing:** Features Time Mode and Intelligent Mode (PIR sensor activated) to encourage pet hydration.
- **Ultra-Quiet Operation:** Designed to be barely audible, ensuring a peaceful environment for both pets and owners.
- Emergency Storage Capacity: 125ml emergency storage ensures hydration during short power outages.
- Water Shortage Reminder: An indicator light illuminates when the water level is low, prompting a refill.



Image 3.3: The fountain in use with two cats, emphasizing its pumpless design for easy cleaning and freshness.



Image 3.4: A detailed diagram showing the four layers of filtration: PP cotton, ion exchange resin, coconut-shell activated carbon, and another layer of PP cotton.




Image 3.5: A cat drinking from the fountain, illustrating its silent operation that does not disturb pets or owners.

# 4. SETUP GUIDE

Follow these steps to set up your Cheerble Pumpless Cat Water Fountain E1:

- 1. Remove the Replacement Kit (water conduit, impeller) from the box.
- 2. Place the impeller into the groove of the water tank.
- 3. Insert the water conduit above the impeller.

# **Easy Set-up Guide**



Remove the Replacement Kit (water conduit, impeller) from the box.



Place the impeller into the groove of the water tank.



Insert the water conduit above the impeller.

Image 4.1: Visual guide for the initial assembly of the fountain's internal components.

- 4. Soak the filter in water for 5 minutes.
- 5. Rinse the filter for 1 minute.
- 6. Insert the cleaned filter onto the filter tray and press it flat.

# Easy Set-up Guide



Soak the filter in water for 5 minutes.



Rinse the filter for 1 minute.



Insert the cleaned filter onto the filter tray and press it flat.

Image 4.2: Instructions for preparing and installing the multi-layer filter.

- 7. Install the filter tray, water tray, and spout in sequence, securing with the snap lid.
- 8. Insert the cable into one of the slots and plug it into a power source to turn on.
- 9. Properly position the water tank on the base and press the function button for 3 seconds to activate the Cheerble Water Fountain E1.

# **Easy Set-up Guide**



Install the filter tray, water tray, and spout in sequence, securing with the snap lid.



Insert the cable into one of the slots and plug it into a power source to turn on.



Properly position the water tank on the base and press the function button for 3 seconds to activate the Cheerble Water Fountain E1.

Image 4.3: Final steps for assembling the fountain, connecting power, and initial activation.

## 5. OPERATING INSTRUCTIONS

The Cheerble E1 Water Fountain offers two dispensing modes:

- Time Mode: Dispenses water for 20 seconds every 15 minutes.
- **Intelligent Mode:** Automatically dispenses water for 20 seconds when a pet is detected nearby with the built-in PIR smart sensor.

To switch between modes or activate the fountain, refer to the function button on the base unit. The fountain is designed to encourage pets to drink more by providing fresh, flowing water on demand or at regular intervals.



Image 5.1: A cat interacting with the fountain, demonstrating the dual dispensing modes that cater to different pet behaviors.

#### **5.1 Water Shortage Reminder**

The indicator light on the smart base will illuminate when the water level reaches the

#### **Related Documents - CDY02**



#### Cheerble KittySpring 2 Pet Waterer: Installation Guide and FAQ

Comprehensive guide for the Cheerble KittySpring 2 Pet Waterer, covering installation steps, components, and frequently asked questions for optimal use and maintenance.

	Cheerble Pet Fountain E1 User Manual: Setup, Features, and Specifications Comprehensive user manual for the Cheerble Pet Fountain E1 (CDY01), covering setup instructions, component details, operating modes, indicators, specifications, warranty, and terms of use.
Cheerble	
USER MANUAL Pet Fourtain Elfin E1 Lite	Cheerble Pet Fountain Elfin E1 Lite User Manual User manual for the Cheerble Pet Fountain Elfin E1 Lite, providing installation instructions, care guidelines, specifications, and warranty information.
22.1 (2.1 (2.2 (2.2 (2.2 (2.2 (2.2 (2.2	Cheerble Wicked Snail User Manual User manual for the Cheerble Wicked Snail, an interactive smart cat toy. Learn about its features, how to use it, charging instructions, and FCC compliance.
	Cheerble Ball User Manual: Features, Operation, and Specifications  Comprehensive user manual for the Cheerble Ball, detailing its interactive modes, charging, LED indicators, specifications, and warranty information. Learn how to set up and use your Cheerble Ball for pet entertainment.
	Cheerble Ball Ice Cream User Manual and Quick Start Guide Comprehensive user manual and quick start guide for the Cheerble Ball Ice Cream, detailing setup, operation, specifications, and warranty information for this smart interactive pet toy.