

[Manuals.plus](#) /

› [ENJOYWOOD](#) /

› ENJOYWOOD 48 Inch Adjustable Height Workbench with Storage and Power Outlets (Model WB0101-PLUS) User Manual

ENJOYWOOD WB0101-PLUS

ENJOYWOOD 48 Inch Adjustable Height Workbench

Model: WB0101-PLUS

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the ENJOYWOOD 48 Inch Adjustable Height Workbench. This manual provides essential information for the safe assembly, operation, and maintenance of your new workbench. This robust workbench is designed for various applications in garages, workshops, homes, and offices, offering superior stability, ample storage, and convenient power access.

Key features include a durable rubber wood tabletop, an H-shaped steel frame for high load capacity, five adjustable height levels, integrated ETL-certified power outlets, an under-table storage shelf, and three pegboard panels for organized tool storage.



Image: The ENJOYWOOD 48 Inch Adjustable Height Workbench, showcasing its rubber wood tabletop, steel frame, under-table shelf, and pegboard panels.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Ensure all fasteners are securely tightened before placing items on the workbench.
- Do not exceed the maximum load capacity of 2000 lbs (907 kg) for the workbench.
- Distribute weight evenly across the tabletop and shelf.
- Keep children and pets away from the workbench during assembly and operation.
- Use the integrated power outlets only with compatible tools and ensure proper grounding. Do not overload the power strip.

- Adjust the workbench height only when the tabletop is clear of heavy objects. Ensure all locking mechanisms are engaged after adjustment.
- Place the workbench on a level surface. Use the adjustable feet to compensate for minor unevenness.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. Refer to the packing list included with your product for a complete and detailed inventory.

- Rubber Wood Tabletop (1)
- Under-Table Shelf (1)
- Steel H-Frame Legs and Crossbars (Set)
- Adjustable Metal Feet (4)
- Integrated Power Outlet Strip (1)
- Pegboard Panels (3)
- Rubber Protective Pad (1)
- Assembly Hardware (Bolts, Nuts, Washers, Screws, Allen Wrench)
- Instruction Manual (1)

4. SETUP AND ASSEMBLY

The ENJOYWOOD workbench is designed for quick assembly with pre-drilled holes. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble the H-Frame:** Attach the steel legs to the crossbars using the provided hardware. Ensure all connections are finger-tight at this stage.
3. **Attach Adjustable Feet:** Screw the four adjustable metal feet into the bottom of the steel legs.
4. **Install Under-Table Shelf:** Secure the under-table shelf to the H-frame at the desired height using the designated mounting points and hardware.



Under Table Shelf

Expand Storage Space

Image: The under-table shelf provides additional storage space for tools and accessories.

5. **Mount Pegboard Panels:** Attach the three 16x24 inch pegboard panels to the rear of the workbench frame using the supplied hardware.

Increased Storage Space

3 Pcs 16x24 Inch Pegboard




Image: Three pegboard panels offer increased storage and organization for tools.

6. **Install Power Outlets:** Secure the ETL-certified power outlet strip to the designated location on the workbench frame.



Image: The ETL-certified power outlets provide convenient access to power for tools, featuring a switch and cord organizer.

7. **Attach Tabletop:** Carefully place the rubber wood tabletop onto the assembled frame. Align the pre-drilled holes and secure the tabletop with the provided screws.
8. **Tighten All Fasteners:** Once all components are in place, fully tighten all bolts and screws using the included Allen wrench.
9. **Adjust Height:** Loosen the locking pins on the legs, adjust the workbench to one of the five desired height levels (31.5" to 39.4"), and re-engage the locking pins securely.

5-Level Adjustable Heights

Quick and Smooth Adjustment




Image: The workbench offers five adjustable height levels, allowing customization from 31.5 inches to 39.4 inches for ergonomic use.

10. **Level the Workbench:** Adjust the individual metal feet to ensure the workbench is stable and level on uneven ground.
11. **Place Protective Pad:** Lay the 3mm rubber protective pad on the tabletop for added surface protection.

5. OPERATING INSTRUCTIONS

- **Height Adjustment:** To change the workbench height, ensure the tabletop is clear of heavy items. Pull out the locking pins on each leg, raise or lower the tabletop to the desired level, and re-insert the pins firmly into the corresponding holes. Verify all pins are fully engaged before use.
- **Using Power Outlets:** Plug the workbench's main power cord into a grounded electrical outlet. Press the switch button on the power strip to activate the outlets. Plug your power tools into the ETL-certified AC outlets. Always turn off the power strip when not in use.
- **Utilizing Storage:** The under-table shelf provides space for larger items, while the pegboard panels allow for organized hanging storage of tools and accessories. Use appropriate pegboard hooks (not included) for optimal organization.

- **Protective Pad:** The included 3mm rubber pad protects the rubber wood tabletop from scratches, spills, and impacts during work. It can be easily removed for cleaning.

6. MAINTENANCE

- **Cleaning:** Wipe the rubber wood tabletop with a damp cloth and mild detergent. Avoid abrasive cleaners. For the steel frame, use a damp cloth.
- **Fastener Check:** Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain stability.
- **Tabletop Care:** The rubber wood tabletop has a transparent coating for durability. To prolong its life, avoid prolonged exposure to moisture or harsh chemicals.
- **Power Outlet Inspection:** Regularly check the power cord and outlets for any signs of damage. Discontinue use if damage is observed and contact support.

Long-Lasting Rubberwood Tabletop



High-Density



Safety Paint



Easy to Clean

840 sq.inx3mm Protective Pad




Image: The long-lasting rubberwood tabletop is high-density, features safety paint, and is easy to clean, with an optional

7. TROUBLESHOOTING

- **Workbench is unstable/wobbly:**
 - Ensure all assembly bolts and screws are fully tightened.
 - Adjust the individual metal feet to level the workbench on uneven surfaces.
 - Verify that the height adjustment locking pins are fully engaged.
- **Power outlets are not working:**
 - Check if the workbench's main power cord is securely plugged into a functional wall outlet.
 - Ensure the power strip's switch button is in the 'ON' position.
 - Verify that the tool you are trying to use is functioning correctly.
 - Do not overload the power strip. If a circuit breaker trips, unplug devices and reset.
- **Difficulty adjusting height:**
 - Ensure the tabletop is clear of heavy objects before attempting to adjust the height.
 - Confirm that the locking pins are fully disengaged before moving the legs.

8. SPECIFICATIONS

Feature	Specification
Model Number	WB0101-PLUS
Dimensions (L x W)	48 x 20 inches (121.9 x 50.8 cm)
Adjustable Height Range	31.5 to 39.4 inches (80 to 100 cm)
Tabletop Material	1.2 inch (30mm) Rubber Wood
Frame Material	Alloy Steel (2x2 inch / 1.2mm thick steel legs)
Load Capacity	Up to 2000 lbs (907 kg)
Item Weight	45.36 Kilograms
Power Outlets	ETL Certified, with switch and cord organizer
Pegboard Size	Three 16x24 inch panels
Protective Pad	3mm thick, 48x20 inch rubber pad
Assembly Required	Yes

Rugged Structure for Superior **Weight Capacity**



1.2 IN Rubberwood



Stable H-Frame



2"x2" Steel Leg



φ3-3/20" Metal Feet

Image: The workbench features a rugged H-frame structure with 2x2 inch steel legs and 80mm metal feet, contributing to its superior weight capacity of up to 2000 lbs.

9. WARRANTY INFORMATION

Warranty information for the ENJOYWOOD WB0101-PLUS workbench is not provided in this manual. Please refer to the product packaging, the official ENJOYWOOD website, or contact your retailer for detailed warranty terms and conditions.

10. CUSTOMER SUPPORT

For technical assistance, missing parts, or any questions regarding your ENJOYWOOD workbench, please contact ENJOYWOOD customer service directly through their official website or the contact information provided with your purchase. When contacting support, please have your model number (WB0101-PLUS) and purchase date available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question