



## Ashley Kombo 4 in 1 (Model 8.243.0024)

# Lavor Ashley Kombo 4-in-1 Vacuum Cleaner User Manual

Model: Ashley Kombo 4 in 1 (8.243.0024)

## 1. INTRODUCTION

---

The Lavor Ashley Kombo is a versatile 4-in-1 cleaning appliance designed for a variety of tasks. It functions as an ash vacuum, a dry vacuum, a wet vacuum, and a blower. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read these instructions carefully before first use and keep them for future reference.

This appliance is engineered to vacuum ashes from fireplaces, stoves, and barbecues, as well as general dust, debris, and liquids. It features an innovative pneumatic shaker system for quick filter cleaning without opening the unit.

## 2. SAFETY INSTRUCTIONS

---

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance. Failure to follow these instructions may result in serious injury or damage to the appliance.

- **Read all instructions:** Familiarize yourself with the appliance's functions and operating procedures before use.
- **Electrical Safety:** Ensure the power supply voltage matches the rating on the appliance. Do not operate with a damaged cord or plug. Always unplug the appliance from the electrical outlet when not in use, before cleaning, or before performing any maintenance.
- **Flammable Materials:** Never vacuum flammable or combustible liquids, gases, or hot ashes. Ensure ashes are completely cold before vacuuming.
- **Supervision:** This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- **Proper Use:** Use the appliance only for its intended purpose as described in this manual. Do not use it for commercial purposes.
- **Maintenance:** Do not attempt to repair the appliance yourself. Contact qualified service personnel for repairs.

## 3. PRODUCT OVERVIEW AND COMPONENTS

---

The Lavor Ashley Kombo comes with several components designed for its multi-functional capabilities. Please ensure all parts are present before assembly.



Image 1: Lavor Ashley Kombo 4-in-1 vacuum cleaner with its complete set of accessories, including hoses, nozzles, and filters.

### Included Components:

- Main Unit (Motor head, double collection tank)
- Flexible Suction Hose (for general vacuuming)
- Metal Suction Hose (for ash vacuuming)
- Extension Tube
- Floor Nozzle
- Crevice Tool
- Washable Cartridge Filter
- Nylon Filter (for ash collection)
- Air Shaker System
- Wheels (pre-installed or to be attached)

## 4. SETUP AND ASSEMBLY

---

Follow these steps to assemble your Lavor Ashley Kombo before initial use.

1. **Unpacking:** Carefully remove all components from the packaging. Check for any damage.
2. **Wheel Installation:** If the wheels are not pre-installed, insert them into the designated slots on the base of the collection tank until they click into place.
3. **Filter Installation (Dry/Wet Vacuuming):**
  - For dry vacuuming (general dust, debris), ensure the washable cartridge filter is securely installed over the

motor head's filter cage.

- For wet vacuuming, remove the cartridge filter and ensure the foam filter (if included, or use the nylon filter) is in place to protect the motor from liquids.
4. **Filter Installation (Ash Vacuuming):** For ash vacuuming, install the nylon filter over the cartridge filter or directly onto the filter cage, depending on the model, to provide an extra layer of protection against fine ash particles.
  5. **Attach Motor Head:** Place the motor head securely onto the collection tank and fasten the side clips.
  6. **Connect Hose:** Insert the desired suction hose (flexible for general, metal for ash) into the suction inlet on the front of the unit. Ensure it is firmly connected.
  7. **Attach Accessories:** Connect the extension tube and desired nozzle (floor nozzle, crevice tool) to the end of the suction hose.

## 5. OPERATING INSTRUCTIONS

---

The LAVOR Ashley Kombo offers four distinct functions. Select the appropriate mode for your cleaning task.

### 5.1 Ash Vacuuming

This function is specifically designed for cleaning cold ashes from fireplaces, wood stoves, and barbecues.

- **Preparation:** Ensure ashes are completely cold. Never vacuum hot or glowing embers.
- **Filter:** Ensure the nylon filter and cartridge filter are correctly installed for optimal ash collection and motor protection.
- **Hose:** Use the metal suction hose for ash vacuuming.
- **Operation:** Insert the hose into the ash and move it slowly to collect the material.
- **Filter Shaker:** During operation, or when suction power decreases, activate the pneumatic filter shaker (if equipped) by pressing the designated button or lever. This will dislodge ash from the filter, restoring suction without opening the unit.



Image 2: A user demonstrating the ash vacuuming function, cleaning cold ashes from a fireplace.

## 5.2 Dry Vacuuming

For general dry debris, dust, and dirt.

- **Filter:** Ensure the washable cartridge filter is installed. The nylon filter can also be used for finer dust.
- **Hose & Nozzle:** Use the flexible suction hose with the extension tube and appropriate nozzle (floor nozzle for large areas, crevice tool for tight spaces).
- **Operation:** Plug in the appliance and turn it on using the power switch. Move the nozzle over the area to be cleaned.

## 5.3 Wet Vacuuming

For vacuuming liquids and wet spills.

- **Filter: Remove the cartridge filter** before wet vacuuming. Ensure the foam filter (if supplied) or nylon filter is in place to protect the motor from water ingress.
- **Tank:** Monitor the liquid level in the collection tank. Do not overfill. The appliance may have a float valve that will automatically shut off suction when the tank is full.
- **Operation:** Use the flexible suction hose and a suitable wet nozzle.
- **After Use:** Empty and clean the collection tank immediately after wet vacuuming to prevent odors and mold.

## 5.4 Blower Function

The appliance can also be used as a blower for clearing debris from surfaces.

- **Setup:** Disconnect the suction hose from the intake port. Connect the flexible suction hose to the blower outlet port (usually located on the motor head, opposite the suction inlet).

- **Operation:** Turn on the appliance. Air will be expelled from the hose, allowing you to blow away light debris.



Image 3: A user operating the LAVOR Ashley Kombo outdoors, demonstrating its versatility for various cleaning tasks.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your LAVOR Ashley Kombo.

- **Emptying the Tank:** Regularly empty the collection tank, especially after vacuuming ashes or liquids. Unclip the motor head and lift it off. Dispose of contents responsibly.
- **Cleaning Filters:**
  - **Cartridge Filter:** The cartridge filter is washable. Remove it from the unit and rinse it under running water. Allow it to air dry completely before re-installing. Do not use hot water or detergents.
  - **Nylon Filter:** The nylon filter can be brushed clean or rinsed with water. Ensure it is dry before re-use.
  - **Pneumatic Shaker:** Utilize the built-in pneumatic shaker frequently during ash vacuuming to maintain filter efficiency.
- **Cleaning Hoses and Accessories:** Periodically check hoses and nozzles for blockages. Clean them with water if necessary and ensure they are dry before storage.
- **Exterior Cleaning:** Wipe the exterior of the appliance with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the appliance in a dry, cool place, away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

---

If you encounter issues with your LAVOR Ashley Kombo, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not start.	No power supply; Power switch off; Damaged power cord/plug.	Check power outlet; Ensure power switch is ON; Inspect cord/plug for damage (do not use if damaged, contact service).
Loss of suction power.	Clogged filter; Full collection tank; Blockage in hose/nozzle; Improperly sealed motor head.	Clean or replace filter; Empty collection tank; Clear any blockages; Ensure motor head is securely fastened. Use filter shaker for ash.
Water/liquid escaping during wet vacuuming.	Cartridge filter not removed; Tank overfilled; Float valve malfunction.	Remove cartridge filter for wet use; Empty tank; If float valve is stuck, clean it.
Unusual noise from motor.	Motor obstruction; Damaged motor.	Unplug and check for obstructions; If noise persists, contact customer support.

## 8. SPECIFICATIONS

---

Technical details for the LAVOR Ashley Kombo 4-in-1 Vacuum Cleaner.

Feature	Detail
<b>Model Name</b>	Ashley Kombo 4 in 1
<b>Model Number</b>	8.243.0024
<b>Manufacturer</b>	LAVOR
<b>Power (Max)</b>	1200 Watts
<b>Capacity</b>	30 Liters (Double collection tank)
<b>Max Depression</b>	180 mbar
<b>Air Flow</b>	30 liters/second
<b>Filter Type</b>	Washable Cartridge Filter, Nylon Filter
<b>Special Features</b>	4-in-1 (Ash, Dry, Wet Vacuum, Blower), Pneumatic Filter Shaker, Double Electrical Insulation, By-pass Cooling System
<b>Power Source</b>	Electric Cable
<b>Dimensions (L x W x H)</b>	37 cm x 37 cm x 71 cm
<b>Recommended Uses</b>	Cleaning fireplaces and stoves, general dry cleaning, general wet cleaning

## 9. WARRANTY AND CUSTOMER SUPPORT

---

For warranty information or if you require further assistance, please contact your retailer or the manufacturer's customer support. Keep your purchase receipt as proof of purchase.

For service or technical inquiries, please refer to the contact information provided with your product packaging or visit the official LAVOR website.

