Victrola VOS-600-STN

Victrola Rock Speaker Connect User Manual

Model: VOS-600-STN

Introduction

Thank you for choosing the Victrola Rock Speaker Connect. This outdoor wireless speaker is designed to seamlessly blend into your outdoor environment while delivering high-quality audio. Featuring Bluetooth 5.3, solar charging, and IP65 water and dust resistance, it's built for extended outdoor use. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your speaker.
For optimal performance and longevity, please read this manual thoroughly before use and retain it for future reference.

What's in the Box

- Victrola Rock Speaker Connect (Stone Single)
- USB-C Charging Cable
- User Manual (this document)

Key Features

- **Wireless Outdoor Design:** Blends naturally into garden, patio, or poolside environments.
- **Bluetooth 5.3 Connectivity:** For seamless streaming from compatible devices.
- **Multi-Speaker Linking:** Connect up to 20 Rock Speakers for expansive sound coverage.
- **Dual Charging Options:** Integrated solar panel for sustainable power and USB-C port for quick charging.
- **Extended Battery Life:** Up to 22 hours of playback at 60% volume.

- **Durable Construction:** IP65 water and dust resistant for all-weather outdoor use.

Setup Guide

1. Initial Charging

Before first use, fully charge the speaker using the provided USB-C cable. The charging port is located on the back of the speaker, typically under a protective cover to maintain water resistance.




Image: Rear view of the Victrola Rock Speaker Connect, highlighting the USB-C charging port and the solar panel on top. This image illustrates the dual charging capabilities of the speaker.

- Connect the USB-C cable to the speaker's charging port and the other end to a 5V 2A USB power adapter (not included).

- The LED indicator will show charging status. Once fully charged, the indicator will change (refer to the LED indicator section for details).
- The integrated solar panel provides continuous charging under direct sunlight, extending battery life during outdoor use.

2. Placement

The Victrola Rock Speaker Connect is designed to blend into outdoor landscapes. Choose a location that allows for optimal sound dispersion and, if relying on solar charging, sufficient direct sunlight exposure.



Image: A single Victrola Rock Speaker Connect, stone-colored, placed discreetly among garden rocks and mulch, demonstrating its natural integration into an outdoor environment.



Image: A Victrola Rock Speaker Connect, sand-colored, positioned in a garden bed with mulch and a potted plant, showcasing its built-in solar panel on top for continuous charging.

- Ensure the speaker is placed on a stable, level surface.
- For best sound, avoid placing the speaker directly against large obstacles that could block sound.
- Consider the IP65 rating, which protects against water jets and dust, making it suitable for various outdoor conditions.

Operating Instructions

1. Powering On/Off

- To power on, press and hold the Power button (usually located near the charging port) for a few seconds until you

hear an audible prompt or see the LED indicator light up.

- To power off, press and hold the Power button again until the speaker shuts down.

2. Bluetooth Pairing

- Ensure the speaker is powered on and in pairing mode (LED indicator will typically flash blue).
- On your smartphone, tablet, or laptop, enable Bluetooth and search for available devices.
- Select "Victrola Rock Speaker" (or similar name) from the list.
- Once paired, the LED indicator will turn solid blue, and you will hear a confirmation sound.

3. Multi-Speaker Linking (Up to 20 Speakers)

The Victrola Rock Speaker Connect supports linking multiple speakers for a wider soundstage.



Image: An aerial view diagram illustrating how multiple Victrola Rock Speakers can be wirelessly linked and strategically placed around a pool and patio area to create an immersive sound experience.

- Power on all speakers you wish to link.

- Pair your primary speaker to your Bluetooth device as described above.
- On the primary speaker, press the "Link" button (refer to the speaker's control panel for exact button). The primary speaker will enter linking mode.
- On each secondary speaker, press its "Link" button. They will automatically search for and connect to the primary speaker.
- Once linked, all speakers will play audio from your Bluetooth device simultaneously.

4. Volume Control

- Adjust volume directly from your connected Bluetooth device.
- Some speakers may have physical volume buttons (+/-) on the unit itself.

5. Audio Playback

- Once connected, simply start playing audio from your paired device.
- The speaker will automatically play the audio.

Maintenance and Care

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** While IP65 rated, avoid submerging the speaker in water. Ensure the USB-C port cover is securely closed when not charging to maintain water resistance.
- **Storage:** If storing for extended periods, fully charge the battery and store in a cool, dry place. Recharge every few months to maintain battery health.
- **Solar Panel:** Keep the solar panel clean and free of debris to ensure efficient charging.

Troubleshooting

Problem	Possible Solution
Speaker does not power on.	◦ Ensure the battery is charged. Connect to USB-C charger. ◦ Press and hold the Power button for a longer duration (5-7 seconds).
Cannot pair via Bluetooth.	◦ Ensure the speaker is in pairing mode (flashing LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move your device closer to the speaker. ◦ Forget the speaker from your device's Bluetooth list and try pairing again. ◦ Restart both the speaker and your Bluetooth device.

Problem	Possible Solution
No sound or low volume.	◦ Increase volume on both the speaker and your connected device. ◦ Ensure the speaker is properly paired. ◦ If using multiple speakers, ensure they are correctly linked.
Multi-speaker linking issues.	◦ Ensure all speakers are within range of each other. ◦ Follow the linking instructions carefully, ensuring one speaker is designated as primary. ◦ Power cycle all speakers and try linking again.
Solar charging not working.	◦ Ensure the solar panel is clean and free of obstructions. ◦ Place the speaker in direct sunlight for optimal charging. ◦ Note that solar charging is slower than USB-C charging and may not fully charge the speaker on its own, especially in low light conditions.

Specifications

Feature	Detail
Model Name	VOS-600-STN
Connectivity Technology	Bluetooth 5.3
Speaker Type	Outdoor
Water Resistance Level	IP65 (Water & Dust Resistant)
Power Source	Battery Powered, Solar Powered
Battery Life	Up to 22 Hours (at 60% volume)
Speaker Maximum Output Power	20 Watts
Product Dimensions	12.6"D x 10.83"W x 10.04"H
Item Weight	6.6 pounds (3 Kilograms)
Material	Stone
Color	Stone
UPC	810033113017

Warranty and Support

The Victrola Rock Speaker Connect comes with a limited warranty. For detailed warranty information, please refer to the warranty card included with your product or visit the official Victrola website.
For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Victrola Customer Service:

- **Website:** www.victrola.com
- **Email:** Refer to website for contact form or email address.
- **Phone:** Refer to website for phone support numbers.

Please have your model number (VOS-600-STN) and purchase date available when contacting support.

Important Safety Information

- Do not expose the speaker to extreme temperatures or direct flame.
- Do not attempt to disassemble or modify the speaker. This will void the warranty and may cause damage.
- Keep out of reach of children and pets.
- Dispose of the product responsibly according to local regulations. Do not dispose of batteries in household waste.

© 2025 Victrola. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question