Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AISVELDY F6

AISVELDY F6 Rechargeable Camping Fan - Instruction Manual

Model: F6

1. Introduction

Thank you for choosing the AISVELDY F6 Rechargeable Camping Fan. This versatile device combines powerful airflow with integrated LED lighting and portable charging capabilities, making it ideal for various indoor and outdoor activities. Please read this manual carefully before use and retain it for future reference.



Figure 1: AISVELDY F6 Rechargeable Camping Fan

2. Package Contents

Ensure all items are present in the package:

- 1 x AISVELDY F6 Personal Fan Body
- 1 x Remote Control
- 1 x USB to Type-C Charging Cable

3. Product Features

3.1. High-Capacity Rechargeable Battery:

Equipped with a 20000mAh internal battery, providing 14 to 60 hours of runtime depending on the mode. Fully charges in 8-10 hours via the Type-C port. Features a 5V/3A USB-A output port to charge external devices.



Figure 2: 20000mAh Battery and Runtime



Figure 3: USB Output for Device Charging

3.2. Powerful and Quiet Airflow:

Features a brushless motor and upgraded fan blades for strong airflow with a noise level below 30dB. Offers 4 adjustable wind speeds.



Figure 4: Four Adjustable Wind Speeds



Figure 5: Ultra-Quiet Operation

3.3. Integrated LED Camping Lantern:

Includes an LED light with 3 brightness levels for illumination in various settings, from reading to lighting a tent.



Figure 6: Adjustable LED Lighting Modes

3.4. Adjustable and Portable Design:

Features 45°/90° auto oscillation and 270° manual rotation for flexible airflow direction. A 360° rotating hidden hook allows for easy hanging.



Figure 7: Adjustable Fan Head



Figure 8: Integrated Hanging Hook

3.5. Remote Control and Timer:

Offers dual control via remote or base buttons. The remote has a 16ft range and can be stored in a dedicated slot. Timer settings include 1/2/4/8 hours for automatic shutoff.




Figure 9: Manual and Remote Control Functions



Figure 10: Remote Control Storage

4. Setup and Charging

4.1. Initial Charge

Before first use, fully charge the fan's internal 20000mAh battery. Connect the provided USB-C cable to the fan's Type-C input port and a compatible USB power adapter (not included). The battery indicator lights on the base will show charging progress.



Figure 11: USB-C Input and USB-A Output Ports

4.2. Remote Control Setup

The remote control is pre-paired. Ensure the plastic battery tab is removed before use. Store the remote in the designated slot on the fan base to prevent loss.

5. Operating Instructions

5.1. Power On/Off

Press the power button on the fan base or the ON/OFF button on the remote control to turn the fan on or off.

5.2. Adjusting Fan Speed

Press the fan speed button on the base or the Speed +/- buttons on the remote to cycle through the 4 available wind speeds.

5.3. LED Light Operation

Press the light button on the base or the Light button on the remote to turn the LED light on/off and cycle through the 3 brightness levels.

5.4. Oscillation and Rotation

Press the oscillation button on the base or the Rotate button on the remote to activate 45°/90° auto oscillation. The fan head can also be manually rotated 270° for precise airflow direction.

5.5. Timer Function

Press the timer button on the base or the Time button on the remote to set the automatic shutoff timer to 1, 2, 4, or 8 hours.

5.6. Sleep Mode

Activate sleep mode via the remote control to turn off indicator lights for undisturbed rest.

5.7. Charging External Devices

Connect your device to the USB-A output port (5V/2A) on the fan base using a compatible USB cable.

Your browser does not support the video tag. Please update your browser.

Video 1: Demonstration of the fan's features and portability.

Your browser does not support the video tag. Please update your browser.

Video 2: Overview of the fan's battery and charging capabilities.

Your browser does not support the video tag. Please update your browser.

Video 3: Guide on how to use the rechargeable fan's various functions.

6. Maintenance

- Clean the fan blades and exterior regularly with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Ensure the fan is turned off and unplugged before cleaning.
- Store the fan in a cool, dry place when not in use.

7. Troubleshooting

- **Fan not turning on:** Ensure the battery is charged. Press the power button firmly.
- **Remote control not working:** Check if the plastic battery tab has been removed. Ensure the remote is pointed towards the fan's sensor.
- **Light not working:** Press the light button to cycle through brightness levels.
- **External device not charging:** Ensure the fan battery has sufficient charge. Check the USB cable connection.

8. Specifications

Feature	Specification
Brand	AISVELDY
Model Name	Personal Fan F6
Power Source	Battery Powered
Battery Capacity	20000mAh Lithium Polymer
Charging Time	8-10 hours (Type-C)
Runtime	14 to 60 hours (depending on mode)
Fan Speeds	4 Levels
Noise Level	< 30 Decibels
LED Light Brightness	3 Levels
Oscillation	45°/90° Auto Oscillation
Rotation	270° Manual Rotation
Timer Settings	1H, 2H, 4H, 8H
Control Method	Remote, Touch
Remote Range	16ft
Output Port	USB-A (5V-2A)

Input Port	USB Type C
Product Dimensions	4.4"D x 8.66"W x 11.3"H
Item Weight	3.25 pounds
Certifications	FCC, RoHS, UL

9. Warranty and Support

For any issues or support, please contact the seller AISHOPJH-US. Refer to your purchase documentation for specific warranty details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question