



Manuals.plus /

› MSmask /

› MSmask Farmhouse Vanity Desk with Mirror and Lights, Model 207 - Instruction Manual

MSmask 207

MSmask Farmhouse Vanity Desk with Mirror and Lights (Model 207) - Instruction Manual

Comprehensive guide for assembly, operation, and maintenance.

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always unplug the vanity before assembly or disassembly.
- Be cautious of sharp edges and heavy components during assembly.
- Keep electrical components away from water.
- Do not exceed the weight limit of the vanity.

PRODUCT OVERVIEW

The MSmask Farmhouse Vanity Desk (Model 207) is designed to provide a functional and aesthetically pleasing space for personal grooming. It features a farmhouse-style design with ample storage and integrated lighting.

Key Features:

- **Farmhouse Style:** Distressed white finishes, z-brace barn door trim, and exposed metal hardware.
- **Sliding Door Design:** Unique sliding barn doors on the upper part can conceal shelves or the lighted mirror.
- **Powerful Storage Space:** Overall size: 41"W x 16.1"D x 57.3"H. Includes 8 storage compartments, 2 drawers, and 1 storage cabinet. Adjustable shelves and 4 metal hooks for accessories.
- **3-Color Adjustable Hollywood Bulbs:** 18.6"W x 18.9"H mirror with 8 light bulbs. Offers warm yellow, warm white, and cool white modes with adjustable brightness.
- **Integrated Charging Station:** Equipped with 2 standard plug sockets and 2 USB ports for convenient device charging and powering styling tools.



Image: The MSmask Farmhouse Vanity Desk in Antique White, showcasing its overall design with the mirror and lights exposed.

Product Overview Video:

Your browser does not support the video tag.

Video: A brief overview of the MSmask 41 Inch Sliding Door Farmhouse Vanity Desk, highlighting its key features and design elements.

SPECIFICATIONS

Feature	Detail
Brand	MSmask
Model Number	207
Overall Dimensions (W x D x H)	41" x 16.1" x 57.3"
Item Weight	92.6 pounds
Frame Material	Engineered Wood
Furniture Finish	Weathered White and Distressed Wood Finish
Color	Antique White
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Charging Station	2 AC Outlets (125V/12A), 2 USB Ports (5V/2A), 4.9-Foot Power Cord, On/Off Switch
Mirror Lighting	8 Hollywood Bulbs, 3 adjustable color modes (warm yellow, warm white, cool white), adjustable brightness.



3 Lighting Modes & Adjustable Brightness



Cool White

Warm White

Warm Yellow



Adjust via buttons



Image: Detailed dimensions of the MSmask Farmhouse Vanity Desk, including height, width, and depth measurements for various sections.

SETUP AND ASSEMBLY

This vanity desk requires assembly. Please follow the included instructions carefully. It is recommended to have two people for assembly due to the size and weight of some components.

Before You Begin:

- Unpack all components and verify against the parts list in your physical instruction manual.
- Ensure you have all necessary tools (typically a screwdriver and hammer, not included).
- Assemble on a soft, clean surface to prevent scratches.

Assembly Video:

Your browser does not support the video tag.

Video: A detailed installation guide for the MSmask Farmhouse Vanity Desk, demonstrating step-by-step assembly of all components.

General Assembly Steps (Refer to physical manual for detailed diagrams):

1. Assemble the base frame of the vanity desk.
2. Attach the side panels and support beams.
3. Install the tabletop, ensuring the charging station cutout aligns correctly.
4. Assemble the upper hutch structure, including the mirror frame and shelves.
5. Mount the upper hutch onto the tabletop.
6. Install the drawer slides and assemble the drawers.
7. Attach the sliding barn doors to the upper hutch.
8. Install the mirror lights and connect the wiring to the charging station.
9. Secure any remaining hardware and perform a final check for stability.

OPERATING INSTRUCTIONS

Using the Mirror Lights:

- Connect the light power cord to a standard electrical outlet.
- Use the inline control button to turn the lights ON/OFF.
- Press the control button repeatedly to cycle through the 3 color modes: warm yellow, warm white, and cool white.
- Hold the control button to adjust the brightness within each color mode.



Image: The vanity mirror lights demonstrating the three adjustable color modes: Cool White, Warm White, and Warm Yellow, with a brightness adjustment slider.

Using the Charging Station:

- Ensure the vanity is plugged into a functional wall outlet.
- Plug your devices into the 2 standard AC outlets or the 2 USB ports located on the tabletop.
- Use the ON/OFF switch on the charging station to control power to the outlets and USB ports.



Vanity with Charging Station

Embedded power strip, reduce clutter



125V/12A
[2 AC Outlets]



5V/2A
[2 USB Ports]



4.9-Feet
[Power Cord]



On/Off
[Power Switch]

Image: A close-up view of the integrated charging station on the vanity desk, featuring two AC power outlets and two USB ports, with a power switch.

Sliding Barn Doors:

- The barn doors can slide horizontally to cover either the mirror or the side storage shelves, as desired.
- Gently slide the doors along the track to adjust their position.

Unique Sliding Door Design

Sliding barn doors, adjust door position as needed



Image: The unique sliding barn door design of the vanity, illustrating how the doors can be positioned to hide either the mirror or the side storage shelves.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the vanity surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Mirror Care:** Clean the mirror with a glass cleaner and a soft, lint-free cloth.
- **Electrical Components:** Ensure all electrical connections are secure. Do not attempt to repair or modify the electrical components yourself. Contact qualified personnel if issues arise.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights not turning on.	Power cord not plugged in; power switch off; loose connection.	Ensure power cord is securely plugged into outlet. Turn on the inline power switch. Check all light bulb connections.
Charging station not working.	Vanity not plugged in; charging station switch off; device not properly connected.	Verify the vanity's main power cord is plugged in. Ensure the charging station's ON/OFF switch is engaged. Reconnect your device.
Drawers are stiff or not sliding smoothly.	Drawer slides are misaligned or dirty; screws are loose.	Check alignment of drawer slides and clean any debris. Tighten all screws on the drawer slides.
Sliding doors are sticking.	Track is dirty or obstructed; doors are misaligned.	Clean the sliding track of any dust or debris. Gently adjust the doors to ensure proper alignment on the track.

WARRANTY AND SUPPORT

Msmask products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or contact Msmask customer service.

Customer Service:

If you have any questions, require assistance with assembly, or need to report damaged/lost parts, please contact Msmask customer service.

- **Contact Information:** Refer to your product packaging or the official Msmask website for the most current contact details.
- **Online Support:** Visit the Msmask Store on Amazon for additional product information and support resources.