

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Trevi](#) /
- › [Trevi XFest XF 1600 KB Amplified Speaker User Manual](#)

Trevi XF 1600 KB

Trevi XFest XF 1600 KB Amplified Speaker User Manual

Model: XF 1600 KB

INTRODUCTION

Thank you for purchasing the Trevi XFest XF 1600 KB Amplified Speaker. This powerful portable speaker is designed to deliver high-quality audio with versatile connectivity options, including wireless Bluetooth, USB, MicroSD, and AUX-IN. It also features a karaoke function with an included microphone and True Wireless Stereo (TWS) capability for connecting two speakers.

This manual provides essential information for the safe and efficient operation of your speaker. Please read it thoroughly before use and keep it for future reference.



Image: Front view of the Trevi XFest XF 1600 KB Amplified Speaker, showcasing its integrated colorful LED lighting around the main speaker cone.

PACKAGE CONTENTS

Please check that all items are present and in good condition:

- Trevi XFest XF 1600 KB Amplified Speaker
- Power Adapter
- User Manual (this document)
- Warranty Certificate
- Dynamic Microphone
- Full Control Remote Control

SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the unit to rain or moisture to prevent fire or electric shock.
- Do not block ventilation openings. Ensure adequate space around the unit for proper airflow.
- Use only the power adapter supplied with the unit.
- Do not open the speaker casing. Refer all servicing to qualified personnel.
- Keep the unit away from direct sunlight, heat sources, and strong magnetic fields.
- Avoid placing heavy objects on top of the speaker.
- When moving the speaker, ensure the trolley handle is fully extended and locked, and use caution due to its weight.

PRODUCT COMPONENTS AND CONTROLS

Familiarize yourself with the various parts and controls of your Trevi XFest XF 1600 KB speaker.



Image: Close-up of the speaker's control panel, showing the LED display, volume knobs, equalizer sliders, and various input ports (USB, MicroSD, AUX-IN, Microphone 1, Microphone 2, Guitar).

Control Panel Overview:

- **1. LED Light Switch:** Toggles the speaker's integrated LED lights on/off.
- **2. Master Volume Control:** Adjusts the overall output volume of the speaker.
- **3. Microphone Volume Control:** Adjusts the volume of the connected microphones.
- **4. Guitar Input:** 6.3mm jack for connecting a guitar.
- **5. Microphone Inputs (MIC1, MIC2):** Two 6.3mm jacks for connecting microphones.
- **6. Power Switch:** Turns the speaker on or off.
- **7. LED Display:** Shows current mode, track information, and other status indicators.
- **USB Port:** For playing audio files from a USB flash drive.
- **MicroSD Card Slot:** For playing audio files from a MicroSD card.
- **AUX-IN:** 3.5mm jack for connecting external audio devices.
- **Equalizer Controls:** Adjust bass, treble, and other audio frequencies.
- **Echo/Delay Controls:** Adjust echo and delay effects for microphone inputs.



Image: Side view of the speaker, highlighting the extendable trolley handle for easy transport and additional side handles.



Image: The full-function remote control, featuring buttons for power, mode selection, volume, track control, EQ, and more.

SETUP

Initial Charging:

Before first use, fully charge the speaker's internal rechargeable battery. Connect the supplied power adapter to the DC 15V input port on the speaker and plug it into a wall outlet. The charging indicator light will show the charging status. A full charge typically takes several hours.

Powering On/Off:

Locate the Power Switch (6) on the control panel. Flip the switch to the "ON" position to power on the speaker. The LED display will light up. To power off, flip the switch to the "OFF" position.

Microphone Connection:

Connect the included dynamic microphone to either MIC1 or MIC2 input (5) on the control panel. Adjust the Microphone Volume Control (3) to your desired level. You can also adjust echo and delay effects using the dedicated controls.



Image: A person demonstrating the extendable trolley handle, making the speaker easy to move despite its size.

OPERATING INSTRUCTIONS

Mode Selection:

Press the "MODE" button on the control panel or remote control to cycle through available input modes: Bluetooth, USB, MicroSD, AUX-IN, and FM Radio (if available).

Bluetooth Pairing:

1. Turn on the speaker and select Bluetooth mode. The LED display will show "BLUE" and a blinking Bluetooth icon, indicating it's ready for pairing.
2. Enable Bluetooth on your smartphone, tablet, or other device.
3. Search for "TREVI XF 1600 KB" in your device's Bluetooth list and select it to connect.
4. Once paired, the Bluetooth icon on the speaker's display will stop blinking, and you will hear a confirmation sound.
5. You can now play audio wirelessly from your device.

USB/MicroSD Playback:

Insert a USB flash drive or MicroSD card (with MP3 files) into the corresponding port. The speaker will automatically switch to USB or MicroSD mode and begin playing audio. Use the playback controls (Play/Pause, Next/Previous Track) on the control panel or remote control.

AUX-IN Connection:

Connect an external audio device (e.g., MP3 player, computer) to the AUX-IN port using a 3.5mm audio cable. Select

AUX-IN mode on the speaker. Audio will be played through the speaker, controlled by the external device's volume.

Karaoke Function:

With a microphone connected to MIC1 or MIC2, you can sing along to your music. Adjust the microphone volume and apply echo/delay effects as desired for a better karaoke experience.



Image: A person using the microphone with the speaker, demonstrating its karaoke capabilities.

True Wireless Stereo (TWS) Pairing:

The TWS function allows you to connect two XF 1600 KB speakers wirelessly for a more immersive stereo sound experience.

1. Ensure both XF 1600 KB speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one of the speakers (this will be the master), press and hold the TWS button (usually indicated by two interlocking arrows or "TWS").
3. The speaker will search for the other unit. Once connected, you will hear a confirmation sound, and the TWS indicator will light up on both speakers.
4. Now, connect your Bluetooth device to the master speaker. Audio will play in stereo through both speakers.

Collegamento wireless di due
XF 1600 KB

Modalità di connessione TWS



Raddoppiate il volume ed
ottenete un suono stereo più
realistico



Image: A visual representation of how two XF 1600 KB speakers connect wirelessly using the TWS function to create a stereo sound system.



Image: A hand turning a control knob on the speaker's top panel, demonstrating user interaction with the device's settings.

MAINTENANCE

Cleaning:

Wipe the speaker's exterior with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Avoid spraying liquids directly onto the speaker.

Storage:

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to charge the battery periodically (e.g., every 3-6 months) to maintain its lifespan.

Battery Care:

To maximize battery life, avoid fully discharging the battery frequently. Recharge the speaker when the low battery indicator appears. Do not leave the speaker uncharged for very long periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is depleted; Power adapter not connected properly.	Charge the speaker using the supplied power adapter; Ensure power adapter is securely connected to both the speaker and a working power outlet.
No sound	Volume is too low; Incorrect input mode selected; Device not properly connected (Bluetooth, AUX, USB/MicroSD).	Increase master volume; Select the correct input mode; Repair Bluetooth device, check AUX cable, or re-insert USB/MicroSD.
Bluetooth pairing fails	Speaker not in pairing mode; Device too far from speaker; Interference; Speaker already connected to another device.	Ensure speaker is in Bluetooth pairing mode (blinking "BLUE"); Move device closer to speaker; Turn off other Bluetooth devices; Disconnect from previous device.
Microphone not working	Microphone not connected; Microphone volume too low; Microphone faulty.	Ensure microphone is securely plugged into MIC1 or MIC2; Increase microphone volume; Test with another microphone if available.
TWS pairing fails	Speakers not in TWS pairing mode; Speakers too far apart; One speaker already connected to a Bluetooth device.	Ensure both speakers are in Bluetooth mode and not connected to any device before initiating TWS pairing; Move speakers closer; Disconnect any Bluetooth devices from both speakers.

SPECIFICATIONS

Feature	Detail
Model Number	0X160000
Power Output	200W (Max)
Connectivity Technology	Bluetooth, USB, MicroSD, AUX-IN
Audio Inputs	2 x Microphone (6.3mm), 1 x Guitar (6.3mm), 1 x AUX-IN (3.5mm)

Feature	Detail
Channels	2
Power Source	Battery Powered / AC Adapter
Battery Type	Internal Rechargeable (12V-7Ah)
Material	Robust materials
Color	Black
Item Weight	18.5 Kilograms
Product Dimensions (LxWxH)	34.5 x 51.8 x 70.25 cm
Mounting Type	Floor Standing
Special Features	Karaoke Function, TWS (True Wireless Stereo), Integrated LED Lights, Trolley System

WARRANTY AND SUPPORT

This product is manufactured by Trevi. For warranty information and support, please refer to the warranty certificate included in your package.

In case of a defective or damaged product, please consult the return policy of your retailer. For purchases made on Amazon.it, you may return a product within 30 days of receipt if you change your mind. Specific information regarding returns for defective or damaged products, or purchases from marketplace sellers, can be found on Amazon's help pages.

For technical assistance or further inquiries, please contact Trevi customer support through their official channels, as indicated in the warranty documentation or on their website.

© 2024 Trevi. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents - XF 1600 KB

	<p>Trevi XF 370 KB Portable Bluetooth Speaker User Manual</p> <p>Comprehensive user manual for the Trevi XF 370 KB portable speaker, covering setup, functions, Bluetooth connectivity, TWS pairing, USB/SD playback, AUX input, disco light effects, microphone use, recording, technical specifications, and disposal information.</p>
---	--



[\[pdf\]](#) User Manual Guide

XF 1600 KB Guida d'uso User guide manual dmi es 2315 109715 60466106 |||

XF 1600 KB Guida d'uso User guide ALTOPARLANTE AMPLIFICATO ALTA POTENZA Manuale d'uso e collegamento HIGH POWER PORTABLE SPEAKER Connection and Operation Manual HAUT-PARLEUR PORTABLE AMPLIFIE Mode d'emploi et branchement BEWEGLICHER LAUTSPRECHER Gebrauchs- und Anschlusshandbuch ALTAVOZ AMPLIFICADO ...

lang:it score:56 filesize: 1006.63 K page_count: 44 document date: 2023-11-13



[\[pdf\]](#) User Manual

XF 1600 KB Bedienungsanleitung 451RT021 bed kober ws dokuments manuals |||

XF 1600 KB Bedienungsanleitung BEWEGLICHER LAUTSPRECHER Gebrauchs- und Anschlusshandbuch BLUETOOTH CONNECTION MIC WIRELESS USB microSD INPUT TWS LED DISCO LIGHT 200W MAX DEUTSCH **XF 1600 KB** GEBRAUCHSHINWEISE Wenn Sie lngere Zeit mit hoher Lautstärke hren, kann dies Ihr Gehr schdigen. Dies is...

lang:de score:42 filesize: 786.98 K page_count: 9 document date: 2024-04-26



[\[pdf\]](#)

Trevi Party Lautsprecher XF 1600 KB cdr Christiane Ritzer Leopold Kober GmbH 451RT021kober ws dokuments manuals 451RT021 |||

18 WOOFER SUPER BASS NETZ- ODER AKKUBETRIEB Party-Lautsprecher XF 1600 KB 200W mit TWS-Funktion Bluetooth USB MP3 Trolley Mikrofon MP3-Player von USB-/Micro-SD-Speichern AUX-IN-Eingang/Eingnge: 2xMikrofone, 6,3-mm-Gitarrenbuchse Die TWS-Funktion verbindet drahtlos einen zweiten XF 1600...

lang:de score:38 filesize: 1.58 M page_count: 1 document date: 2024-04-26



[\[pdf\]](#) Catalog

Catalogo Compact Trevi it Sistema 2 Vie Bass Reflex Subwoofer 10 ad alta potenza Funzione Audio Wireless Maniglia e ruote posteriori per un facile trasporto Telecomando CATALOGO COMPACT TREVI size 12994665 trevi dms zidi |||

Lifestyle Technology 49 S I NCE 1 976 Il nuovo programma Trevi 2025 rappresenta la continuit nell i ... nology pag. 25 CATALOGO COMPACT 2024 X Fest 200W SUPER BASS WIRELESS MIC TWS GUITAR / 2 MIC **XF 1600 KB** ALTOPARLANTE AMPLIFICATO ALTA POTENZA FX 0X160000 EAN 8011000040646 18 WOOFERS SUPER B...

lang:it score:16 filesize: 12.39 M page_count: 60 document date: 2025-05-15



[\[pdf\]](#) Catalog

Catalogo Compact Trevi itSi connette con Smartphone per gestione dati su App FitCloudPro Notifica sul display di Chiamate lettura messaggi da social media Possibilità di CATALOGO COMPACT TREVIitrevi it dms zidi TREVI CATALOGO |||

Lifestyle Technology 49 S I NCE 1 976 Il nuovo programma Trevi 2025 rappresenta la continuit nell i ... nology pag. 25 CATALOGO COMPACT 2024 X Fest 200W SUPER BASS WIRELESS MIC TWS GUITAR / 2 MIC **XF 1600 KB** ALTOPARLANTE AMPLIFICATO ALTA POTENZA FX 0X160000 EAN 8011000040646 18 WOOFERS SUPER B...

lang:it score:15 filesize: 12.39 M page_count: 60 document date: 2025-05-15



[\[pdf\]](#) Catalog

Catalogo Italia Trevi it indesiderati quindi il circuito nelle cuffie emette suoni a una frequenza in grado di cancellarli DJ 12E90 ANC CUFFIA AUDIO WIRELESS CON RIDUZIONE DI CATALOGO GENERALE TREVI size 45764592 trevi dms zidi |||

Lifestyle Technology 48 S I NCE 1 976 Il nuovo programma Trevi 2024 rappresenta la continuit nell i ... 000 EAN 8011000026558 USB,SD / AUX IN / 2 INGRESSI MICROFONO 67 trevi.it catalogo prodotti 2024 **XF 1600 KB** ALTOPARLANTE AMPLIFICATO ALTA POTENZA 18 WOOFERS SUPER BASS 1 MIC WIRELESS AUDIO WIRELES...

lang:it score:15 filesize: 43.64 M page_count: 138 document date: 2024-09-03



[\[pdf\]](#) Catalog

Untitled Trevi it Smart Android TV OS 13 Tiramisù 10 GO GMS Google listed Slot SIM ANDROID AUTO e
APPLE CARPLAY app compatible TREVI COMPACT CATALOGUE trevi dms zidi |||

Lifestyle Technology 48 SINCE 1976 The new Trevi 2023 program represents
continuity in technolog ... pag. 25 CATALOGUE COMPACT 2024 Digital Audio 200W
SUPER BASS WIRELESS MIC TWS GUITAR / 2 MIC **XF 1600 KB** HIGH POWER
AMPLIFIED SPEAKER 18 WOOFERS SUPER BASS MIC WIRELESS AUDIO
WIRELESS USB / MIC...

lang:en score:14 filesize: 18.77 M page_count: 60 document date: 2025-01-13