Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Woodpeckers Furniture And Mattress CLOSET-448

Woodpeckers Furniture And Mattress 4-Door Wardrobe with 2 Drawers and Shelves (Model CLOSET-448) Instruction Manual

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Woodpeckers Furniture And Mattress 4-Door Wardrobe with 2 Drawers and Shelves, Model CLOSET-448. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- **Pinch Point Hazard:** Exercise caution during assembly and operation due to potential pinch points from drawer slides and door hinges.
- **Tipping Hazard:** This wardrobe must be securely anchored to a wall to prevent tipping, especially in households with children. Follow all instructions for securing the unit.
- **Lock Usage:** If your model includes a lock, ensure proper installation and safe usage of the key. Keep keys out of reach of children.
- **Assembly:** Assembly requires at least two adults. Do not attempt to assemble alone.
- **Weight Capacity:** Do not overload shelves or clothing rods. Refer to specifications for weight limits.

Parts List

Before beginning assembly, verify that all parts are present and undamaged. Refer to the included hardware and panel identification guide (not provided in this digital manual, typically found in packaging).

- Large Cabinet Panels (sides, top, bottom, back)
- Small Cabinet Panels (sides, top, bottom, back)
- Large Cabinet Doors (2)
- Small Cabinet Doors (2)

- Drawers (2) - front, back, sides, bottom panels
- Shelves (3 total: 1 for large cabinet, 2 for small cabinet)
- Clothing Rods (2)
- Drawer Slides (metal tracks)
- Door Hinges
- Handles (plastic, black finish)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-tip hardware
- Lock mechanism and keys (if applicable)

Setup and Assembly

Assembly of this wardrobe requires careful attention to detail and adherence to the step-by-step instructions provided in the physical packaging. Ensure you have adequate space and the necessary tools (e.g., screwdriver, hammer) before starting.

1. **Unpack and Identify:** Carefully unpack all components and lay them out. Identify each panel and hardware piece using the provided labels and diagrams.
2. **Assemble Base:** Begin by assembling the base frame of the wardrobe.
3. **Construct Cabinet Frames:** Attach side panels to the top and bottom panels for both the large and small cabinet sections. Ensure all connections are secure.
4. **Install Back Panels:** Slide or nail the back panels into place for each cabinet section.
5. **Assemble Drawers:** Construct the two drawers by attaching the front, back, and side panels, then inserting the bottom panel. Install the euro-glide metal slides onto the drawer sides and corresponding cabinet sections.
6. **Install Shelves and Rods:** Insert the fixed and removable shelves into their designated slots. Install the clothing rods in both cabinet sections.
7. **Attach Doors:** Secure the door hinges to the cabinet frames and then attach the four doors. Adjust hinges for proper alignment.
8. **Install Handles and Lock:** Attach the plastic bar handles to the doors and drawers. Install the lock mechanism on the large cabinet doors if included.
9. **Secure to Wall: CRITICAL STEP:** Use the provided anti-tip hardware to securely fasten the wardrobe to a wall stud. This prevents accidental tipping.



Image: Front view of the assembled Woodpeckers 4-Door Wardrobe in grey, showcasing the four doors and two lower drawers.



Image: Interior view of the Woodpeckers 4-Door Wardrobe, showing the large cabinet with a clothing rod and top shelf, and the smaller cabinet with a clothing rod, two removable shelves, and two lower drawers.

Operating Instructions

- **Doors:** Gently open and close the four cabinet doors using the black plastic handles. Avoid forcing them.
- **Drawers:** Pull the two lower drawers open and push them closed using the handles. The euro-glide metal tracks ensure smooth operation. Do not slam drawers.
- **Shelves:** The small cabinet features two removable shelves. To adjust or remove, carefully lift and slide them out of their supports. Ensure they are securely seated when repositioning.
- **Clothing Rods:** Hang garments on hangers from the clothing rods in both cabinet sections. Distribute weight evenly.
- **Lock (if applicable):** Use the key to lock and unlock the large cabinet doors for added security. Ensure the doors are fully closed before locking.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary to maintain stability.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone lubricant can be applied to the metal slides.
- **Door Alignment:** If doors become misaligned, adjust the hinges as needed.

Troubleshooting

Problem	Possible Cause	Solution
Wardrobe feels wobbly or unstable.	Loose fasteners; not secured to wall.	Ensure all assembly screws are tightened. Verify the anti-tip hardware is correctly installed and anchored to a wall stud.
Drawers do not slide smoothly.	Misaligned slides; debris in tracks; overloaded drawer.	Check that drawer slides are correctly aligned and free of obstructions. Do not overload drawers. Apply silicone lubricant if necessary.
Doors do not close properly or are misaligned.	Loose hinges; improper hinge adjustment.	Tighten hinge screws. Adjust hinges to align doors. Refer to hinge adjustment instructions (if provided with hardware).
Damage to material during assembly.	Excessive force; incorrect tool usage.	Always use appropriate tools and apply gentle, controlled force. If damage occurs, contact customer support for replacement parts.

Specifications



Image: Diagram showing the overall dimensions of the Woodpeckers 4-Door Wardrobe: 47 inches wide, 19 inches deep, and 71.25 inches high.

- **Model Name:** 448 Closet (CLOSET-448)
- **Brand:** Woodpeckers Furniture And Mattress
- **Overall Dimensions:** 19"D x 48"W x 72"H (48" W x 19" D x 72" H)
- **Drawer Dimensions:** 15"D x 20.5"W x 5"H
- **Shelf Dimensions:** 16"D x 22.75"W

- **Color:** Grey
- **Material:** Engineered Wood
- **Finish Type:** Painted
- **Item Weight:** 183 Pounds
- **Number of Doors:** 4
- **Number of Drawers:** 2
- **Number of Shelves:** 3 (1 fixed, 2 removable)
- **Special Feature:** Lockable (large cabinet)
- **Mounting Type:** Floor Mount (requires wall anchoring)
- **Assembly Required:** Yes

Warranty and Support

For any questions regarding assembly, missing parts, or product issues, please contact Woodpeckers Furniture And Mattress customer support. While specific warranty details are not provided in this manual, the manufacturer offers a return policy for unsatisfied purchases. Please refer to your purchase documentation or the retailer's website for the most current return and warranty information.
If for whatever reason you are not completely satisfied with your purchase, please notify us immediately, so we can issue your return label. However, we do not offer "call tag service" where a carrier can pick up at your residence.

© 2026 Woodpeckers Furniture And Mattress. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CY5RM7DB

More documents and user manuals: **https://manuals.plus/**