

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SPYRA](#) /

› [SPYRA Electric Water Gun Blaster SpyraGO Instruction Manual](#)

SPYRA SPGO1R

SPYRA Electric Water Gun Blaster

MODEL: SPYRAGO (SPGO1R)

Your Guide to Next-Level Water Battles

Introduction

Welcome to the world of SPYRA! This manual provides essential information for the safe and effective use of your new SPYRA Electric Water Gun Blaster. Please read through these instructions carefully before first use to ensure optimal performance and enjoyment.

1. Setup

1.1 Unboxing

Carefully remove all components from the packaging. Ensure the following items are present:

- SPYRA Electric Water Gun Blaster (SpyraGO)
- Integrated Battery (pre-installed)
- USB-C Charging Cable
- Small Screwdriver (for battery compartment access, if needed)

SPYRA



Image: The SPYRA Electric Water Gun Blaster packaging box.

1.2 Charging the Blaster

Your SPYRA blaster comes with an integrated Lithium Ion battery. Before first use, fully charge the blaster using the provided USB-C charging cable.

1. Locate the USB-C charging port on the blaster.
2. Connect the USB-C cable to the blaster and the other end to a compatible USB power source (e.g., wall adapter, computer USB port).
3. The LED display will indicate charging status. A full charge typically takes a few hours.

1.3 Filling the Water Tank

The SPYRAGO features a convenient Tank Slider Reload system for quick refills.

1. Locate the tank slider on the top of the blaster.
2. Slide the tank cover open to reveal the water reservoir opening.
3. Fill the tank with clean water from a tap, bottle, or a SpyraBase (sold separately). The clear tank windows allow you to monitor the water level.
4. Once filled, slide the tank cover back into place until it clicks securely.



Image: The SPYRA Electric Water Gun Blaster being refilled with water using the tank slider.



Image: A graphic demonstrating the Tank Slider Reload system for quick and easy water refills.

2. Operating the Blaster

2.1 Powering On and Firing

The SPYRAGO is designed for immediate action. Simply pick it up and prepare to fire.

1. Ensure the blaster is charged and filled with water.
2. Aim the blaster at your target.
3. Pull the trigger to activate the Single Shot Technology. Each pull of the trigger will unleash a powerful, individual water blast.

4. The blaster is capable of blasting water up to 26 feet.



Image: A user holding and aiming the SPYRA Electric Water Gun Blaster, ready for action.



Image: A user firing the SPYRA Electric Water Gun Blaster, demonstrating its powerful water stream.




Image: A graphic explaining the precision and power of the Single Shot Technology.

2.2 LED Display

The integrated LED display provides real-time information about your blaster's status.

- **Water Level Indicator:** Shows how much water remains in the tank.
- **Battery Level Indicator:** Displays the current battery charge.



Image: A graphic highlighting the LED display that shows blast count and battery levels.

2.3 Official Product Video

Video: An official product video demonstrating the SPYRA Electric Water Blaster in action, including filling and firing.

3. Maintenance

3.1 Cleaning

To ensure the longevity of your SPYRA blaster, follow these cleaning guidelines:

- After each use, empty any remaining water from the tank.
- Rinse the tank with clean water to remove any debris or residue.
- Wipe down the exterior of the blaster with a damp cloth. Do not submerge the entire blaster in water.
- Ensure the charging port is dry before charging.

3.2 Storage

When not in use, store your SPYRA blaster in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the tank is empty and the blaster is clean before storing.

4. Troubleshooting

If you encounter any issues with your SPYRA Electric Water Gun Blaster, please refer to the following common solutions:

| Problem | Possible Cause | Solution |
|------------------------------------|--|--|
| Blaster not firing | Low battery or empty water tank. | Charge the battery fully. Refill the water tank. |
| Weak water blast | Low water level or partial blockage. | Ensure the tank is full. Check the nozzle for any obstructions and clear if necessary. |
| Charging indicator not lighting up | Cable not properly connected or faulty power source. | Ensure USB-C cable is securely connected. Try a different USB power source. |

5. Specifications

| Feature | Detail |
|------------------------------|----------------------------------|
| Product Dimensions | 28.5 x 3.9 x 9.1 inches |
| Item Weight | 3.96 pounds |
| Item Model Number | SPGO1R |
| Manufacturer Recommended Age | 14 years and up |
| Batteries | 1 Lithium Ion battery (included) |
| Manufacturer | SPYRA |

6. Warranty and Support

For warranty information, product registration, or further support, please visit the official SPYRA website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

[Visit the Official SPYRA Store on Amazon](#)
