

[Manuals.plus](#) /

› [TEMOLA](#) /

› TEMOLA TS10 Handheld Cordless Vacuum Cleaner User Manual

TEMOLA TS10

TEMOLA TS10 Handheld Cordless Vacuum Cleaner User Manual

Model: TS10 | Brand: TEMOLA

1. INTRODUCTION

Thank you for choosing the TEMOLA TS10 Handheld Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new device. Please read it thoroughly before first use and retain it for future reference.

The TEMOLA TS10 is designed for versatile cleaning, offering powerful suction in a lightweight and portable form factor. Its brushless motor ensures strong performance with reduced noise, making it ideal for quick cleanups in various environments, including your car, home, office, or pet areas.



Figure 1: TEMOLA TS10 Handheld Cordless Vacuum Cleaner

2. WHAT'S IN THE BOX

Upon unpacking, please ensure all items listed below are present and in good condition:

- 1 x TEMOLA TS10 Cordless Handheld Vacuum
- 1 x Extra HEPA Filter
- 1 x Crevice Tool
- 1 x Dust Brush

- 1 x Drawstring Bag
- 1 x User Manual (this document)
- 1 x Charging Cable (Type-C)
- 1 x Filter Cleaning Brush

PACKING INCLUDES

- 1 TS10BS Cordless Handheld Vacuum
- 2 Extra HEPA Filter
- 3 Crevice Tool
- 4 Dust Brush
- 5 Drawstring Bag
- 6 User Manual
- 7 Charging Cable
- 8 Filter Cleaning Brush



Figure 2: All included components of the TEMOLA TS10 package.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the vacuum cleaner. Use the provided Type-C charging cable with a 5V/1A, 5V/2A, or 5V/3A charger. Other chargers may not work correctly.

- Connect the Type-C cable to the charging port on the vacuum.
- Plug the other end into a compatible USB power adapter.
- The indicator light will show charging status (e.g., red for charging, off for fully charged).



Figure 3: Connect the Type-C cable to charge the vacuum cleaner.

3.2 Attaching Accessories

Select the appropriate attachment for your cleaning task:

- **Crevice Tool:** Ideal for reaching tight spaces, corners, and gaps in car seats or furniture.
- **Dust Brush:** Suitable for cleaning delicate surfaces, car parts, keyboards, and pet hair.

To attach, simply push the desired tool firmly onto the vacuum's nozzle until it clicks into place.




Figure 4: The vacuum cleaner shown with its crevice tool and dust brush attachments.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

To turn on the vacuum, slide the power switch to the 'ON' position. To turn it off, slide the switch to 'OFF'.

4.2 Cleaning with the Vacuum

The TEMOLA TS10 features an upgraded high-speed brushless motor, providing powerful 12000Pa suction for effective removal of trash and dust. Its lightweight design (0.8 lbs) and ergonomic handle ensure comfortable use for extended periods.

POWERFUL SUCTION



Low Noise



80000 R/Min



120 Watt Motor

12000PA



Figure 5: The TEMOLA TS10 in action, demonstrating its powerful suction on a carpeted surface.

Use the appropriate attachment for the surface you are cleaning. The compact size allows for easy maneuverability in small areas like car interiors, office desktops, or between sofa cushions.

CORDLESS

LIGHTWEIGHT DESIGN



Ergonomic Handle



Portable **0.8**lbs



Figure 6: The lightweight design and ergonomic handle of the TEMOLA TS10 for comfortable use.

4.3 Anti-Clogging Protection

The vacuum is equipped with an anti-clogging feature. If the high-efficiency air filter becomes clogged and air cannot pass through, the appliance will automatically stop running to protect the motor and extend its lifespan. It will resume operation once the filter is cleaned and dry.

ANTI-CLOGGING PROTECTION

When the HEPA gets dirty, the appliance will aut- stops working to protect the motor.



It will work again until HEPA is cleaned and dry.

Figure 7: Illustration of the anti-clogging protection, showing the filter and cleaning process.

4.4 Product Demonstration Video

Watch this video for a demonstration of the TEMOLA Handheld Car Vacuum Cleaner:

Your browser does not support the video tag. Please update your browser to view this content.

Video 1: A demonstration of the TEMOLA Handheld Car Vacuum Cleaner by Manso US.

5. MAINTENANCE

5.1 Emptying the Dustbin

Regularly empty the dustbin to maintain optimal suction power. The dustbin is transparent, allowing you to monitor its fill level.

- Ensure the vacuum is turned off.
- Locate the release button or latch for the dustbin.
- Detach the dustbin and empty its contents into a waste receptacle.

5.2 Cleaning the Filter

The TEMOLA TS10 features a washable and reusable high-efficiency steel HEPA filter. Regular cleaning (every 2-3 months or as needed) is crucial for maintaining performance.

- Remove the dustbin.
- Carefully remove the HEPA filter from the dustbin.
- Use the provided small cleaning brush to remove loose debris from the filter.
- Rinse the filter under running water until clean.
- Allow the filter to air dry completely before reinserting it into the dustbin. Ensure it is fully dry to prevent damage to the motor.

WASHABLE REUSABLE STAINLESS STEEL FILTE



Figure 8: The washable and reusable HEPA filter being cleaned under water.

6. TROUBLESHOOTING

If you encounter issues with your TEMOLA TS10, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the vacuum fully using the provided Type-C cable and a compatible charger.

Problem	Possible Cause	Solution
Low suction power.	Dustbin is full or filter is clogged.	Empty the dustbin and clean the HEPA filter thoroughly. Ensure the filter is completely dry before reinserting.
Vacuum stops unexpectedly.	Anti-clogging protection activated due to a clogged filter.	Clean the HEPA filter as described in the Maintenance section. The vacuum will resume once the filter is clean and dry.
Charging indicator not working.	Incorrect charger used or cable is faulty.	Ensure you are using a 5V/1A, 5V/2A, or 5V/3A charger. Try a different Type-C cable if available.

7. SPECIFICATIONS

Feature	Detail
Brand	TEMOLA
Model Name	TS10BS Handheld Vacuum Cordless
Special Feature	Portable, Lightweight, Cordless, Compact
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	350 Grams
Form Factor	Handheld
Color	Black Cordless
Product Dimensions	11"L x 4"W x 4"H
Battery Description	Lithium-Ion (1 required, included)
Noise Level	75 Decibels
Connectivity Technology	USB
Item Weight	1 pounds
UPC	797417731534

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact TEMOLA customer service directly. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CYBXMR8R>

More documents and user manuals: **<https://manuals.plus/>**