

[Manuals.plus](#) /

> [OLEVS](#) /

> OLEVS Mens Automatic Watches Self-Winding Starry Sky Diamond Skeleton Luxury Wrist Watch Waterproof Luminous User Manual

OLEVS XBC-OS-G6690GB-BL

OLEVS Mens Automatic Watch User Manual

Brand: OLEVS

Model: XBC-OS-G6690GB-BL

INTRODUCTION

This manual provides comprehensive instructions for the OLEVS Mens Automatic Watch, Model XBC-OS-G6690GB-BL. This self-winding mechanical watch features a unique starry sky luminous dial, diamond and Roman numeral markers, and multi-functional subdials including 24-hour/moon phase display and year/month windows. Crafted with 316L stainless steel, it offers durability and comfort. Please read this manual carefully to ensure proper use and longevity of your timepiece.



Image: The OLEVS Mens Automatic Watch, showcasing its blue starry sky dial, stainless steel band, and the included band adjustment tool.

SETUP

Initial Winding

Your OLEVS automatic watch is powered by mechanical movement and does not require batteries. For the first use, or if the watch has stopped due to inactivity, manual winding is necessary to initiate the movement.

1. Locate the crown on the right side of the watch case.
2. Ensure the crown is in its fully pushed-in position (position 0).
3. Turn the crown clockwise approximately 30-40 turns. This will build up the power reserve.
4. Once wound, the watch should begin to operate. Subsequent winding will occur automatically through wrist

movement.

Setting Time and Date

The watch features multiple functions including time, date, moon phase, and year/month display. Refer to the diagram below for crown positions and button functions.



Image: A detailed diagram illustrating the crown positions and the functions of the watch's various adjustment points, including time, date, and year/month settings.

- **Adjusting Time:** Pull the crown out to position 2. Turn the crown to set the hour and minute hands. Push the crown back in to position 0 when done.
- **Adjusting Date:** Pull the crown out to position 1. Turn the crown to adjust the date. Push the crown back in to position 0 when done.
- **Adjusting Year/Month:** Use the concealed knob on the left side of the watch case (labeled ① in diagrams) to adjust the year. The month display is typically linked to the date mechanism or adjusted via a separate pusher.
- **Adjusting Moon Phase:** This is often adjusted via a pusher or by rotating the crown in a specific position. Refer to the detailed diagram for precise instructions.

Band Adjustment

The watch comes with a free adjustment tool for the stainless steel band. Use this tool to remove or add links to achieve a comfortable fit. If unsure, it is recommended to seek professional assistance for band adjustments.

OPERATING YOUR WATCH

Automatic Winding Mechanism

Your OLEVS watch is equipped with an automatic self-winding movement. This means the watch is powered by the natural motion of your wrist. As you wear the watch, an oscillating weight inside the movement rotates, winding the mainspring and storing energy. If worn regularly (8-10 hours a day), the watch should maintain its power reserve without manual winding.

Luminous Display

The watch features luminous hands and markers, allowing for easy time reading in low-light conditions. The luminous material charges by absorbing light (natural or artificial) and then emits a glow in the dark.



Image: A close-up view of the watch face demonstrating the high-definition luminous feature, with hands and markers glowing brightly in the dark.

Water Resistance

This watch is rated for 30M (3ATM) water resistance. This means it is suitable for daily water splashing, hand washing, and sweat. It is **not** suitable for showering, bathing, swimming, diving, or any activities involving prolonged water immersion or high-pressure water exposure.



Image: An infographic explaining the 30M water resistance rating, showing the watch is safe for hand washing, rain, and sweat, but not for submersion.

Multi-functional Dial

The watch features a complex dial with several subdials and indicators:

- **Moon Phase Display:** Indicates the current phase of the moon.
- **Date Display:** Shows the current day of the month.
- **Year/Month Window:** Displays the current year and month.
- **Skeleton Movement Window:** A visible part of the mechanical movement, showcasing the intricate gears and balance wheel.

MAINTENANCE

Cleaning Your Watch

To maintain the appearance of your watch, regularly wipe the case and band with a soft, dry cloth. For stainless steel bands, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals, solvents, or abrasive cleaners.

Water Resistance Precautions

Always ensure the crown is fully pushed in before any contact with water. Do not operate the crown or pushers when the watch is wet. Avoid exposing the watch to extreme temperature changes, as this can affect the water resistance seals.

Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight and strong magnetic fields. A watch box or a soft pouch is ideal to protect it from dust and scratches. If storing for an extended period, manually wind the watch periodically to keep the movement lubricated.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or is running slow.	Insufficient power reserve.	Manually wind the watch by turning the crown clockwise 30-40 times. Wear the watch regularly to allow the automatic winding mechanism to function.
Date/Time is incorrect.	Needs adjustment.	Refer to the "Setting Time and Date" section for instructions on adjusting the crown and pushers.
Condensation under the crystal.	Water ingress or extreme temperature change.	Stop using the watch immediately. Seek professional watch repair. Avoid further water exposure.
Band is too loose/tight.	Incorrect sizing.	Use the included adjustment tool to add or remove links, or consult a jeweler.

If you encounter problems not listed here, or if the suggested solutions do not resolve the issue, please contact OLEVS customer support or the seller for assistance.

SPECIFICATIONS

- **Model Number:** XBC-OS-G6690GB-BL
- **Movement:** Automatic Mechanical
- **Case Material:** Stainless Steel (implied from band material and product images)
- **Band Material:** 316L Stainless Steel
- **Dial Features:** Starry Sky Luminous Dial, Diamond & Roman Scale, 24-hour/Moon Phase Display, Year/Month Window, Skeleton Movement
- **Water Resistance:** 30M (3ATM)
- **Package Dimensions:** 4.49 x 4.37 x 2.99 inches
- **Item Weight:** 14.07 ounces
- **First Available Date:** March 18, 2024

WARRANTY AND SUPPORT

OLEVS watches are designed for durability and performance. If you encounter any issues with your watch, please

refer to the troubleshooting section first. For further assistance or warranty claims, please contact the seller directly through the Amazon platform. The package includes a user guide and a free adjustment tool. Keep your purchase receipt as proof of purchase for any warranty-related inquiries.

Contact Information: For support, please reach out to the seller "xingbaochengkeji" via Amazon's messaging system.



© 2024 OLEVS. All rights reserved. This manual is for informational purposes only.