

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [OLEVS](#) /

› [OLEVS G6690 Automatic Self-Winding Watch User Manual](#)

OLEVS G6690

OLEVS G6690 Automatic Self-Winding Watch User Manual

Model: G6690

INTRODUCTION

Welcome and thank you for choosing the OLEVS G6690 Automatic Self-Winding Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

PRODUCT OVERVIEW

The OLEVS G6690 is a men's automatic mechanical watch designed with a distinctive starry sky luminous dial, accented with diamonds and Roman numeral markers. It features multiple sub-dials for 24-hour/moon phase display and year/month indication. The watch is equipped with a self-winding movement and a comfortable leather strap.



Image: Front view of the OLEVS G6690 watch, showcasing its blue starry sky dial, Roman numerals, and visible automatic movement.



Image: The OLEVS G6690 watch worn on a wrist, highlighting its elegant design and fit.

KEY FEATURES

- **Automatic Mechanical Movement:** Self-winding, requiring no batteries.
- **Multi-functional Dial:** Features a starry sky design, diamond and Roman numeral markers, 24-hour/moon phase display, and year/month windows.
- **Luminous Hands:** Provides clear readability in low-light conditions.
- **Water Resistance:** Rated at 30 meters (3ATM), suitable for daily water splashes, hand washing, and sweat. Not suitable for diving or showering.
- **Leather Strap:** Soft, breathable, and durable for comfortable wear.



Image: A collage illustrating key features: 30M water resistance, high stiffness glass, fully automatic movement, and luminous dial.

INITIAL SETUP

Your OLEVS G6690 watch is an automatic mechanical timepiece. For its first use or after a period of inactivity, manual winding is required to initiate the movement and build up the power reserve.

1. **Manual Winding:** Gently turn the crown clockwise 30-40 times. This action will start the watch and provide an initial power reserve.
2. **Automatic Winding:** Once started, the watch will continue to wind itself through the natural motion of your wrist while worn. For consistent operation, it is recommended to wear the watch for at least 8 hours a day.

Your browser does not support the video tag.

Video: An official product video demonstrating the OLEVS G6690 watch, including its design and features.

OPERATING INSTRUCTIONS

The OLEVS G6690 features multiple functions controlled by the crown and a concealed button. Refer to the diagram below for reference.

PRODUCT PARAMETERS



Product Size

Case diameter 42MM

Case thickness 13MM

Chain width Steel22/Skin22MM

Chain length Steel20/Skin21CM

Brand model number: OLEVS/6690

Mirror: High hardness coated glass mirror

Watchband: Steel / Leather

Movement: Fully automatic

Waterproof: 30M

Watch weight: Steel 148/Skin 76g

* Tips: All sizes are manually measured, there is a reasonable error, please prevail in kind

Image: Diagram illustrating the watch's crown and concealed button functions for setting time, date, year/month, and moon phase.

Setting the Time

1. Pull the crown out to the furthest position (Position 2).
2. Turn the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Push the crown back in to its original position (Position 0) to secure the time setting.

Setting the Date

1. Pull the crown out to the first position (Position 1).
2. Turn the crown to adjust the date display. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
3. Push the crown back in to its original position (Position 0).

Setting Year/Month and Moon Phase

- **Year/Month:** Use a small, pointed tool (such as the provided adjustment tool or a toothpick) to gently press the concealed knob on the left side of the watch case. Pressing this button will advance the year and month displays.
- **Moon Phase:** The moon phase display is typically adjusted in conjunction with the date or time setting, or via a separate pusher. Refer to the specific mechanism on your watch for precise adjustment, often by repeatedly pressing the concealed button until the desired moon phase is shown.

CARE AND MAINTENANCE

- **Water Resistance:** While the watch is 30M water resistant, avoid exposing it to hot water, steam, or prolonged submersion. Do not operate the crown or buttons when the watch is wet or underwater.
- **Cleaning:** Wipe the watch case and crystal with a soft, dry, lint-free cloth. For leather straps, avoid excessive moisture and harsh chemicals, which can cause damage or discoloration.
- **Storage:** When not in use for extended periods, store the watch in its original box or a watch winder to maintain its power reserve and protect it from dust and scratches.
- **Avoid Magnetic Fields:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, computers, mobile phones) as these can affect the accuracy of the mechanical movement.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures, both hot and cold, as this can impact the movement's performance and the integrity of the materials.

TROUBLESHOOTING

Watch Stops or Runs Inaccurately

This is common for automatic watches if they are not worn regularly or have insufficient power reserve. Manually wind the watch by turning the crown 30-40 times. Ensure you wear the watch for at least 8 hours a day for consistent self-winding. If the issue persists, it may require professional inspection.

Date/Time Not Changing Correctly

Ensure the crown is fully pushed in after setting. Re-check the operating instructions for proper adjustment of each function. Avoid setting the date during the watch's automatic date change period (typically between 9 PM and 3 AM).

Condensation Inside the Watch

This indicates a potential breach in water resistance. Avoid further contact with water and seek professional service immediately to prevent damage to the movement.

SPECIFICATIONS (MODEL G6690)

Below are the general specifications for the OLEVS G6690 watch. Please note that minor variations may occur.



Moon phase
Multi-function



Dates
Multi-function



Year/Month
Multi-function



▼ **Side show**

Adjustment week

Adjustment time

Clockwise rotation for winding

Adjustment Date

Concealed knob on the left side:

① Dark Button Adjustment Year

Image: A detailed graphic outlining the product parameters including case diameter, thickness, strap material, and movement type.

Feature	Detail
Brand Model Number	XBC-OS-G6690PL-BL
Case Diameter	42mm
Case Thickness	13mm
Watchband Material	Leather
Movement Type	Fully Automatic Mechanical
Water Resistance	30M
Mirror Material	High hardness coated glass mirror

WARRANTY AND CUSTOMER SUPPORT

OLEVS watches are designed for reliability and come with a user guide to assist you. If you encounter any issues or have questions regarding your watch, please contact OLEVS customer service through the platform where you purchased the product. A professional after-sales team is available to provide

assistance.

For specific warranty details and terms, please refer to the documentation included with your purchase.

Keep your proof of purchase for warranty claims.