

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AMACOOOL](#) /

› [AMACOOOL Portable Handheld Fan BP923 User Manual](#)

AMACOOOL BP923

AMACOOOL Portable Handheld Fan

MODEL: BP923 USER MANUAL

Brand: AMACOOOL

1. Introduction

Thank you for choosing the AMACOOOL Portable Handheld Fan, Model BP923. This fan is designed to provide powerful and versatile personal cooling with its dual motor, 12-blade design, and 4-speed settings. Its foldable and compact design makes it ideal for various uses, including handheld, desk, and neck fan applications. Please read this manual carefully before use to ensure proper operation and maintenance.

2. Product Features

- **Dual Motor & 12 Blades:** Engineered for enhanced airflow, delivering a strong and wide cooling breeze.
- **4 Adjustable Speeds:** Easily switch between four power levels to suit your cooling needs, with a maximum speed of 7000 RPM.
- **3-in-1 Versatile Design:** Functions as a handheld fan, a stable desk fan with an upright stand, and a hands-free neck fan using the included lanyard.
- **Rechargeable Battery:** Equipped with a 2000mAh lithium polymer battery for extended use.
- **USB-C Charging:** Convenient and fast charging via a USB-C port.
- **Compact & Portable:** Lightweight at 7.4 ounces and foldable for easy carrying and storage.
- **LED Indicators:** Four LED lights display current speed setting and battery power status.
- **Durable Construction:** Features non-slip pads for stability and a polished surface for comfortable handling.

3. What's in the Box

The package includes the following items:

- AMACOOOL Portable Handheld Fan (Model BP923)
- USB-A to USB-C Charging Cable
- Neck Lanyard
- User Manual



Image: Contents of the AMACOOOL Portable Handheld Fan package.

4. Setup

4.1 Initial Charging

Before first use, fully charge the fan. Connect the provided USB-A to USB-C charging cable to the fan's USB-C port and a compatible USB power source (e.g., wall adapter, computer, power bank). The LED indicators will show charging progress and turn solid when fully charged.

4.2 Attaching the Lanyard

To use the fan as a neck fan, attach the included lanyard to the designated loop on the fan's handle. Ensure it is securely fastened.

4.3 Using as a Desk Fan

The fan features a foldable handle that doubles as an upright stand. Fold the handle down completely until it locks into position, allowing the fan to stand stably on a flat surface.

Details Make the Difference



Image: Key features of the fan, including the foldable stand and lanyard attachment point.

5. Operating Instructions

5.1 Power On/Off and Speed Adjustment

The fan is controlled by a single touch button located on the front of the handle.

1. **To Turn On:** Press the power button once. The fan will start at Speed 1.
2. **To Adjust Speed:** Press the power button repeatedly to cycle through Speed 1, Speed 2, Speed 3, and Speed 4.
3. **To Turn Off:** After Speed 4, press the power button one more time to turn the fan off.

5.2 LED Indicators

The four LED lights above the power button indicate the current speed setting and battery level:

- 1 LED: Speed 1 / Low Battery
- 2 LEDs: Speed 2 / Medium Battery
- 3 LEDs: Speed 3 / High Battery
- 4 LEDs: Speed 4 / Full Battery

One-Step To Control 4 Powerful Speed

Max 7000RPM



Beat Hot Flash Way Faster



Still Feels Fresh & Comfort



Image: Fan in use, highlighting the 4-speed control.

5.3 Versatile Usage Modes

- **Handheld:** Hold the fan by its ergonomic handle for direct personal cooling.
- **Desk:** Fold the handle to create a stable base and place it on any flat surface.
- **Neck:** Attach the lanyard and wear the fan around your neck for hands-free cooling.

Versatile Fan

Not Only Handheld, One Fan For All



Image: Demonstrating the fan's versatility as a handheld, desk, and neck fan.

6. Charging Instructions

To charge the fan, locate the USB-C port on the side of the handle. Plug the small end of the provided USB-C cable into the fan's port and the larger USB-A end into a power source. The LED indicators will flash during charging and remain solid when the battery is fully charged. A full charge typically takes approximately 2-3 hours.

The USB charging port is covered by a rubber flap for sweatproof and dustproof protection. Ensure this cover is properly sealed when not charging.

More Surprising Features




Image: Detailed view of the fan's charging port and controls.

7. Maintenance

7.1 Cleaning

To clean the fan, ensure it is turned off and unplugged. Use a soft, dry cloth to wipe the exterior. For dust accumulation on the fan blades, use a soft brush or compressed air. Do not immerse the fan in water or use harsh chemicals.

7.2 Storage

When not in use for an extended period, store the fan in a cool, dry place. It is recommended to charge the battery at least once every three months to maintain battery health.

8. Troubleshooting

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the provided USB-C cable.
Fan runs weakly.	Low battery or obstruction.	Charge the fan. Check for any obstructions in the fan blades and remove them carefully.
Fan makes unusual noise.	Obstruction in blades or internal issue.	Turn off the fan immediately. Check for and remove any obstructions. If the noise persists, contact customer support.
LED indicators not working.	Internal malfunction.	Ensure the fan is charged. If the issue continues, contact customer support.

9. Specifications

Feature	Detail
Model Name	BP923

Feature	Detail
Brand	AMACOOOL
Color	Pink
Power Source	Battery Powered
Battery Type	1 Lithium Polymer battery (included)
Battery Capacity	2000mAh
Product Dimensions	1.81"D x 7.87"W x 3.34"H
Item Weight	7.4 ounces
Number of Power Levels	4
Max Speed	7000 RPM
Control Method	Touch
Charging Port	USB-C
Special Features	Dual motor, 12 Blades, Foldable, 3-in-1 (Handheld/Desk/Neck)

10. Safety Information

- Do not insert fingers or any objects into the fan grille when the fan is operating.
- Keep the fan away from water and moisture. Do not use in wet environments.
- Do not disassemble or attempt to repair the fan yourself. Contact qualified personnel for service.
- Keep out of reach of children and pets.
- Use only the provided charging cable or a certified USB-C cable for charging.
- Avoid exposing the fan to extreme temperatures or direct sunlight for prolonged periods.
- Dispose of the battery according to local regulations.

11. Product Videos

Your browser does not support the video tag.

Video: An overview of the AMACOOOL Portable Handheld Fan, demonstrating its features and various uses.

12. Warranty and Support

AMACOOOL products come with a standard manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official AMACOOOL website. Please retain your proof of purchase for warranty claims.

