

[Manuals.plus](#) /

› [Simplicity Vacuums](#) /

› Simplicity Sport S100.6 Canister Vacuum Cleaner User Manual

Simplicity Vacuums S100.6

Simplicity Sport S100.6 Canister Vacuum Cleaner

Model: S100.6 | Brand: Simplicity Vacuums

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

1. Read all instructions before using this vacuum cleaner.
2. To reduce the risk of fire, electric shock, or injury, do not leave the appliance unattended when plugged in.
3. Do not use outdoors or on wet surfaces.
4. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
5. Use only as described in this manual. Use only manufacturer's recommended attachments.
6. Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
7. Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
8. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
9. Do not handle plug or appliance with wet hands.
10. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
11. Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
12. Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
13. Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
14. Do not use without dust bag and/or filters in place.
15. Turn off all controls before unplugging.
16. Use extra care when cleaning on stairs.
17. Store your appliance indoors in a cool, dry area.

WHAT'S INCLUDED

Your Simplicity Sport S100.6 vacuum cleaner comes with the following components:

What's Included?



- | | |
|--------------------------------|----------------------------------|
| 1 Sport Canister Vacuum | 6 Upholstery Tool |
| 2 Dual Wands | 7 Dusting Brush |
| 3 Floor Tool | 8 Shoulder Strap |
| 4 Hose | 9 One SS-6 Disposable Bag |
| 5 Crevice Tool | 10 Tool Storage Bag |

All components included with the Simplicity Sport S100.6 vacuum cleaner.

- Sport Canister Vacuum with 25ft cord
- Two Extension Wands
- Adjustable Floor Tool
- Hose
- Upholstery Tool
- Dusting Brush
- Crevice Tool
- Shoulder Strap
- One SS-6 Disposable Bag
- Storage Bag for Vacuum and Tools

SETUP

1. **Unpack Components:** Carefully remove all items from the packaging. Ensure all listed components are present.
2. **Insert Disposable Bag:** Open the canister lid and insert one SS-6 disposable bag into the designated compartment. Ensure it is securely seated to prevent dust leakage.
3. **Attach Hose:** Connect the flexible hose to the suction port on the front of the canister vacuum. Twist until it clicks into place.
4. **Assemble Wands and Floor Tool:** For floor cleaning, connect the two extension wands together, then attach them to the end of the hose. Finally, attach the adjustable floor tool to the end of the wands. For handheld use, attach desired tools directly to the hose or a single wand.
5. **Attach Shoulder Strap (Optional):** If desired, attach the shoulder strap to the designated loops on the canister for portable use.

Key FEATURES



Portable



Versatile



Simple Storage



Canister weight = 4.5 lbs.

The Simplicity Sport S100.6 is compact and lightweight for easy maneuverability.

OPERATING INSTRUCTIONS

1. **Power Connection:** Plug the 25-foot power cord into a suitable electrical outlet. The vacuum operates on corded electric power.
2. **Power On/Off:** Press the power button located on the canister to turn the vacuum on or off.
3. **Adjust Suction:** The Simplicity Sport allows you to adjust suction power. This feature is useful for various cleaning tasks, from delicate curtains to heavily soiled floors.
4. **Cleaning Surfaces:**
 - **Hard Floors and Rugs:** Use the adjustable floor tool. It can be switched between settings suitable for hard floors and rugs.
 - **Upholstery and Furniture:** Attach the upholstery tool or dusting brush directly to the hose or a single wand for cleaning furniture, car interiors, and delicate surfaces.
 - **Tight Spaces:** Use the crevice tool for reaching narrow gaps, corners, and edges.
 - **High Reach Cleaning:** Utilize the two extension wands to achieve an 8-foot cleaning reach, ideal for ceilings, high shelves, and other elevated areas.
5. **Blower Function:** The vacuum also includes a blower function for clearing debris from outdoor areas or hard-to-reach spots. To use, remove the dust bag and attach the hose to the exhaust port.
6. **Portable Use:** For maximum portability, use the included shoulder strap to carry the vacuum while cleaning stairs, vehicles, or RVs.



Lightweight design makes cleaning effortless.



Extended reach for high-up cleaning.



Ideal for cleaning vehicles and RVs.



Floor tool adjusts for rugs and bare floors.

Product Overview Video

Your browser does not support the video tag.

This video provides a visual overview of the Simplicity Sport Small Canister Vacuum's features and uses.

MAINTENANCE

1. **Replacing the Dust Bag:** The Simplicity Sport S100.6 uses SS-6 vacuum replacement bags. When the bag is full or suction decreases, turn off and unplug the vacuum. Open the canister lid, remove the full bag, and dispose of it. Insert a new SS-6 bag, ensuring it is properly sealed.
2. **Cleaning the Filter:** The vacuum is equipped with an Activated Charcoal Electrostatic Filter. Check the filter regularly for dirt and debris. Tap it gently to dislodge loose particles. Replace the filter periodically according to usage or if it appears heavily soiled.
3. **Cleaning Attachments:** Wipe down the hose, wands, and tools with a damp cloth as needed to remove dust and grime. Ensure they are dry before reattaching.
4. **Cord Care:** After use, wrap the power cord neatly around the integrated cord wrap on the canister to prevent damage and ensure easy storage.

Integrated cord wrap for tidy storage.



Store tools in the included bag.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on	Not plugged in; Power outlet fault; Power button not pressed	Check plug connection; Test outlet with another appliance; Press power button firmly.
Low suction	Full dust bag; Clogged hose/filter; Improperly seated bag	Replace dust bag; Check hose and filter for blockages and clean; Ensure dust bag is correctly installed.
Hose or attachments detach easily	Improper connection; Wear and tear on connectors	Ensure hose and attachments are twisted or pushed firmly into place until secure. If connections are worn, contact customer support for replacement parts.
Unusual noise	Obstruction in hose/nozzle; Motor issue	Turn off and unplug. Check for and remove any obstructions. If noise persists, discontinue use and contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Simplicity Vacuums
Model Name	Sport
Model Number	S100.6
Special Feature	Bagged, Compact, Corded, Lightweight, Blower Function
Filter Type	Activated Charcoal Electrostatic Filter
Power Source	Corded Electric
Wattage	700 watts
Amperage	6 Amps
Capacity	0.95 Quarts
Hose Length	4 Feet
Cord Length	25 Feet

Feature	Detail
Cleaning Path Width	10.5 Inches
Item Weight	4.5 pounds
Product Dimensions	21"L x 15"W x 7"H
Color	White
Recommended Uses	Hard Floor, Rugs, Upholstery, Vehicles, Stairs
Assembly Required	Yes
Certifications	ETL Certified

WARRANTY AND SUPPORT

The Simplicity Sport S100.6 Canister Vacuum Cleaner comes with a **one-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal household use. For warranty claims, technical support, or to purchase replacement parts (such as SS-6 vacuum bags or filters), please contact Simplicity Vacuums customer service. Refer to the contact information provided with your product packaging or visit the official Simplicity Vacuums website for assistance.

© 2024 Simplicity Vacuums. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CYCL9BQK>

More documents and user manuals: <https://manuals.plus/>