

## Orion B0CYCSHQ3

# Orion TV User Manual

Model: B0CYCSHQ3

## 1. INTRODUCTION

---

Thank you for choosing the Orion TV. This manual provides essential information for the safe and efficient use of your new television. Please read this manual thoroughly before operating the device and retain it for future reference. For the best viewing experience, ensure proper setup and regular maintenance.

## 2. SAFETY INFORMATION

---

Always observe the following safety precautions to prevent electric shock, fire, or injury.

- Do not expose the TV to rain or moisture.
- Ensure proper ventilation; do not block ventilation openings.
- Use only the power cord supplied with the TV.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Keep the TV away from direct sunlight and heat sources.
- Place the TV on a stable, level surface to prevent it from falling.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in the box:

- Orion TV Unit
- Remote Control
- Power Cord
- AAA Batteries (2) for Remote Control
- Quick Start Guide
- User Manual (this document)

## 4. SETUP

---

Follow these steps to set up your Orion TV:

1. **Unpacking:** Carefully remove the TV from its packaging. It is recommended to have two people for this step.
2. **Stand Installation (Optional):** If using the included stand, attach it to the bottom of the TV using the provided screws. Refer to the Quick Start Guide for detailed diagrams.
3. **Wall Mounting (Optional):** If wall mounting, ensure you use a VESA-compatible mount (not included) and follow the mount manufacturer's instructions.
4. **Connecting Devices:** Connect your external devices (e.g., cable box, Blu-ray player, gaming console) to the appropriate HDMI, USB, or other input ports on the back of the TV.
5. **Power Connection:** Plug the power cord into the TV's power input, then into a wall outlet.
6. **Initial Power On:** Press the power button on the TV or remote control to turn on the TV. Follow the on-screen instructions for initial setup, including language selection, network connection, and channel scanning.

*Note: No product images were provided in the input. An image here would typically show the back panel of the TV with various input ports labeled, demonstrating how to connect external devices.*

*Note: No official product videos were provided in the input. A video here would typically demonstrate the step-by-step process of installing the TV stand or connecting common external devices.*

## 5. OPERATING

---

### 5.1 Basic Operation

- **Power On/Off:** Press the **Power** button on the remote control or TV.
- **Volume Control:** Use the **VOL + / -** buttons to adjust the volume.
- **Channel Selection:** Use the **CH + / -** buttons to change channels or enter channel numbers directly using the numeric keypad.
- **Input Source:** Press the **Input** or **Source** button to select between HDMI, AV, USB, or other connected inputs.
- **Menu Navigation:** Use the arrow keys (**Up, Down, Left, Right**) and **OK** button to navigate through the on-screen menus.

### 5.2 Smart TV Features

Your Orion TV includes smart features for enhanced entertainment:

- **Network Connection:** Connect your TV to a Wi-Fi network via the Settings menu to access online content.
- **App Store:** Access the integrated app store to download and install streaming services, games, and other applications.
- **Screen Mirroring:** Use the screen mirroring function to display content from your compatible smartphone or tablet on the TV screen.
- **Voice Control:** If your remote control supports voice commands, press the dedicated voice button and speak clearly into the microphone.

## 6. MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your TV.

- **Screen Cleaning:** Gently wipe the screen with a soft, dry microfiber cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (never spray directly onto the screen).
- **Casing Cleaning:** Use a soft, dry cloth to clean the TV casing. Avoid abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked by dust or objects. Periodically clean dust from these areas.
- **Remote Control:** Replace batteries when the remote control's range decreases or it stops responding. Use AAA batteries.
- **Software Updates:** Periodically check for software updates via the TV's settings menu to ensure you have the latest features and security patches.

## 7. TROUBLESHOOTING

---

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
No power	Power cord disconnected; outlet issue; remote batteries dead.	Check power cord connection; test outlet with another device; replace remote batteries.
No picture, but sound is present	Incorrect input source selected; external device issue.	Press the <b>Input/Source</b> button to cycle through inputs; check external device connections.
No sound, but picture is present	Volume muted or too low; external device audio settings.	Unmute or increase volume; check audio output settings on external device.
Remote control not working	Dead batteries; obstruction; remote not paired.	Replace batteries; remove obstructions; re-pair remote if applicable (refer to Quick Start Guide).
Wi-Fi connection issues	Incorrect password; router issue; TV too far from router.	Verify Wi-Fi password; restart router; move TV closer to router or use an extender.

If the problem persists after trying these solutions, please contact customer support.

## 8. SPECIFICATIONS

---

Feature	Specification
Model Number	B0CYCASHQC3
Display Type	LED

Feature	Specification
Resolution	Full HD (1920 x 1080) or 4K UHD (3840 x 2160) - <i>Specific resolution depends on variant.</i>
Connectivity	HDMI (x3), USB (x2), AV In, Optical Audio Out, Ethernet, Wi-Fi
Smart Features	Integrated App Store, Screen Mirroring, Voice Control (on select models)
Power Supply	AC 100-240V ~ 50/60Hz
Dimensions (without stand)	<i>Varies by screen size.</i>
Weight (without stand)	<i>Varies by screen size.</i>

## 9. WARRANTY AND SUPPORT

---

Your Orion TV comes with a limited warranty from the date of purchase. Please register your product online to activate your warranty and receive important updates.

- **Warranty Period:** 1-year limited warranty on parts and labor.
- **What is Covered:** Defects in materials and workmanship under normal use.
- **What is Not Covered:** Damage caused by misuse, accidents, unauthorized modifications, or acts of nature.

### Customer Support:

For technical assistance, warranty claims, or general inquiries, please contact our support team:

- **Website:** [www.orientvsupport.com](http://www.orientvsupport.com) (hypothetical link)
- **Email:** [support@orienttv.com](mailto:support@orienttv.com) (hypothetical link)
- **Phone:** 1-800-555-ORION (hypothetical number)

Please have your model number (B0CYCASHQC3) and proof of purchase ready when contacting support.