

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [abode](#) /
- › [Abode Lock & Keypad Smart Lock User Manual](#)

abode 850025571326

Abode Lock & Keypad Smart Lock User Manual

Model: 850025571326

1. INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of the Abode Lock & Keypad Smart Lock. This device offers keyless entry through a keypad, fingerprint recognition, or the Abode mobile application, and integrates with smart home systems like Alexa and Google Home.



Image 1.1: The Abode Lock and Keypad Smart Lock, showcasing both the interior lock unit and the exterior keypad.

2. PRODUCT OVERVIEW

2.1 Included Components

The Abode Lock package includes the following items:

- Lock Body with battery
- Keypad with fingerprint scanner
- Mounting plate
- Screws
- Lock adaptor fittings (3 types)
- Keypad mounting screws and plugs

- Keypad mounting adhesive
- Lock stabilizing tape

2.2 Component Identification



Image 2.1: Detailed diagram illustrating the internal and external components of the Abode Lock Body and Keypad, with numbered labels for each part.

Lock Body:

1. Battery
2. Reset button
3. LED indicator
4. Thumb turn

Keypad:

1. Fingerprint scanner
2. LED indicator
3. Mounting plate
4. Battery compartment
5. Mounting screw location

3. INSTALLATION

The Abode Lock is designed to work with your existing deadbolt and door hardware, preserving the door's aesthetic. It replaces the existing locking mechanism on the inside of your door.

3.1 Compatibility

The lock includes 3 deadbolt lock adapters to fit most common deadbolt locks.

3.2 Installation Steps

1. **Prepare Door:** Ensure your existing deadbolt operates smoothly. The Abode Lock mounts on the interior side of the door.
2. **Install Lock Body:** Replace your existing interior locking mechanism with the Abode Lock body. Use the appropriate lock adaptor fitting for your deadbolt. Secure the mounting plate and lock body with the provided screws.




Image 3.1: The interior Abode Lock body being installed over an existing deadbolt mechanism on a door.

3. **Mount Keypad:** The wireless keypad is weatherproof and can be mounted on the outside door, door frame, or any desired location within 9 feet of the lock. Use the keypad mounting screws and plugs or the adhesive.

Works With Your Existing Door Lock

The Abode Lock uses your current deadbolt, outside door lock & handle.




Image 3.2: The Abode Keypad mounted on a wall adjacent to a door, demonstrating its placement for external access.

4. **App Setup:** Download the Abode App (available for iOS and Android). Follow the in-app instructions to complete the installation, connect the lock to your WiFi network, and pair it with the Bluetooth keypad.

4. OPERATING INSTRUCTIONS

The Abode Lock offers multiple methods for secure keyless entry and remote management.

4.1 Keyless Entry Options

Access your property using one of the following methods:

- **Fingerprint Recognition:** Use the integrated fingerprint reader on the keypad for quick and secure access.



Image 4.1: A finger being placed on the fingerprint scanner located at the top of the Abode Keypad for entry.

- **PIN Codes:** Enter a programmable keycode on the keypad.



Image 4.2: A user entering a PIN code on the numerical keypad of the Abode Smart Lock.

- **Abode Mobile App:** Lock and unlock your door directly from the Abode application on your smartphone.



Image 4.3: A smartphone displaying the Abode application interface, with the smart lock visible in the background.

- **Voice Commands:** Control the lock using Amazon Alexa or Google Home voice assistants.

Easy To Control With Alexa and Google Assistant



Image 4.4: A woman using her smartphone to control the Abode Lock, with Alexa and Google Home logos indicating voice assistant compatibility.

4.2 Remote Management

The Abode app allows you to manage your lock remotely from any location:

- Monitor the lock's status (locked/unlocked).
- Create and manage customizable keycodes, including permanent, single-use, and time-specific codes.
- Grant or revoke access for guests or service providers.

Remotely Manage From Anywhere

Unlock and lock your door anytime,
anywhere with the Abode app.



Image 4.5: A woman standing outside her home, using her smartphone to remotely manage the Abode Lock.

5. MAINTENANCE

5.1 Battery Replacement

The Lock Body and Keypad are battery-powered. The package includes 2 AAA batteries for the Lock Body. The wireless keypad battery is expected to last approximately 12 months on a full charge.

- The Abode app will notify you when battery levels are low.
- Refer to the component identification diagram (Image 2.1) for battery compartment locations.
- Replace batteries with new ones of the specified type (AAA for Lock Body, type not specified for keypad but typically similar).

5.2 Cleaning

Clean the lock and keypad surfaces with a soft, dry cloth. Avoid using abrasive cleaners or solvents that may damage the finish or electronic components.

6. TROUBLESHOOTING

If you encounter issues with your Abode Lock & Keypad, refer to the following common problems and solutions:

- **Lock Motor Weakness or Incomplete Locking:**

If the lock motor struggles to engage or disengage the deadbolt, ensure there is no obstruction in the door frame or strike plate. The deadbolt should move freely without resistance. Adjust the strike plate or the deadbolt hole if necessary to ensure smooth operation.

- **Connectivity Issues (Disconnection from Network/Keypad):**

If the lock frequently disconnects from your WiFi network or the keypad, ensure the lock is within range of your WiFi router and the keypad is within 9 feet of the lock. Check your home network for stability. A hard reset of the lock or keypad may resolve temporary connection issues. Refer to the Abode app for network status and troubleshooting guides.

- **Keypad Unresponsive or Codes Invalid:**

If the keypad stops working or programmed codes are not recognized, check the keypad's battery level. If batteries are sufficient, try performing a hard reset on the keypad. Ensure the keypad is properly paired with the lock via Bluetooth through the Abode app. Firmware updates can also address such issues; check the Abode app for available updates.

- **Lock Body Fit Issues:**

If the Abode Lock body does not fit securely over your existing deadbolt mechanism, ensure you are using the correct lock adaptor fitting. The lock is designed to fit most standard deadbolts, but some variations may require minor adjustments to the door or deadbolt components.

- **Door Open/Closed Status:**

Note that this lock primarily indicates locked or unlocked status, not whether the door itself is open or closed. For door open/closed sensing, additional sensors may be required as part of a broader security system.

7. SPECIFICATIONS




Brand	abode
Model Number	850025571326
Lock Type	Keypad
Special Features	Fingerprint, Keyless, Programmable
Material	Metal
Color	Black
Item Dimensions (L x W x H)	1.46 x 2.83 x 5.94 inches
Item Weight	1.5 pounds
Batteries	2 AAA batteries required (included)
Connectivity Protocol	Bluetooth (for keypad pairing), WiFi (for remote app control)
Control Method	App, Voice (Amazon Alexa, Google Home)
Recommended Uses	Residential Doors, Commercial Doors, Home Security, Office Security

8. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Abode website or contact Abode customer service directly. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

For technical assistance, product registration, or to access the latest FAQs and troubleshooting guides, visit the Abode support portal.

Related Documents - 850025571326

	<p>Abode Iota Home Security and Automation Gateway: User Guide and Technical Specifications</p> <p>Comprehensive guide to the Abode Iota, an all-in-one home security and automation gateway featuring HD camera, motion sensor, Z-Wave, ZigBee, and voice control. Includes setup, features, and technical command class information.</p>
	<p>Abode Wireless Remote Key Fob: Setup and Usage Guide</p> <p>Comprehensive guide to the Abode Wireless Remote Key Fob, covering its functions, button operations, battery replacement, and pairing procedures with the Abode gateway. Learn how to arm, disarm, and manage your security system remotely.</p>
	<p>Abode Wireless Keypad User Guide: Features, Functions, and Setup</p> <p>Comprehensive guide to the Abode wireless keypad, covering product features, battery power, arming/disarming procedures, LED indicators, fault status, and gateway pairing. Learn how to use and program your Abode keypad for home security.</p>
	<p>Abode Wireless Video Doorbell: Setup and Compliance Information</p> <p>Learn how to set up your Abode Wireless Video Doorbell and Chime. Includes pairing instructions, FCC and ISED compliance statements, and product specifications.</p>
	<p>Abode Indoor Siren (abode RF) User Guide</p> <p>Comprehensive user guide for the Abode Indoor Siren (abode RF). Learn about its features, AC power and battery backup, pairing process with the Abode gateway, alarm activation, audio status indications, and how to control various sound settings like entry/exit delays and confirmation beeps. Includes factory reset instructions.</p>

