Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-FB2

Joyroom JR-FB2 Funpods Series True Wireless Earphones User Manual

Introduction

The Joyroom JR-FB2 Funpods Series True Wireless Earphones are designed to provide a high-quality audio experience. They feature a 13mm dynamic driver for powerful sound and HiFi audio. Key functionalities include an extended battery life, Bluetooth 5.3 for stable connectivity, one-step reconnection, low latency technology for synchronized audio and video, and DNS Enhanced Calling for clear communication.

Package Contents

Please verify that all items listed below are present in your package:

- Joyroom JR-FB2 True Wireless Earphones (Left and Right earbuds)
- Charging Case
- USB Charging Cable
- User Manual



Image: The retail box, user manual, charging case, two earbuds, and a USB charging cable are displayed.

Product Overview

The Joyroom JR-FB2 Funpods Series consists of two wireless earbuds and a portable charging case. The earbuds are designed for in-ear comfort, while the charging case provides protection and recharges the earbuds on the go.



Image: The blue Joyroom JR-FB2 earbuds are shown resting inside their open charging case, with a small green indicator light visible on the front of the case.

Setup

1. Charging the Earphones and Case

Before first use, fully charge the charging case and earbuds. Connect the provided USB charging cable to the charging port on the case and a power source. A 10-minute charge can provide approximately 1 hour of playback time for the earbuds.



Image: A close-up view of the side of the blue charging case, showing the USB-C charging port.

2. Pairing with a Device

1. Ensure the earbuds are in the charging case and the case is sufficiently charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (e.g., smartphone, tablet), enable Bluetooth.
4. Search for available Bluetooth devices and select "Joyroom Funpods FB2" from the list.
5. Once connected, the earbuds are ready for use. The Bluetooth 5.3 technology ensures higher noise immunity and lower power consumption, with one-step reconnection for convenience.



Image: A smartphone screen displays Bluetooth settings, showing "Joyroom Funpods FB2" as a connected device, next to an open charging case with earbuds.

Operating Instructions

Audio Playback

The JR-FB2 earphones feature a 13mm dynamic driver, delivering powerful sound and HiFi audio quality for an enhanced listening experience.




Image: A diagram illustrating the internal structure of a 13mm dynamic driver, highlighting its components for sound production.

Calling Functionality

The earphones incorporate DNS Enhanced Calling technology, which helps to reduce background noise, ensuring clear communication during calls.



Image: A person smiling while wearing a Joyroom JR-FB2 earbud, illustrating the clear calling experience.

Low Latency Mode

With 65ms low latency technology, the earphones provide synchronized audio and video, which is beneficial for watching videos or playing games.



Image: A person wearing a Joyroom JR-FB2 earbud while holding a smartphone horizontally, playing a racing game, demonstrating the low latency feature.

Touch Controls

The earphones are equipped with touch controls for managing playback, calls, and other functions. Refer to the quick start guide included in your package for specific touch gestures.

Battery Life

The earphones offer up to 7 hours of continuous use on a single charge. With the charging case, the total playback time extends to approximately 35 hours (at 70% volume).



Image: A graphic illustrating the 35-hour total playtime of the Joyroom JR-FB2 earphones, with the earbuds floating above the charging case.

Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in constant use.
- **Water Exposure:** Avoid exposing the earphones to water or excessive moisture.

Troubleshooting

No Sound or Pairing Issues

- Ensure both earbuds are charged and correctly placed in the charging case.

- Verify that Bluetooth is enabled on your device and the earphones are selected.
- Try unpairing and re-pairing the earphones with your device.
- Restart your device and try connecting again.

Charging Problems

- Check the charging cable and adapter for damage.
- Ensure the charging port on the case is clean and free of debris.
- Confirm the power source is active.

Poor Call Quality

- Ensure the earbuds are properly seated in your ears.
- Check for strong environmental noise that might interfere with the microphone.
- Ensure your device has a stable network connection if making calls over cellular or Wi-Fi.

Specifications

Feature	Detail
Brand	Joyroom
Model Name	Funpods Series (JR-FB2)
Connectivity Technology	Wireless (Bluetooth 5.3)
Headphones Form Factor	In Ear
Noise Control	Active Noise Cancellation (DNC Detect Noise Cancellation)
Driver Size	13mm Dynamic Driver
Total Playtime (with case)	Up to 35 hours
Earbud Playtime (single charge)	Up to 7 hours
Quick Charge	10-minute charge for 1 hour playback
Low Latency	65ms
Control Method	Touch
Compatible Devices	Cellphones
Item Weight	37.6 Grams
Product Dimensions	9 x 5 x 16 cm
Material	Plastic

Warranty and Support

For warranty information, technical support, or further assistance, please refer to the warranty card included in your product packaging or visit the official Joyroom website. You may also contact Joyroom customer service directly.

Visit the Joyroom Store on Amazon for more products and information.

© 2024 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYD9PHQR

More documents and user manuals: **https://manuals.plus/**