WOPET CA10-White

WOPET Automatic Pet Feeder User Manual

Model: CA10-White
Brand: WOPET

1. Product Overview

The WOPET Automatic Pet Feeder (Model CA10-White) is designed to provide scheduled and portion-controlled meals for your cats and dogs. It features smart APP control for remote feeding, a 10-second voice recording function, and a large 4L food storage capacity. The feeder supports 1-10 meals per day with up to 8 portions of dry food per meal.



Figure 1: Front view of the WOPET Automatic Pet Feeder, showing the transparent food hopper filled with kibble and the stainless steel bowl.

2. Setup and Assembly

1. **Unpack Components:** Carefully remove all components from the packaging. Ensure you have the main feeder unit,

food hopper, stainless steel bowl, and power adapter.

2. **Attach Food Hopper:** Align the food hopper with the main feeder unit. Gently push it forward until it snaps securely into place. The hopper is designed for easy detachment for cleaning.



Figure 2: Illustration of the detachable food hopper and bowl, emphasizing ease of cleaning.

3. **Install Feeding Bowl:** Flip the main feeder unit upside down. The black plastic bowl holder will attach to the bottom. Push it in until it clicks. Then, place the stainless steel bowl into the black plastic holder.

4. **Insert Odor Bag (Optional but Recommended):** Open the small cage on the underside of the lid. Insert the provided odor bag into this compartment and close the cage. This helps keep the food fresh.
5. **Fill Food Hopper:** Open the lid and pour dry pet kibble into the 4L capacity hopper. Ensure the kibble size is between 0.07-0.47 inches (2-12mm) to prevent clogging. Close the lid securely. The twist-lock design helps prevent pets from accessing the food.



Figure 3: The feeder's twist-lock lid, designed to prevent pets from opening it and overeating.

6. **Connect Power:** Plug the power adapter into the feeder and then into a wall outlet. The feeder also supports 3 x D

alkaline batteries (not included) for backup power during outages, ensuring continuous operation.



Figure 4: The feeder operating with dual power supply options: power adapter and battery backup.

3. Operating Instructions

3.1 Setting the Current Time

1. Press the **Settings** button (gear icon) on the control panel.

2. Use the **Up** and **Down** arrows to adjust the hour.
3. Press the **Settings** button again to move to minutes, then adjust with arrows.
4. Press the **Settings** button once more to set AM/PM, then adjust with arrows.
5. Press the **Lock** button (padlock icon) to save the time and exit.

3.2 Scheduling Automatic Meals

The feeder allows you to schedule up to 6 meals per day, with 1 to 8 portions per meal. Each portion is approximately 12g (1/12 cup).



Figure 5: The feeder in a home setting with a cat, highlighting its capacity for scheduled feeding (1-6 meals/day, 0-8 portions/meal, 4L capacity).

1. Press the **Settings** button (gear icon) until "MEAL 1" appears on the display.
2. Use the **Up** and **Down** arrows to set the desired feeding time for Meal 1 (hour, then minutes, then AM/PM). Press **Settings** after each adjustment.
3. After setting the time, the display will show "P-00". Use the**Up** and **Down** arrows to select the number of portions (1-8)

for Meal 1.

4. Press the **Settings** button to confirm Meal 1 settings and move to Meal 2.
5. Repeat steps 2-4 for additional meals (up to 6). If you do not wish to set all 6 meals, simply press the **Lock** button to exit the scheduling mode.
6. To record a 10-second voice message that plays during feeding times, press and hold the **Record** button (microphone icon) until you hear a beep. Speak your message, then release the button.

3.3 Manual Feeding

To dispense one portion of food immediately, press the **Manual Feed** button (bowl icon) on the control panel. This will dispense a single portion into the bowl.

4. Maintenance and Cleaning

Regular cleaning ensures hygienic feeding and extends the life of your feeder.

1. **Disassembly:** Unplug the feeder. Detach the food hopper by pushing it forward. Remove the stainless steel bowl from its holder.
2. **Cleaning:** Both the food hopper and the stainless steel bowl are dishwasher-safe for thorough cleaning. The main unit should be wiped clean with a damp cloth. Do not immerse the main unit in water.
3. **Reassembly:** Ensure all parts are completely dry before reassembling. Follow the setup steps in reverse order.
4. **Odor Bag Replacement:** Replace the odor bag periodically (e.g., every 1-2 months) to maintain food freshness.

5. Troubleshooting

Problem	Possible Cause	Solution
Feeder not dispensing food.	• Food hopper empty. • Kibble size too large, causing a jam. • Power issue.	• Refill food hopper. • Check for and clear any food jams. Ensure kibble is within 0.07-0.47 inches. • Verify power adapter is securely plugged in. Check battery level if using battery power.
Scheduled meals not dispensing.	• Incorrect time setting. • Meal schedule not properly saved.	• Re-check and set the current time accurately. • Review meal schedule settings and ensure they are saved by pressing the Lock button.
Voice recording not playing.	• Recording not saved. • Volume too low.	• Ensure you held the record button until a beep and released it after speaking. Re-record if necessary. • Check feeder volume settings (if applicable, though not explicitly mentioned in feature bullets, common for feeders).

6. Specifications

- **Model Name:** CA10-White
- **Brand:** WOPET

- **Capacity:** 4 Liters (approx. 17 cups / 4.4 lbs of dry food)
- **Material:** Stainless Steel (bowl), Plastic (hopper, main unit)
- **Dimensions:** 7 x 7 x 13 inches
- **Item Weight:** 1.5 Pounds
- **Power Supply:** Power Adapter (included), 3 x D alkaline batteries (not included)
- **Meals Per Day:** 1-10 (via APP control), 1-6 (via manual panel)
- **Portions Per Meal:** Up to 8 portions
- **Kibble Size:** 0.07-0.47 inches (2-12mm) recommended
- **Special Features:** APP Control, Remote Feeding, 10S Voice Record, Twist-Lock Storage, Detachable for Cleaning, Dual Power Supply
- **Target Species:** Dog, Cat, Small animals

7. Warranty and Support

This WOPET product comes with a**1-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.
For technical support, troubleshooting assistance, or warranty inquiries, please contact WOPET Customer Service through the following channels:

- **Website:** Visit the official WOPET website for FAQs and support contact information.
- **Email:** Refer to your product packaging or the WOPET website for the customer support email address.
- **App Support:** Utilize the support features within the WOPET Life App for direct assistance.

Always refer to the latest information on the official WOPET website for the most up-to-date support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question