

Woowind BP188

Woowind BP188 Electric Tire Inflator User Manual

Brand: Woowind | Model: BP188

INTRODUCTION

The Woowind BP188 Electric Tire Inflator is a versatile and portable air compressor designed for various inflation needs. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device. With features like multiple inflation modes, auto shut-off, and a digital display, the BP188 offers convenience and precision for keeping your tires and inflatables at the correct pressure.

SETUP

Unboxing and Components

Upon opening the package, ensure all components are present. The standard packing list includes:

- 1x Woowind BP188 Tire Inflator
- 1x Flexible Hose with Adapters (Presta, Schrader, Dunlop)
- 1x Ball Needle
- 1x Swimming Ring Nozzle
- 1x USB-C Charging Cable
- 1x Carrying Bag
- 1x User Manual



Figure 1: Woowind BP188 Smart Air Pump and included accessories: flexible hose, USB cable, Presta valve, Dunlop valve, ball needle, swimming ring nozzle, and carrying bag.

Experiencia de producto
incomparable



ELEGIDO POR
300.000+
USUARIOS EN EL MUNDO

2x MÁS VIDA ÚTIL QUE
OTROS INFLADORES

24 MESES DE GARANTÍA
SIN PREOCUPACIONES



Figure 2: All components of the Woowind BP188 pump laid out on a wooden table, including the pump, hose, adapters, and charging cable.

Charging the Device

Before first use, fully charge the BP188 pump using the provided USB-C charging cable. Connect the USB-C end to the pump's charging port and the USB-A end to a compatible power source (e.g., wall adapter, computer USB port).



LISTO EN 3 PASOS

- 1 Conecta el inflador
- 2 Configura la presión deseada
- 3 ¡Comienza a inflar!

**Inflado sencillo y
y sin complicaciones**

 **APAGADO
AUTOMÁTICO**

Figure 3: Close-up of the Woowind BP188 pump's USB-C charging port.

Attaching the Hose and Adapters

Screw the flexible hose securely into the top port of the inflator. Select the appropriate valve adapter (Schrader, Presta, Dunlop, ball needle, or swimming ring nozzle) for your item and attach it to the other end of the flexible hose.

Tus llantas, siempre
listas **donde y cuando sea.**

Presión Precisa
en Tiempo Real
±0.5 PSI



**AHORRA TIEMPO CON
MODOS PREESTABLECIDOS**

Coche / Bicicleta / Moto / Balón

Figure 4: Hand attaching the flexible hose to the Woowind BP188 pump and then to a bicycle tire valve.

Design Esperto Do Armazenamento Do Tubo De Ar



Figure 5: Various valve adapters including Schrader, Presta, Dunlop, and a ball needle.

OPERATING INSTRUCTIONS

Powering On and Display

To power on the device, long-press the central power button for 3 seconds. The digital display will illuminate, showing the current pressure (if connected to an item) and the target pressure. The display also indicates the battery level and the selected inflation mode.

El único inflador que necesitarás



Bicicletas
2-150 PSI



Motocicletas
2-40 PSI



Ciclomotores
2-40 PSI



Balones
2-15 PSI



Figure 6: Close-up of the Woowind BP188 pump's digital display showing current and target PSI.

Selecting Inflation Mode

Press the 'Mode' button (usually the bottom button on the control wheel) to cycle through the preset inflation modes: Bike, Motorcycle, Sports Ball, and Customization. The customization mode allows you to set pressure for car tires or other items.

**Potente y rápido,
Tan solo 2 minutos**



DE 2-120PSI



Figure 7: Woowind BP188 pump display showing different inflation modes for various items like balls, motorcycles, and bicycles.

Setting Target Pressure

Use the '+' and '-' buttons on the control wheel to adjust the target pressure to your desired PSI. The pump will automatically stop once this pressure is reached.

Starting and Stopping Inflation

Once the hose is securely attached and the target pressure is set, short-press the central power button to begin inflation. The pump will automatically shut off when the target pressure is achieved. To manually stop inflation at any time, short-press the power button again.

Note: No official seller videos demonstrating operation were available in the provided data.


Using the LED Light

The BP188 includes an integrated LED light for convenience in low-light conditions. Long-press the top button on the control wheel for 2 seconds to turn the light on or off.

Prepárate para imprevistos en la carretera



TRANQUILIDAD
EN TU PALMA



¿SIN LUZ? SIN PROBLEMA
Linterna Integrada



SIEMPRE EN TU BOLSA
Diseño portátil y sin cables



**VUELVE A LA
CARRETERA EN
MINUTOS**
Inflado rápido, sin
perder tiempo en la
gasolinera

Figure 8: Woowind BP188 pump's LED light illuminating a bicycle tire valve in the dark.

MAINTENANCE

Cleaning

Wipe the exterior of the pump with a soft, damp cloth. Do not use harsh chemicals or abrasive materials. Ensure the air intake vents are clear of debris.

Storage

Store the pump and its accessories in the provided carrying bag in a cool, dry place. The BP188 has a long standby time of up to 6 months after a full charge, making it ready when you need it.

Todo lo que incluye



Figure 9: Woowind BP188 pump and accessories stored neatly in its carrying pouch.

Battery Care

To prolong battery life, avoid completely draining the battery frequently. Recharge the device when the battery indicator is low, even if not in immediate use, especially before long storage periods.

TROUBLESHOOTING

| Issue | Possible Cause | Solution |
|-----------------------------|---|---|
| Device does not turn on | Low battery; Incorrect power-on procedure | Charge the device; Long-press the power button for 3 seconds |
| Pump does not inflate | Hose not securely attached; Adapter not properly connected; Target pressure already reached | Ensure hose is screwed in tightly; Check adapter connection; Verify current pressure on display |
| Inaccurate pressure reading | Loose hose or adapter connection | Tighten all connections between pump, hose, and valve |

SPECIFICATIONS

- Color: Black-120PSI

- Brand: Woowind
- Material: Aluminum
- Item Weight: 450 Grams
- Product Dimensions: 1.57"L x 1.57"W x 7.49"H
- Power Source: Battery Powered
- Air Flow Capacity: 20 LPM
- Maximum Pressure: 120 Pound per Square Inch
- Operation Mode: Automatic
- Model Name: Bp188 Black
- Model Year: 2022




WARRANTY




The Woowind BP188 Electric Tire Inflator comes with a 2-year warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, product inquiries, or warranty support, please visit the official Woowind Store on Amazon: [Woowind Store](#).

Related Documents - BP188

| | |
|--|--|
| <div>Ventus Race User Manual</div> <div></div> <div>Mini Bike Tire Inflator</div> | <div>Ventus Race Mini Bike Tire Inflator User Manual WOOWIND</div> <div>Comprehensive user manual for the Ventus Race Mini Bike Tire Inflator by WOOWIND, detailing specifications, setup, usage, and safety precautions for efficient tire inflation for bicycles and sports balls.</div> |
| <div>Smart Bike Pump User Manual</div> <div></div> <div>Model: BP188</div> | <div>Woowind BP188 Smart Bike Pump User Manual</div> <div>User manual for the Woowind BP188 Smart Bike Pump, detailing its features, specifications, operation, and safety guidelines for efficient tire inflation and maintenance.</div> |
| <div>Smart Tire Inflator User Manual</div> <div></div> <div>Model: DP3</div> | <div>Woowind DP3 Smart Tire Inflator User Manual</div> <div>Comprehensive user manual for the Woowind DP3 Smart Tire Inflator, covering specifications, operation, safety precautions, and troubleshooting for efficient tire inflation.</div> |

| | |
|--|--|
|  | <p>WOOWIND Ventus PRO Portable Air Pump User Manual</p> <p>The WOOWIND Ventus PRO User Manual provides comprehensive instructions for operating the portable air pump, including setup, charging, inflation modes, pressure settings, and troubleshooting tips for various applications like bicycles, motorcycles, cars, and balls. Learn about its features, specifications, and safety precautions.</p> |
| <p>Smart Tire Inflator User Manual</p>  <p>Model: AP2-P</p> | <p>Smart Tire Inflator AP2-P User Manual - Portable Air Pump Guide</p> <p>Comprehensive user manual for the Smart Tire Inflator AP2-P. Learn about its features, specifications, accessories, operation, and safety precautions for inflating tires on cars, motorcycles, bicycles, and more.</p> |
| <p>Smart Tire Inflator User Manual</p>  <p>Model: LP1</p> | <p>Woowind LP1 Smart Tire Inflator User Manual</p> <p>User manual for the Woowind LP1 Smart Tire Inflator, detailing setup, operation, specifications, and safety guidelines for efficient tire inflation.</p> |