

- Manuals.plus /
- › Kaichenyt /
- › Kaichenyt Portable Electric Food Heat Lamp Instruction Manual (Model: Infrared Heating Bulb for Food)

Kaichenyt Infrared Heating Bulb for Food

Kaichenyt Portable Electric Food Heat Lamp Instruction Manual

Model: Infrared Heating Bulb for Food

1. INTRODUCTION

Thank you for choosing the Kaichenyt Portable Electric Food Heat Lamp. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new food warming device. Please read this manual thoroughly before use and retain it for future reference.



Image: The Kaichenyt Food Heat Lamp in operation, warming a dish of food.

2. SAFETY INSTRUCTIONS

To prevent injury or damage, always observe the following safety precautions:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Food Heat Lamp Unit (Base, Pole, Flexible Arm, Lampshade)
- Infrared Heating Bulb (250W)
- Power Cord (integrated)

4. SETUP

Follow these steps to set up your food heat lamp:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Assemble:** The lamp unit typically comes pre-assembled. Ensure the pole is securely attached to the base and the flexible arm is firmly connected to the lampshade.
3. **Install Bulb:** Gently screw the provided 250W infrared heating bulb into the socket inside the lampshade. Do not overtighten.
4. **Placement:** Place the assembled heat lamp on a stable, flat, and heat-resistant surface. Ensure there is adequate clearance around the lamp and the food being warmed to prevent overheating of surrounding objects.

5. OPERATING INSTRUCTIONS

Operating your Kaichenyt Food Heat Lamp is straightforward:

1. **Connect Power:** Plug the power cord into a standard 110V electrical outlet. The power cord length is approximately 4.76 ft (1.45m).
2. **Turn On:** Locate the rocker switch on the base of the lamp. Toggle the switch to the 'ON' position to activate the heating bulb.



Image: The rocker switch for easy operation.

3. **Adjust Lamp Head:** The lamp head features a flexible hose that can be swiveled 180°. Adjust the direction and angle of the lampshade to focus the heat directly onto the food.



180° Rotatable Light Head

The top of the light head has a flexible hose that can be rotated 180°. This allows you to easily adjust the direction and angle of the lighting.

Image: The 180-degree rotatable light head allows for precise heat direction.

4. **Food Warming:** The 250W infrared lamp is designed to maintain food temperature at approximately 140°F (60°C), ensuring food remains warm and fresh for extended periods.



250W High-Power Infrared Lamp

The 250W high-power infrared lamp can control the food temperature at about 60°C/140°F (Depending on the Working Environment), ensuring that food keeps warm and fresh for a longer period of time.

Image: The 250W high-power infrared lamp effectively warms food.

5. **Turn Off:** When finished, toggle the rocker switch to the 'OFF' position and unplug the lamp from the power outlet. Allow the lamp to cool completely before handling or storing.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your heat lamp:

- **Cleaning:** Ensure the lamp is unplugged and completely cool before cleaning. Due to its smooth surface and simple structure, you can simply wipe the exterior with a dry, soft cloth. Do not use abrasive cleaners or immerse the unit in water.

Product Details

1



Stainless Steel Lampshade

Durable and high temperature resistant

2

Heat Dissipation Holes

Dissipates heat from the bulb in a timely manner



Image: The stainless steel lampshade and heat dissipation holes for efficient operation.

- **Bulb Replacement:** If the bulb needs replacement, ensure the lamp is unplugged and cool. Unscrew the old bulb and screw in a new 250W infrared heating bulb.
- **Heat Dissipation:** The lamp head features multiple heat dissipation holes to prevent overheating and prolong the bulb's lifespan. Ensure these holes are not obstructed during operation.
- **Storage:** Store the lamp in a dry, cool place when not in use.

7. TROUBLESHOOTING

If you encounter issues with your food heat lamp, refer to the following table:

Problem	Possible Cause	Solution
Lamp does not turn on	No power supply; Bulb loose or faulty; Switch in OFF position	Check power outlet; Ensure plug is fully inserted; Tighten or replace bulb; Toggle switch to ON

Problem	Possible Cause	Solution
Food not warming effectively	Lamp too far from food; Bulb wattage insufficient; Bulb faulty	Adjust lamp closer to food; Ensure 250W bulb is used; Replace bulb
Overheating smell	Obstructed heat dissipation holes; Foreign object on lampshade	Ensure ventilation holes are clear; Remove any foreign objects; Unplug and allow to cool

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Detailed specifications for the Kaichenyt Portable Electric Food Heat Lamp:

Feature	Detail
Model Number	Infrared Heating Bulb for Food
Voltage	110 Volts
Wattage	250 watts
Material	Stainless Iron
Product Dimensions (L x W x H)	7.48 x 7.48 x 27.56 inches (19 x 19 x 70 cm)
Lampshade Diameter	7.48 inches (19 cm)
Item Weight	10.6 pounds
Power Cord Length	4.76 ft (1.45 m)
Power Source	Corded Electric

Product Dimensions

PARAMETERS

Voltage: 110V 50Hz

Power: 250W

Lampshade Diameter: 19cm/7.48in

Power Cord Length: 1.45m/4.76ft



Image: Product dimensions and specifications.

9. APPLICABLE SCENARIOS

This food heat lamp is suitable for various commercial and home settings where food warming is required:

- Restaurants
- Kitchens
- Cafeterias
- Canteens
- Hotels
- Buffet Lines

Applicable Scenarios

KITCHEN



CAFETERIA



CANTEEN



HOTEL



Image: Examples of environments where the food heat lamp can be used.

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase documentation or contact Kaichenyt customer service directly. Keep your purchase receipt as proof of purchase.

© 2024 Kaichenyt. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CYGXY9XZ>

More documents and user manuals: **<https://manuals.plus/>**