

[Manuals.plus](#) /

› [Demeyere](#) /

› Demeyere 10-Shelf Column Bookcase, Scandinavian Style, White Matt & Hamilton Oak, Model 347766 Instruction Manual

Demeyere 347766

Demeyere 10-Shelf Column Bookcase

Model: 347766

Instruction Manual

1. INTRODUCTION

Thank you for choosing the Demeyere 10-Shelf Column Bookcase. This versatile furniture piece, featuring a Scandinavian style with a white matt and Hamilton oak finish, is designed to provide extensive storage and enhance your living space. This manual provides essential information for safe assembly, proper use, and maintenance of your new bookcase.

The bookcase can be oriented vertically as a column or horizontally as a longer storage unit, adapting to your space and needs. It features 10 distinct storage compartments.



182.8cm

The image shows a tall, white bookcase with a modern, geometric design. It features a central column of light-colored wood that divides the interior into three main sections. The shelves are white and are arranged in a staggered fashion, with some shelves extending from the left side and others from the right. The bookcase is shown in a vertical orientation. Dimensions are indicated with black lines and text: a height of 182.8cm, a width of 77.9cm, and a depth of 36cm.

36cm

77.9cm

Image 1.1: Demeyere 10-Shelf Column Bookcase, vertical orientation, showing overall dimensions (Height: 182.8 cm, Width: 77.9 cm, Depth: 36 cm).

2. SAFETY INFORMATION

- **Assembly:** Always assemble the unit on a soft, clean surface to prevent scratches. Keep small parts away from

children during assembly.

- **Stability:** This bookcase is designed to be freestanding. However, for added safety, especially in households with children or in earthquake-prone areas, it is highly recommended to secure the unit to a wall using appropriate anti-tip hardware (not included).
- **Weight Distribution:** Distribute weight evenly across the shelves. Place heavier items on lower shelves to improve stability. Do not overload shelves beyond their capacity.
- **Placement:** Ensure the bookcase is placed on a level and stable surface to prevent tipping.
- **Moving:** When moving the assembled unit, always lift it. Do not drag it, as this can damage the structure and floor.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

Typical Components:

- Side Panels (2)
- Top/Bottom Panels (2)
- Fixed Shelves (various sizes, total 10 compartments)
- Back Panel (if included)
- Hardware Pack (screws, dowels, cam locks, cam studs, shelf pins, anti-tip kit if provided)

Note: The exact number and type of panels and hardware may vary slightly. Refer to the detailed assembly diagram included in your package.

4. ASSEMBLY INSTRUCTIONS (SETUP)

Assembly is required for this product. We recommend two people for assembly. Approximate assembly time: 1-2 hours.

Tools Required:

- Phillips Head Screwdriver
- Hammer (for dowels)
- Measuring Tape (optional)

Step-by-Step Assembly:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Refer to the parts list and diagrams in your package to identify each piece.
2. **Install Dowels and Cam Studs:** Insert wooden dowels and metal cam studs into the pre-drilled holes on the designated panels as per the assembly diagram. Use a hammer gently for dowels if needed.
3. **Assemble the Frame:** Connect the side panels to the top and bottom panels using cam locks and cam studs. Ensure all connections are tight and secure.
4. **Insert Fixed Shelves:** Slide the fixed shelves into their designated slots within the frame. Secure them using the appropriate hardware (e.g., cam locks) as shown in the diagram.
5. **Attach Back Panel (if applicable):** If your unit includes a back panel, align it with the rear edges of the bookcase and secure it using small nails or screws provided.
6. **Final Tightening:** Once the main structure is assembled, gently tighten all screws and cam locks to ensure stability. Do not overtighten.

7. **Positioning:** Carefully move the assembled bookcase to its desired location. Ensure it is level.
8. **Wall Anchoring (Recommended):** For enhanced safety, attach the anti-tip hardware (if included or purchased separately) to the top rear of the bookcase and secure it to a wall stud.

5. USAGE

This 10-shelf bookcase offers versatile storage for books, decorative items, and more. Its design allows for both vertical and horizontal placement.

Vertical Orientation:



Image 5.1: The bookcase configured vertically, providing a tall storage solution.

Horizontal Orientation:

When placed horizontally, the bookcase functions as a long, low storage unit, suitable for media consoles or room dividers.



Image 5.2: The bookcase configured horizontally, demonstrating its adaptability.

Shelf Detail:



Image 5.3: Detail of a shelf, highlighting the finish and construction.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat and Moisture:** Keep the bookcase away from direct heat sources and areas of high humidity.
- **Hardware Check:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary, but do not overtighten.

7. TROUBLESHOOTING

- **Wobbly Unit:**
 - Ensure the bookcase is on a level surface. Adjust floor glides if present.
 - Check all assembly hardware (screws, cam locks) and tighten them securely.
 - Verify that all panels are correctly aligned and fully seated.
- **Damaged Parts:** If you discover any damaged parts upon unpacking or during assembly, do not proceed with assembly. Contact customer support for replacement parts.
- **Difficulty Assembling:** Review the assembly instructions and diagrams carefully. Ensure you are using the correct hardware for each step. If issues persist, contact customer support.

8. SPECIFICATIONS

Model Number	347766
Brand	Demeyere
Dimensions (W x D x H)	77.9 cm x 36 cm x 182.8 cm
Weight	45.69 kg
Material	Particle Board, MDF (15mm and 25mm thickness)
Number of Shelves	10 compartments
Color/Finish	White Matt & Hamilton Oak
Style	Scandinavian
Assembly Required	Yes
Installation Type	Freestanding

9. WARRANTY AND SUPPORT

This Demeyere product comes with a **2-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical assistance, missing parts, or warranty inquiries, please contact Demeyere customer support through their official website or the retailer where the product was purchased.

Demeyere is PEFC certified, ensuring sustainable forest management practices in the production of its furniture.

© 2026 Demeyere. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question