POLICE 8810

Police Stun Gun & Burn Pepper Spray Combo User Manual

Model: 8810

Product Overview

The Police Stun Gun Burn Pepper Spray Combo (Model 8810) is a dual-purpose self-defense tool designed for personal protection. It combines a powerful stun gun with an integrated LED flashlight and a maximum strength pepper spray. The stun gun features a durable aircraft-grade aluminum construction and is USB rechargeable. The pepper spray includes a safety lock and a keyring attachment for convenient carry.

Key Features:

- **Stun Gun:** Powerful heavy-duty police metal stun gun with strongest available power.
- **Flashlight:** Bright, tactical LED light with 3 modes (high, low & strobe) and adjustable focus zoom.
- **Rechargeable:** Internal USB rechargeable battery, eliminating the need for replacements.
- **Safety:** Features an on/off safety switch to prevent accidental discharges.
- **Portability:** Conveniently sized at 7.5 inches and includes a free holster with belt loop.
- **Pepper Spray:** BURN self-defense pepper spray with maximum stopping power.
- **Pepper Spray Range:** Long-range spray for protection from a safe distance.
- **Pepper Spray Safety:** Durable plastic shell and safety lock prevent accidental discharge; simple twist-to-unlock mechanism.
- **Pepper Spray Carry:** Equipped with a keyring attachment and belt clip for convenient, everyday carry.





Image: The Police Stun Gun and Burn Pepper Spray Combo, showing both devices side-by-side. The stun gun is a black, cylindrical device with a textured grip and a silver band, while the pepper spray is a compact black unit with a red safety switch and a keyring.

Safety Information

It is imperative to read and understand all safety warnings and instructions before using this product. Improper use can result in serious injury or legal consequences. Always check and comply with local, state, and federal laws regarding the ownership, carry, and use of stun guns and pepper spray.

- **Keep Out of Reach of Children:** This product is not a toy and should be stored securely away from children.
- **Intended Use:** This product is designed for self-defense purposes only.
- **Accidental Discharge Prevention:** Always engage the safety switch on the stun gun when not in use or when carrying it. For the pepper spray, ensure the safety lock is engaged to prevent accidental discharge.
- **Stun Gun Usage:** Do not use the stun gun on individuals with pacemakers, heart conditions, or pregnant women. Avoid prolonged contact; a 1-3 second contact is generally sufficient for incapacitation.
- **Pepper Spray Usage:** Only use in self-defense situations. Aim for the attacker's face (eyes, nose, mouth). Be aware of wind direction to avoid blowback.
- **First Aid (Pepper Spray Exposure):** In case of accidental exposure, flush affected areas with large amounts of cool water. Seek medical attention if irritation persists.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures.

Setup

Charging the Stun Gun:

1. Locate the charging port on the stun gun.
2. Connect the provided USB charging cable to the stun gun's charging port.
3. Plug the other end of the USB cable into any standard USB outlet (e.g., wall adapter, computer USB port).
4. Allow the device to charge for approximately 7 hours for a full charge. The charging indicator light will typically change or turn off when fully charged.



Image: The Police Stun Gun connected to a wall outlet via its charging cable, indicating the charging process.

Preparing the Pepper Spray:

- Familiarize yourself with the safety twist lock mechanism.
- Attach the keyring to your keys or use the belt clip for convenient access.

Operating Instructions

Using the Stun Gun:

1. Ensure the stun gun is adequately charged.
2. Slide the safety switch to the "ON" position.
3. Press the activation button to generate an electrical arc between the prongs. This creates a loud, intimidating sound and visible arc.
4. To incapacitate an attacker, firmly press the prongs against a large muscle group (e.g., shoulder, hip, thigh) for 1 to 3 seconds. The electrical current will disrupt muscle control.
5. Immediately disengage the safety switch after use.



Image: A close-up of the Police Stun Gun, highlighting its prongs and the "POLICE" branding on the body.

Using the LED Flashlight:

- With the stun gun safety switch in the "OFF" position, press the dedicated flashlight button to cycle through the light modes: high, low, and strobe.
- Adjust the focus zoom by sliding the head of the flashlight forward or backward.



Image: The Police Stun Gun shown from the flashlight end, demonstrating its use as a bright LED light.

Using the Burn Pepper Spray:

1. To prepare for use, twist the safety lock to the side to unlock the firing mechanism.
2. Aim the nozzle directly at the attacker's face.
3. Push down firmly on the actuator button to release the pepper spray.
4. After use, twist the safety lock back to the center position to prevent accidental discharge.



Image: A diagram illustrating the key features of the Burn Pepper Spray, including the safety twist lock, maximum heat strength, molded grooves for grip, and ease of carry.

Maintenance

Stun Gun Battery Care:

- Recharge the stun gun fully every 1-2 months, even if not used, to maintain battery health.
- Avoid overcharging by disconnecting the charger once the charging indicator shows a full charge.

Cleaning:

- Wipe the exterior of both devices with a soft, dry cloth to remove dust and debris.
- Do not use abrasive cleaners or immerse either device in water.

Pepper Spray Expiration:

- Check the expiration date on the pepper spray canister. Replace the canister before it expires to ensure maximum effectiveness.

Troubleshooting

- **Stun Gun Not Arcing/Working:**
  - Ensure the safety switch is fully in the "ON" position.
  - Check if the battery is charged. Recharge if necessary.
  - Verify that the activation button is being pressed firmly.
- **Flashlight Not Working:**
  - Ensure the stun gun safety switch is in the "OFF" position.
  - Check battery charge.
  - Press the flashlight button multiple times to cycle through modes.
- **Pepper Spray Not Firing:**
  - Ensure the safety twist lock is fully disengaged (twisted to the side).
  - Verify that the actuator button is being pressed down completely.
  - Check the expiration date of the canister.

Specifications

Feature	Detail
Brand	POLICE
Model Name	Police Stun Gun Burn Pepper Spray Combo 8810
UPC	850057244793
Number of Items	2
Color	Black
Material	Metal (Stun Gun)
Item Weight	10 Ounces
Stun Gun Length	7.5 inches (approx.)
Pepper Spray Volume	1/2 oz
Pepper Spray Dimensions	3.5" (height) x 1" (width) (approx.)
Included Components	Burn Pepper Spray, Police Stun Gun 8810



Image: The Burn Pepper Spray with approximate dimensions of 3.5 inches in height and 1 inch in width.

Warranty & Support

The Police Stun Gun Burn Pepper Spray Combo (Model 8810) comes with a **1-year warranty** from the manufacturer, POLICE. For any warranty claims, technical support, or product inquiries, please contact the manufacturer directly or refer to the contact information provided with your product packaging.
Please retain your proof of purchase for warranty validation.