

Doripel 30206

Doripel Rivera 30206 Wardrobe User Manual

MODEL: 30206

Introduction

This manual provides essential information for the proper use, care, and maintenance of your Doripel Rivera 30206 Wardrobe. Please read these instructions carefully before using the product to ensure its longevity and your satisfaction.

The Doripel Rivera 30206 Wardrobe is designed for compact spaces, featuring 6 hinged doors with copper-colored PVC handles, 2 drawers with plastic slides, 2 shelves, and vertical coated wooden hangers. Constructed from MDP, it offers efficient internal storage solutions.



Front view of the Doripel Rivera 30206 Wardrobe in white, showcasing its six doors and two central drawers with copper-colored PVC handles.

Specifications

Feature	Detail
Brand	Doripel
Model	30206
Color	White
Material	MDP Wood
Recommended Use	Clothes
Mounting Type	Floor Mount

Feature	Detail
Included Components	Drawers, Door Hinges, Shelves
Number of Drawers	2
Number of Shelves	2
Item Weight	57 Kilograms
Number of Doors	6
Customizable	No
Number of Levels	2
Style	Modern
Door Style	Slab
Finish Type	White
Installation Type	Freestanding
Assembly Required	No



Image showing the internal dimensions of the Doripel Rivera 30206 Wardrobe. Overall width: 137cm, height: 175cm, depth: 38cm. Internal sections include hanging spaces with heights of 114cm and widths of 44cm, and shelving units with varying heights (33cm, 45cm, 33cm) and widths of 44cm. Two drawers are located at the bottom center.

Setup and Placement

The Doripel Rivera 30206 Wardrobe is designed for freestanding installation and does not require assembly.

1. Choose a flat, level surface for placement to ensure stability.
2. Ensure there is adequate space around the wardrobe for opening all 6 doors and 2 drawers without obstruction.
3. Avoid placing the wardrobe in direct sunlight or near heat sources to prevent material damage or discoloration.
4. For safety, consider securing the wardrobe to a wall using appropriate anti-tip hardware (not included) to prevent accidental tipping, especially in households with children or pets.

Operating Instructions

Doors

The wardrobe features 6 hinged doors. To open, gently pull the copper-colored PVC handles. To close, push the doors firmly until they are securely shut. Avoid slamming the doors to prevent damage to the hinges and frame.

Drawers

The wardrobe includes 2 drawers with plastic slides. To open, pull the handles outwards. To close, push the drawers inwards until they are fully seated. Do not overload the drawers, as this can affect the smooth operation of the slides.

Shelves and Hanging Space

Utilize the 2 internal shelves for folded items and the vertical coated wooden hangers for garments that require hanging. Distribute weight evenly across shelves and hanging rods to maintain stability and prevent warping.

Maintenance

Cleaning

Wipe surfaces regularly with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner diluted in water. Dry immediately with a clean, dry cloth to prevent moisture damage.

Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the finish of the MDP wood.

Hinges and Slides

Periodically check door hinges and drawer slides for smooth operation. If they become stiff or noisy, a small amount of silicone-based lubricant can be applied.

General Care

Do not place hot items directly on the wardrobe surface. Use coasters or protective pads.

Avoid dragging the wardrobe when moving it; always lift it to prevent damage to the base and floor.

Troubleshooting

Doors do not close properly

- Check for any obstructions preventing the door from closing fully.
- Ensure the wardrobe is on a level surface. Uneven flooring can cause doors to misalign.
- Inspect hinges for damage or loose screws. Tighten screws if necessary.

Drawers are stiff or difficult to open/close

- Reduce the load in the drawer. Overloading can hinder movement.
- Check for any items obstructing the drawer slides.
- Clean the drawer slides and apply a silicone-based lubricant if needed.

Wardrobe feels unstable

- Verify that the wardrobe is placed on a completely flat and level surface.
- Consider using shims under the base if the floor is uneven.
- For added stability, secure the wardrobe to a wall using appropriate anti-tip hardware.

Warranty and Support

Warranty Information

This Doripel Rivera 30206 Wardrobe comes with a 3-month warranty from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for any warranty claims.

The warranty does not cover damage resulting from improper use, neglect, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For further assistance, parts replacement, or to report any issues not covered in this manual, please contact Doripel customer support. Refer to your purchase documentation for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question