



Manuals.plus /

› HOOBRO /

› HOOBRO BB22CW01 Storage Bench Instruction Manual

HOOBRO BB22CW01

HOOBRO BB22CW01 Storage Bench Instruction Manual

Model: BB22CW01 | Brand: HOOBRO

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOOBRO BB22CW01 Storage Bench. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Keep children away from the assembly area until the unit is fully assembled.
- The storage bench features a safety hinge and U-shaped cutout to prevent accidental lid closure and finger pinching. Always ensure these mechanisms are functioning correctly.
- Do not exceed the maximum weight recommendation of 220 lb (100 kg) for the bench.
- Do not use in prolonged exposure to direct sunlight or humid environments to prevent material degradation.
- Periodically check all fasteners to ensure they remain tight.

PACKAGE CONTENTS

Verify that all components listed in the assembly instructions are present before starting. The package includes all necessary parts and installation tools for assembly.

ASSEMBLY INSTRUCTIONS

Follow the detailed, easy-to-follow instructions included with your product. All parts are clearly numbered for straightforward assembly.

1. Unpack all components and lay them out on a soft, clean surface.
2. Identify each part using the provided numbering in the instruction manual.

3. Begin by attaching the side panels to the base, ensuring all screws are tightened securely.
4. Install the rattan-like panels into their designated slots.
5. Attach the safety hinges to the main body and the lid. Ensure the U-shaped cutout aligns correctly for safe operation.
6. Secure the metal pull rings to the sides of the bench.
7. Once fully assembled, gently test the lid's opening and closing mechanism to confirm the safety hinge functions as intended.



Image: The HOOBRO Storage Bench, model BB22CW01, shown in a child's room with the lid open, revealing various plush toys stored inside. The bench features a black finish and rattan-like panels.



Image: The HOOBRO Storage Bench, model BB22CW01, positioned at the foot of a bed in a bedroom. The lid is open, showing folded clothes neatly stored within the spacious interior.



Image: The HOOBRO Storage Bench, model BB22CW01, serving as an entryway bench. A coat rack with various items hangs above it, demonstrating its versatility and functional design.

OPERATING INSTRUCTIONS

Opening and Closing the Lid:

The storage bench is equipped with a safety hinge and a U-shaped cutout for easy and safe operation. To open, gently lift the lid using the U-shaped cutout. The safety hinge will hold the lid open, preventing it from slamming shut. To close, gently push the lid down. The hinge will control the descent, ensuring a slow and safe closure.

Safety Hinge

Enhanced security and reliability for the storage chest.



Image: A close-up view of the safety hinge mechanism on the HOOBRO Storage Bench, model BB22CW01, highlighting its design for controlled lid movement.

U-Shaped Cutout

Effortless opening/closing, enhanced ventilation.



Image: A close-up of the U-shaped cutout on the lid of the HOOBRO Storage Bench, model BB22CW01, designed for effortless and safe opening and closing.

Moving the Bench:

The bench features two metal pull rings on its sides for convenient relocation. When moving the bench, ensure the lid is closed and secured, then use the pull rings to lift and reposition the unit.

Metal Pull Rings

Easy to move the toy box with the dual pull rings.



Image: A close-up view of one of the metal pull rings located on the side of the HOOBRO Storage Bench, model BB22CW01, facilitating easy movement.

MAINTENANCE

- **Cleaning:** Wipe the surface with a dry cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish.
- **Environmental Conditions:** Do not expose the bench to prolonged direct sunlight or high humidity, as this can cause warping or discoloration of the particleboard and PVC materials.
- **Fastener Check:** Periodically inspect all screws and connections to ensure they are tight. Re-tighten if necessary to maintain stability and safety.

TROUBLESHOOTING

- **Lid not closing smoothly:** Check the alignment of the safety hinges and ensure no objects are obstructing the closing path.

- **Bench feels wobbly:** Verify that all assembly screws are securely tightened. If the issue persists, disassemble and reassemble carefully, ensuring all parts are correctly aligned.
- **Scratches or minor damage:** For minor scratches, a furniture repair marker matching the finish color can be used.

SPECIFICATIONS

Model Number	BB22CW01
Brand	HOOBRO
Product Dimensions (L x W x H)	43.3"L x 15.7"W x 19.7"H (110cm x 40cm x 50cm)
Material	Particleboard, MDF, PVC
Color	Black
Item Weight	16 Kilograms
Maximum Weight Recommendation	220 lb (100 Kilograms)
Assembly Required	Yes




Image: A diagram illustrating the dimensions of the HOOBRO Storage Bench, model BB22CW01, with measurements in both inches and centimeters.

PRODUCT VIDEOS

HOOBRO Storage Chest, 43.3" Storage Bench

Your browser does not support the video tag.

Video: An official HOOBRO video showcasing the 43.3" Storage Bench, highlighting its features and design.

HOOBRO Storage Chest, 43.3" Storage Bench, Wooden Toy Chest

Your browser does not support the video tag.

Video: An official HOOBRO video demonstrating the 43.3" Storage Bench, also referred to as a wooden toy chest, showcasing its storage capabilities.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official HOOBRO website. Keep your purchase receipt for any warranty claims.

