Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TECURS FR-Layout

TECURS FR-Layout 60% Mechanical Gaming Keyboard User Manual

Model: FR-Layout

Introduction

Thank you for choosing the TECURS FR-Layout 60% Mechanical Gaming Keyboard. This compact and powerful keyboard is designed for gamers and users who require a responsive and space-saving input device. Featuring clicky blue switches, customizable LED backlighting, and an ergonomic design, this manual will guide you through its setup, operation, and maintenance.

What's in the Box

- TECURS Mechanical Gaming Keyboard (FR-Layout)
- Instruction Manual
- USB-C Charging Cable
- Keycap Puller (may be included)
- Additional Red Keycap (may be included)

Product Features

- **60% Compact Design:** 61-key layout saves desktop space and enhances mouse movement flexibility.
- **Clicky Blue Switches:** Provides tactile feedback and an audible click for a responsive typing and gaming experience.
- **Ergonomic Design:** Three adjustable angles (6°/8°/12°) to reduce hand fatigue during extended use.
- **LED Backlighting:** 19 distinct lighting effects with adjustable brightness levels.
- **Anti-Ghosting:** Supports simultaneous multi-key presses without conflict.
- **Wide Compatibility:** Compatible with Windows 11/10/8/7/Vista/XP, PC, PS4, and PS5.
- **Wired Connectivity:** Reliable USB-C connection.

Setup

1. Connecting the Keyboard

1. Locate the USB-C port on the back of the keyboard.
2. Connect the provided USB-C cable to the keyboard's port.
3. Plug the other end of the USB-A connector into an available USB port on your computer, PS4, or PS5.
4. The keyboard should be automatically recognized by your system. No additional drivers are typically required.



Image: The keyboard is compatible with various operating systems and gaming consoles.

2. Adjusting Ergonomics

The keyboard features adjustable feet on the underside, allowing you to set the typing angle to one of three positions (6°, 8°, or 12°). Adjust these feet to find the most comfortable position for your wrists and hands, reducing strain during prolonged use.



Image: Adjustable feet allow for ergonomic customization.

Operating Instructions

1. Basic Key Functions (AZERTY Layout)

This keyboard features a standard French AZERTY layout. Due to its 60% compact size, some functions are accessed via the **Fn** (Function) key in combination with other keys. Refer to the keycaps for secondary functions, typically indicated by smaller icons or text.



Image: The compact 60% AZERTY layout.

2. LED Backlighting Control

The keyboard offers 19 different LED lighting modes and adjustable brightness. Use the following key combinations to control the backlighting:

- **Fn + * (PrtSc key):** Cycle through 19 different lighting modes.
- **Fn + ^ (Up Arrow):** Increase brightness level (6 levels).
- **Fn + v (Down Arrow):** Decrease brightness level (6 levels).
- **Ctrl + Alt + F10:** Produces the "@" symbol (specific to AZERTY layout).



Image: Key combinations for controlling LED lighting effects and brightness.

3. Anti-Ghosting Feature

The keyboard supports 61-key anti-ghosting, meaning that all 61 keys can be pressed simultaneously and registered correctly without any conflicts or missed inputs. This is crucial for fast-paced gaming where multiple commands are often executed at once.



Image: The 61-key anti-ghosting ensures all simultaneous key presses are registered.

Maintenance

1. Cleaning the Keyboard

- Disconnect the keyboard from your device before cleaning.
- Use a soft, dry cloth to wipe down the keycaps and keyboard surface.
- For deeper cleaning, use a can of compressed air to remove dust and debris from between the keycaps.
- If necessary, lightly dampen a cloth with water or a mild cleaning solution (avoid harsh chemicals) and gently wipe the surface. Ensure no liquid enters the keyboard.

2. Keycap Removal and Replacement

The keyboard comes with a keycap puller for easy removal and replacement of keycaps. This is useful for thorough cleaning or customizing your keyboard with different keycaps.

1. Gently place the keycap puller over the keycap you wish to remove.
2. Apply even pressure and pull upwards until the keycap detaches from the switch.
3. To replace, align the keycap with the switch stem and press down firmly until it clicks into place.



Image: Visible blue mechanical switches and removable keycaps.

TROUBLESHOOTING

- **Keyboard Not Responding:**
  - Ensure the USB-C cable is securely connected to both the keyboard and your device.
  - Try plugging the keyboard into a different USB port on your computer or console.
  - Test the keyboard on another device to rule out a system-specific issue.
  - Restart your computer or console.
- **LED Backlighting Not Working or Incorrect:**
  - Ensure the keyboard is properly connected and receiving power.

- Try cycling through the lighting modes using **Fn + ***.
- Adjust brightness levels using **Fn + ^** and **Fn + v**.

- **Keys Not Registering Correctly:**
  - Clean the affected key(s) using compressed air to remove any debris.
  - If a specific keycap is loose, remove and re-seat it firmly.
  - Ensure your operating system's keyboard settings are configured correctly for an AZERTY layout.

Specifications

Feature	Detail
Brand	TECURS
Model Name	TECURS Mechanical Gaming Keyboard
Model Number	FR-Layout
Keyboard Layout	AZERTY
Number of Keys	61
Switch Type	Clicky Blue Switches
Connectivity Technology	Wired (USB-C)
Backlighting	LED, 19 modes, 6 brightness levels
Compatible Devices	PC (Windows 11/10/8/7/Vista/XP), PS4, PS5
Ergonomic Features	Adjustable angles (6°/8°/12°)
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	White and Grey
Water Resistance Level	Not Water Resistant

Warranty and Support

TECURS products are manufactured to high-quality standards. For warranty information or technical support, please refer to the documentation included with your purchase or visit the official TECURS website. If you encounter any issues not covered in this manual, please contact TECURS customer service for assistance.

© 2026 TECURS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYKWZT8N

More documents and user manuals: **https://manuals.plus/**