LuxenHöme 22" Ceramic Bird Bath Fountain

LuxenHome 22" Ceramic Bird Bath Fountain Instruction Manual

Model: 22" Ceramic Bird Bath Fountain

Important Safety Information

Please read all instructions carefully before assembling and operating your LuxenHome Ceramic Bird Bath Fountain. Keep this manual for future reference.

- Ensure the fountain is placed on a firm, level surface to prevent tipping.
- Only use clean water in the fountain. Do not use chemicals or abrasive cleaners.
- Always unplug the fountain from the power outlet before performing any maintenance, cleaning, or when adding/removing water.
- Do not operate the pump dry. Ensure the water level is always sufficient to cover the pump.
- Keep the power cord away from heat sources, sharp edges, and moving parts.
- This product is designed for outdoor use. Ensure the power outlet is a GFCI (Ground Fault Circuit Interrupter) protected outlet.
- During freezing temperatures, drain all water and store the fountain indoors to prevent damage.
- Keep children and pets away from the fountain during operation and maintenance.

Package Contents

Verify that all components are present before beginning assembly:

- Ceramic Bird Bath Base
- Ceramic Top Bowl with Lotus-shaped Bubbler
- Water Pump with LED Light
- Water Hose/Tubing
- Instruction Manual (this document)

Setup Instructions

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.



Image: The LuxenHome 22-inch Ceramic Bird Bath Fountain, fully assembled and operating, showcasing its glazed jade green finish and lotus-shaped bubbler.

2. **Position the Pump:** Place the water pump inside the base of the fountain. Ensure the power cord exits through the designated opening in the base.
3. **Connect the Tubing:** Attach one end of the water hose/tubing to the outlet of the pump.



Image: A close-up view showing the clear water tubing connected to the pump outlet, positioned within the fountain's ceramic structure.

4. **Assemble the Top Bowl:** Carefully place the top bowl onto the base, guiding the other end of the water hose through the opening in the top bowl and connecting it to the inlet of the lotus-shaped bubbler. Ensure the top bowl is seated securely and level.



Image: The detachable top bowl of the fountain, showing the internal structure and the connection point for the water hose.

5. **Fill with Water:** Fill the fountain with distilled or clean tap water until the pump is fully submerged. Do not overfill.
6. **Plug In:** Connect the power cord to a GFCI-protected outdoor electrical outlet.

Setup Video Guide

Your browser does not support the video tag.

Video: An official LuxenHome video demonstrating the assembly and initial setup of the Aqua Glazed Ceramic Outdoor Waterfall Fountain.

Operating Instructions

1. **Initial Start-up:** After plugging in, the pump will begin circulating water, and the LED light will illuminate. It may take a few moments for water to flow consistently.



Image: The bird bath fountain positioned in a lush green garden, demonstrating its aesthetic appeal in an outdoor setting.

2. **Water Level:** Regularly check the water level. Due to evaporation and splashing, water levels will decrease over time. Refill as needed to ensure the pump remains submerged. Operating the pump dry can cause damage.
3. **Adjusting Water Flow:** The pump may have an adjustable flow rate switch. Refer to the pump's specific instructions if you wish to modify the water flow intensity.



Image: A detailed view of the lotus-shaped bubbler with water gently flowing and rippling across the top basin.

4. **Turning Off:** To turn off the fountain, simply unplug it from the power outlet.

Maintenance

Regular maintenance will ensure the longevity and optimal performance of your fountain.

- **Daily:** Check and replenish water levels to keep the pump submerged.
- **Weekly:** Clean the fountain basin and pump filter to prevent algae buildup and blockages. Unplug the fountain, remove the top bowl, and clean all surfaces with a soft brush and clean water. Rinse thoroughly.



Image: The top bowl of the fountain detached from the base, illustrating the ease of access for cleaning and maintenance.

- **Monthly:** For stubborn mineral deposits or algae, use a fountain cleaner specifically designed for ceramic fountains. Follow the product instructions carefully.
- **Winterization:** Before the first frost, completely drain all water from the fountain. Clean all components thoroughly. Disassemble the pump and store it indoors in a dry, frost-free location. Store the ceramic fountain base and top bowl indoors or cover them securely to protect from freezing temperatures and harsh weather.

Troubleshooting

Problem	Possible Cause	Solution
Fountain not running / Pump not working	Not plugged in or power outage. Low water level (pump not submerged). Pump or tubing clogged. Pump impeller damaged.	Check power connection and outlet. Add water until pump is fully submerged. Unplug, clean pump and tubing. Inspect pump impeller for damage; replace pump if necessary.

Problem	Possible Cause	Solution
Water flow is weak or inconsistent	Low water level. Pump or tubing partially clogged. Kink in tubing. Pump flow rate set too low.	Add water. Unplug, clean pump and tubing. Straighten tubing. Adjust pump flow rate (if applicable).
Water is leaking from the fountain	Improper assembly of top bowl. Cracked ceramic. Water level too high, causing splashing over edges.	Ensure top bowl is seated correctly and level. Inspect ceramic for damage. Contact support if damaged. Reduce water level slightly.
LED light not working	Light connection loose. LED bulb failure.	Check all light connections. Contact support for replacement parts.

Specifications

Feature	Detail
Product Dimensions	12.99" L x 12.99" W x 22.05" H
Material	Ceramic
Color	Aqua Green
Power Source	Corded Electric
Special Feature	Built-in LED Light and Pump
GTIN (UPC)	810129481167
Brand	LuxenHöme



Image: Diagram showing the height (22.05 inches) and diameter (12.99 inches) of the ceramic bird bath fountain.

Warranty and Support

LuxenHome products are manufactured with quality and care. For specific warranty details, please refer to the documentation included with your purchase or contact LuxenHome customer service directly.
If you encounter any issues or require assistance with your product, please contact LuxenHome customer support through their official website or the retailer where the product was purchased. Please have your model number (22" Ceramic Bird Bath Fountain) and GTIN (810129481167) ready when contacting support.
For more information, visit the official LuxenHome store:LuxenHome Store

© 2026 LuxenHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question