

## PISEN 30W USB-C Fast Charger with Type-C to L Cable

# PISEN 30W USB-C Fast Charger with 4FT Type-C to L Cable User Manual

Model: 30W USB-C Fast Charger with Type-C to L Cable

Brand: PISEN

## 1. INTRODUCTION

---

Thank you for choosing the PISEN 30W USB-C Fast Charger with 4FT Type-C to L Cable. This product is designed to provide efficient and safe charging for a wide range of compatible devices. Please read this manual carefully before use to ensure optimal performance and safety.

## 2. WHAT'S INCLUDED

---

- 1 x PISEN 30W USB-C Fast Charger Block
- 1 x 4FT USB-C to L Cable
- 1 x Instruction Manual (this document)

# 30W PD Fast Charger



30min charging

≈ **60%**

iPhone15 Pro

Image: PISEN 30W USB-C Fast Charger with included 4FT Type-C to L cable.

### 3. PRODUCT FEATURES

- **30W USB-C Wall Charger:** Supports multiple fast charging protocols for wide compatibility.
- **Fast Charging:** Capable of charging an iPhone 15 Pro from 0% to 60% in approximately 30 minutes.
- **4FT USB-C to L Cable:** Included cable supports PD 3.0 fast charging and data transfer up to 480Mbps. Made from bio-based materials with a 20,000-bend lifespan.
- **Smart Chips:** Both the charger block and cable are equipped with smart chips for efficient and safe charging.
- **Compact Design:** Portable and pocket-sized for convenient travel.



Image: Close-up of the PISEN 30W USB-C Fast Charger block, highlighting its compact design.

## 4. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the PISEN 30W USB-C Fast Charger and the 4FT USB-C to L Cable from the packaging.
2. **Inspect:** Check the charger and cable for any visible damage. Do not use if damaged.
3. **Connect Cable:** Plug the USB-C end of the provided cable into the USB-C port on the charger block.
4. **Plug into Wall:** Insert the charger block into a standard wall outlet.
5. **Connect Device:** Plug the Lightning end of the cable into your compatible device (e.g., iPhone, iPad).



Image: PISEN 30W USB-C Fast Charger in use, charging a device.

## 5. OPERATING INSTRUCTIONS

- Once connected, your device should automatically begin charging.
- The charger is designed for fast charging. Charging speed may vary based on your device's battery level and specifications.
- For optimal performance, ensure your device supports USB Power Delivery (PD) 3.0.
- Disconnect the charger from the wall outlet when not in use.



Note: Data based on internal testing.  
The included cable is a USB-C to lightning cable.  
To charge an iPhone with a USB-C port, use a  
USB-C to USB-C cable.

Image: PISEN 30W USB-C Fast Charger connected to an iPhone, showing fast charging capability.

## 6. SAFETY INFORMATION

The PISEN 30W USB-C Fast Charger is built with multiple safety systems to protect your devices:

- **Short Circuit Protection:** Prevents damage from electrical shorts.
- **Overload Protection:** Safeguards against excessive current draw.
- **Over Temperature Protection:** Monitors and regulates internal temperature to prevent overheating.
- **Overvoltage Protection:** Protects devices from voltage spikes.

### Important Safety Precautions:

- Do not expose the charger to liquids, extreme temperatures, or direct sunlight.
- Do not disassemble or attempt to repair the charger.
- Keep out of reach of children.
- Use only with compatible devices and cables.

Video: Official video demonstrating the PISEN 30W USB-C Fast Charger's features and usage, including safety aspects.

## 7. SPECIFICATIONS

<b>Brand</b>	PISEN
<b>Model Number</b>	30W charger + C to L cable
<b>Wattage</b>	30 watts
<b>Connector Type</b>	USB Type C
<b>Compatible Devices</b>	Cellular Phones, iPhone 16/15/14/13/12/11/XR/XS/X/8 Series, iPad Series, AirPods Series, MacBook Air M1 M2
<b>Included Components</b>	30W USB C charger, 4FT USB C to L cable
<b>Special Feature</b>	Fast Charging
<b>Color</b>	White

<b>Input Voltage</b>	240 Volts
<b>Total USB Ports</b>	1
<b>Item Weight</b>	4 ounces
<b>Package Dimensions</b>	5.47 x 3.98 x 1.34 inches

## 8. TROUBLESHOOTING

---

If you encounter any issues with your PISEN 30W USB-C Fast Charger, please refer to the following common solutions:

- **Device not charging:**
  - Ensure the charger is securely plugged into a working wall outlet.
  - Verify that the USB-C to L cable is firmly connected to both the charger and your device.
  - Try using a different wall outlet.
  - Test with a different compatible cable or device to isolate the issue.
- **Slow charging:**
  - Confirm your device supports PD 3.0 fast charging. Older devices may charge at a slower rate.
  - Ensure the cable is not damaged. A damaged cable can reduce charging efficiency.
  - Avoid using the device heavily while charging, as this can slow down the charging process.
- **Charger is hot:**
  - It is normal for the charger to become warm during fast charging. However, if it becomes excessively hot to touch, disconnect it immediately.
  - Ensure adequate ventilation around the charger. Do not cover it.

## 9. WARRANTY AND SUPPORT

---

PISEN products come with a standard warranty. For specific warranty details, returns, or technical support, please refer to the contact information provided on the product packaging or visit the official PISEN website. Keep your purchase receipt for warranty claims.

PISEN is committed to enhancing lifestyles with technology, offering quality-driven products that blend warmth and innovation. Through continuous innovation and user-centric services, we strive to create unique products and services, sharing the joy of boundless living empowered by technology.