

YITAHOME MAYIHIA sGM

YITAHOME Outdoor Grill Cart Pizza Oven Table User Manual

Model: MAYIHIA sGM

1. INTRODUCTION

Thank you for choosing the YITAHOME Outdoor Grill Cart Pizza Oven Table. This versatile and durable cart is designed to enhance your outdoor cooking and entertaining experience. Featuring a stainless steel top, adjustable shelving, and convenient accessories, it serves as an ideal prep station, serving cart, or storage solution for your patio, garden, or BBQ area. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your product.

2. SAFETY INFORMATION

- **Pinch Points:** Use caution when extending and retracting the drop leaf to avoid pinch points.
- **Stability:** Be mindful of the surface you are using the cart on to prevent tipping. Ensure the locking wheels are engaged when the cart needs to remain stationary.
- **Weather Protection:** Protect the cart from extreme weather conditions when not in use to prolong its lifespan.
- **Weight Capacity:** Do not exceed the stated weight capacities for the tabletop and shelves to prevent damage or injury.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact YITAHOME customer support.

- Main Cart Frame Components
- Stainless Steel Tabletop with Drop Leaf
- Adjustable Shelves (2)
- 360° Swivel Casters (4, 2 with locks)

- Removable Spice Rack
- Sturdy Hooks (8)
- Bottle Opener
- Trash Bag Holder
- Assembly Hardware (screws, bolts, tools)
- Assembly Instructions



Figure 3.1: A technical diagram illustrating the overall dimensions of the grill cart (35.4"D x 31.5"W x 34.3"H) and the maximum weight capacities for the top surface (110 lbs) and each shelf (45 lbs).

4. ASSEMBLY INSTRUCTIONS

The YITAHOME Grill Cart is designed for straightforward assembly with pre-labeled parts and clear instructions. While assembly is generally easy, careful attention to the visual instructions provided in the package is beneficial for

a smooth process.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the package contents list and the assembly diagram to ensure everything is present and undamaged.
2. **Attach Casters:** Secure the four 360° swivel casters to the bottom of the cart frame. Ensure that the two lockable casters are positioned on the same side for easy access.
3. **Assemble Frame:** Connect the vertical and horizontal frame components according to the instructions, using the provided hardware. Do not fully tighten all screws until the entire frame is loosely assembled to allow for adjustments.
4. **Install Shelves:** Slide the two mesh shelves into the designated slots on the frame. The middle shelf is adjustable to three different height levels. Choose your desired height before securing.
5. **Attach Tabletop:** Secure the stainless steel tabletop to the top of the frame. Ensure the drop leaf mechanism is correctly aligned.
6. **Install Accessories:** Attach the removable spice rack, eight sturdy hooks, bottle opener, and trash bag holder to the designated areas on the cart.
7. **Final Tightening:** Once all components are in place and aligned, systematically tighten all screws and bolts to ensure the cart is stable and secure.



VERSATILE STAINLESS STEEL TABLETOP EXTENDER

Conveniently expand your table surface area for elegant food displays at gatherings.



Figure 4.1: This image highlights the cart's four 360° swivel casters, two of which are lockable for stability, and illustrates the three adjustable height levels for the middle shelf.



Figure 4.2: This detailed view showcases the convenient organizational features of the cart, including a removable spice rack, eight sturdy hooks, a built-in bottle opener, and a practical trash bag holder.

5. OPERATING INSTRUCTIONS

5.1 Using the Drop Leaf

The drop leaf extends the tabletop surface, providing additional space for food preparation or serving. To extend, gently lift the leaf until it is level with the main tabletop. To retract, lift slightly and then carefully lower the leaf until it rests in its folded position. Always ensure hands are clear of the hinge mechanism.

LOCKABLE WHEELS

Make Relocation Easy



Four 360° Swivel Casters, Two with Locks
Effortlessly roll and secure in place.



ADJUSTABLE SHELF

Three height settings to accommodate
items of various sizes.

Figure 5.1: The image demonstrates the drop leaf feature, which expands the tabletop surface for additional preparation or serving space, and how it folds down for compact storage.

5.2 Mobility and Locking Wheels

The cart is equipped with four 360° swivel casters for easy movement. To move the cart, simply push it to your desired location. To secure the cart in place, press down on the locking levers on the two designated casters until they click into the locked position. To unlock, lift the levers.

5.3 Adjusting Shelf Height

The middle shelf can be adjusted to three different height levels to accommodate items of various sizes. To adjust, carefully lift the shelf, reposition it to the desired height, and ensure it is securely seated in the frame's grooves.

5.4 Using Integrated Accessories

- **Spice Rack:** The removable spice rack can be placed on the pegboard for easy access to seasonings.
- **Hooks:** Use the eight sturdy hooks to hang grilling tools, towels, or other utensils.
- **Bottle Opener:** The built-in bottle opener provides a convenient way to open beverages.
- **Trash Bag Holder:** Utilize the trash bag holder to keep a waste bag readily available for easy cleanup during

outdoor activities.



Figure 5.2: This image displays the YITAHOME Outdoor Grill Cart in use, featuring a grill on its stainless steel top, prepared food, and various items stored on its shelves and attached accessories.



Figure 5.3: The grill cart is shown with a pizza oven placed on its stainless steel surface, demonstrating its versatility for different outdoor cooking appliances.

6. MAINTENANCE AND CARE

Regular maintenance will help preserve the appearance and functionality of your grill cart.

- **Cleaning the Stainless Steel Top:** Wipe the stainless steel surface with a soft cloth and a mild, non-abrasive cleaner. For stubborn stains, use a stainless steel cleaner. Always wipe in the direction of the grain.
- **Cleaning Metal Frame and Shelves:** Clean the metal frame and shelves with a damp cloth and mild soap. Dry thoroughly to prevent rust.
- **Weather Protection:** While designed for outdoor use, it is recommended to cover the cart or store it indoors during prolonged periods of harsh weather, such as heavy rain, snow, or extreme heat, to prevent premature wear and tear.
- **Wheel Maintenance:** Periodically check the casters for debris or hair that may impede movement. Clean as necessary and apply a small amount of silicone spray if the wheels become stiff.
- **Hardware Check:** Periodically inspect all screws and bolts to ensure they remain tight. Retighten as needed to

maintain stability.

7. TROUBLESHOOTING

If you encounter issues with your YITAHOME Grill Cart, refer to the following common troubleshooting tips:

- **Cart is Unstable/Wobbly:**
 - Ensure all assembly hardware (screws, bolts) are fully tightened.
 - Verify that the cart is on a flat, level surface.
 - Check that the shelves are correctly seated in their designated slots.
- **Wheels Not Rolling Smoothly or Popping Off:**
 - Inspect wheels for any trapped debris (e.g., dirt, hair) and clean them.
 - Ensure the casters are securely attached to the cart frame. If they are popping off, re-attach them firmly, ensuring the mounting mechanism is fully engaged.
 - Apply a silicone-based lubricant to the wheel axles if they are stiff.
- **Drop Leaf Not Operating Smoothly:**
 - Check for any obstructions in the hinge mechanism.
 - Ensure the leaf is properly aligned with the main tabletop.
- **Missing or Damaged Parts:**
 - Refer to the package contents list. If parts are missing or damaged upon arrival, contact YITAHOME customer support immediately for assistance.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	35.4"D x 31.5"W x 34.3"H
Shelf Type	Tiered Shelf
Frame Material	Metal
Brand	YITAHOME
Color	Black
Style	w/ Folding Extension Board
Assembly Required	Yes
Number of Shelves	3
Item Weight	37 pounds
UPC	197839911864
Model Number	MAYIHIAAsGM
Included Components	Grill Cart

9. WARRANTY AND SUPPORT

YITAHOME is committed to providing high-quality products. For any questions regarding your YITAHOME Outdoor Grill Cart Pizza Oven Table, including warranty information, missing parts, or technical support, please contact YITAHOME customer service directly. Please have your model number (MAYIHIAAsGM) and purchase details ready when contacting support.

You can typically find contact information on the YITAHOME official website or through the retailer where you purchased the product.