

Leyoue LE-USB029

Leyoue Electric Wax Melt Warmer with LED Light

MODEL: LE-USB029 - USER MANUAL

1. Safety Information

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or injury.

- Keep out of reach of children and pets.
- Do not place the warmer on or near flammable materials.
- Ensure the warmer is placed on a stable, heat-resistant surface.
- Do not immerse the warmer in water or any other liquid.
- Unplug the warmer when not in use or before cleaning.
- Do not touch the heating plate when the warmer is in operation, as it will be hot.
- Use only wax melts designed for electric warmers. Do not add water or essential oils directly to the heating plate.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. Product Overview

The Leyoue Electric Wax Melt Warmer features a unique forest design, PTC heating technology, and a 7-color LED changing light. It is designed to safely melt wax melts to release fragrance into your home or office environment.



Image: The Leyoue Electric Wax Melt Warmer, showcasing its forest design and a blue LED light. Blue wax cubes are visible in the top silicone tray.

Components:

- **Main Unit:** The decorative metal housing with the forest design.
- **PTC Heating Plate:** Located inside the main unit, responsible for melting the wax.
- **Silicone Wax Tray:** A removable, non-stick tray for holding wax melts.
- **LED Light:** Integrated lighting system with 7 color options.
- **Power Cord with Control Button:** For powering the unit and controlling functions.

3. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the warmer on a flat, stable, and heat-resistant surface, away from drafts, flammable materials,

and out of reach of children and pets.

3. **Insert Silicone Tray:** Ensure the silicone wax tray is properly seated on the PTC heating plate inside the main unit.
4. **Connect Power:** Plug the power cord into a standard electrical outlet.

4. Operating Instructions

1. **Add Wax Melts:** Place one or more wax melt cubes into the silicone tray. Do not overfill.
2. **Power On:** Press the control button on the power cord to turn on the warmer. The LED light will illuminate, and the heating plate will begin to warm up.
3. **Select LED Light Mode:** Subsequent presses of the control button will cycle through the 7-color LED light options:
 - Press once for automatic color changing mode.
 - Press again to fix the light to a specific color.
 - Continue pressing to cycle through the available colors.
 - Press until the light turns off if you prefer to use the warmer without the LED light.
4. **Fragrance Release:** The PTC heating plate will melt the wax, releasing fragrance into the room. This process is flameless and smoke-free.
5. **Power Off:** To turn off the warmer, press the control button until both the heating and the LED light are off, or unplug the unit from the electrical outlet.



Image: A row of Leyoue wax warmers, each displaying a different LED color, illustrating the 7-color lighting feature.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and longevity of your wax warmer.

1. **Unplug:** Always unplug the warmer from the power outlet and allow it to cool completely before cleaning.
2. **Remove Used Wax:** Once the wax has cooled and solidified, gently remove the silicone wax tray from the warmer. The flexible silicone allows for easy removal of solidified wax by simply flexing the tray.
3. **Clean Silicone Tray:** Wash the silicone tray with warm, soapy water. Rinse thoroughly and dry completely before reuse.
4. **Clean Main Unit:** Wipe the exterior of the warmer with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
5. **Storage:** Store the warmer in a cool, dry place when not in use.

Silicone Wax Warmer Liners

Easy to disassemble and clean



Image: Hands demonstrating the easy removal of the silicone wax tray from the warmer, highlighting the convenience of cleaning.

6. Troubleshooting

Problem	Possible Cause	Solution
Warmer does not turn on.	Not plugged in; power outlet malfunction; damaged cord.	Ensure plug is fully inserted. Test outlet with another device. Inspect cord for damage; if damaged, discontinue use and contact support.
Wax is not melting.	Warmer not on; too much wax; incorrect wax type.	Verify warmer is powered on. Reduce the amount of wax. Ensure you are using wax melts designed for electric warmers.

Problem	Possible Cause	Solution
No fragrance release.	Wax has lost its scent; wax not melting properly.	Replace old wax melts with new ones. Refer to 'Wax is not melting' solution.
LED light not working.	Light mode off; internal malfunction.	Press the control button to cycle through light modes. If still not working, contact support.

7. Specifications

- **Model Number:** LE-USB029
- **Product Dimensions:** 3.7 x 3.7 x 5.5 inches
- **Item Weight:** 14.9 ounces
- **Heating Technology:** PTC (Positive Temperature Coefficient)
- **Lighting:** 7-Color LED Changing Light
- **Power Source:** Corded Electric
- **Manufacturer:** Leyoue

BRING NATURE INDOORS

Warmth and
tranquility in
every glow.



Image: The Leyoue Electric Wax Melt Warmer with its key dimensions (5.5 inches height, 3.7 inches width) indicated.

8. Warranty and Support

Leyoue products are manufactured with quality and care. For warranty information, product support, or to purchase replacement parts, please visit the official Leyoue store or contact customer service.

Leyoue Store: [Visit the Leyoue Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question