Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- , JVD /
- > JVD Riviera 2200W Professional Hair Dryer User Manual

JVD 8222194-MB

JVD Riviera 2200W Professional Hair Dryer User Manual

Model: 8222194-MB

INTRODUCTION

Thank you for choosing the JVD Riviera 2200W Professional Hair Dryer. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new hair dryer. Please read it thoroughly before first use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep away from water. Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:
- An appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air

openings may be blocked. Keep the air openings free of lint, hair, and the like.

- · Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.
- While using the appliance, keep your hair away from the air inlets.

PRODUCT OVERVIEW

The JVD Riviera Professional Hair Dryer is designed for efficient and effective hair drying with advanced features.



Key Components:

- 1. Nozzle/Concentrator: Directs airflow for precise styling.
- 2. Air Outlet: Where the heated air exits.
- 3. **Temperature Settings Switch:** Controls heat levels (3 settings).
- 4. Airflow Settings Switch: Controls fan speed (2 settings).
- 5. Cold Shot Button: Provides a burst of cool air to set styles.
- 6. Trigger Switch: Power on/off control.
- 7. Handle: Ergonomic grip.
- 8. **Power Cord:** 2-meter straight cord with VDE plug.
- 9. Removable Back Filter: For easy cleaning and maintenance.
- 10. Air Inlet: Where air is drawn into the dryer.



Image 2: The JVD Riviera Hair Dryer shown with an optional wall-mount holder, highlighting its compact storage capability.

SETUP

- 1. **Unpacking:** Carefully remove the hair dryer and all accessories from the packaging. Retain packaging for storage or future transport.
- 2. Inspect: Check the appliance for any signs of damage. Do not use if damaged.
- 3. **Power Connection:** Ensure your power outlet matches the voltage requirements of the hair dryer (220-240V). Plug the VDE plug into a suitable electrical outlet.
- 4. **Attach Nozzle:** If desired, attach the concentrator nozzle to the front of the dryer by aligning it with the air outlet and pushing it firmly into place.

OPERATING INSTRUCTIONS

Follow these steps for optimal hair drying and styling:

- 1. Power On: Press the trigger switch to turn on the hair dryer.
- 2. **Select Airflow:** Use the airflow settings switch to choose between 2 airflow speeds:
 - Low: For gentle drying or styling.
 - High: For fast drying.
- 3. **Select Temperature:** Use the temperature settings switch to choose from 3 heat levels:
 - Cool: For delicate hair or setting styles.
 - Warm: For general drying.
 - Hot: For fast drying of thick or wet hair.
- 4. **Ionic Function:** The in-built negative ionizer automatically activates when the dryer is on, helping to reduce frizz and enhance shine.
- 5. **Cold Shot:** Press and hold the cold shot button for a burst of cool air. This helps to set your hairstyle and add shine. Release the button to return to the selected heat setting.
- 6. Drying Technique:
 - For best results, towel-dry hair to remove excess water before using the dryer.
 - Divide hair into sections.
 - Direct the airflow from roots to ends.
 - Keep the dryer moving to prevent concentrating heat in one area.
- 7. Power Off: After use, press the trigger switch to turn off the hair dryer and unplug it from the power outlet.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your hair dryer.

- 1. **Always Unplug:** Before cleaning, ensure the hair dryer is unplugged from the power outlet and has completely cooled down.
- 2. Clean Exterior: Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- 3. Clean Removable Back Filter:
 - Gently twist or pull off the removable back filter cover (refer to Image 3 for typical location).
 - · Remove any accumulated lint, dust, or hair from the filter screen using a soft brush or by hand.
 - Rinse the filter cover if necessary, ensuring it is completely dry before reattaching.
 - · Reattach the filter cover securely.



Image 3: Rear view of the JVD Riviera Hair Dryer, showing the air inlet and the location of the removable back filter for cleaning.

4. **Storage:** When not in use, store the hair dryer in a cool, dry place. Do not wrap the power cord tightly around the appliance, as this can damage the cord.

TROUBLESHOOTING

If you encounter issues with your JVD Riviera Hair Dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dryer does not turn on.	Not plugged in; power outlet issue; damaged cord/plug.	Ensure the dryer is securely plugged into a working outlet. Check for power at the outlet. Inspect cord and plug for damage; if damaged, do not use and contact support.
Low airflow or overheating.	Blocked air inlet/filter.	Unplug the dryer and allow it to cool. Clean the removable back filter as described in the Maintenance section. Ensure air inlets are clear.

Problem	Possible Cause	Solution
Dryer suddenly stops during use.	Overheat protection activated.	Unplug the dryer and allow it to cool for at least 10-15 minutes. Clean the air filter. Re-plug and try again. If the problem persists, contact support.
Hair is still frizzy.	Improper drying technique; very humid environment.	Ensure you are using the ionic function (it's automatic). Use the cold shot to seal the hair cuticle. Consider using anti-frizz hair products.

SPECIFICATIONS

Model Number	8222194-MB
Power	2200 Watts
Motor Type	AC Motor
Voltage	220-240V (Standard for India)
Special Features	Ionic Technology, 3 Temperature Settings, 2 Airflow Settings, Cold Shot, Removable Back Filter, Trigger Switch
Cord Length	2 meters (straight cord)
Plug Type	VDE Plug
Material	Plastic
Color	Matte Black
Dimensions (LxWxH)	12.7 x 19.8 x 14.2 cm
Item Weight	980 g
Manufacturer	JVD
Country of Origin	China

WARRANTY AND SUPPORT

For information regarding warranty coverage, service, or technical support, please refer to the warranty card included with your product or contact JVD customer service. You may also visit the official JVD website for further assistance.

Note: Extended warranty plans may be available from third-party providers. Please check details with your retailer.

© JVD. All rights reserved. Information in this manual is subject to change without notice.

JVD BRITTONY PRISE 230V Hair Dryer - Instructions and Safety

Official instructions and safety precautions for the JVD BRITTONY PRISE 230V hair dryer, designed for hotel use. Includes installation, maintenance, and technical specifications.



JVD High Speed Automatic Hand Dryer - Operating Instructions and Parts Manual

Comprehensive guide for the JVD High Speed Automatic Hand Dryer (Model JVD-HC120), including installation, operation, maintenance, safety warnings, technical specifications, and a detailed parts list for troubleshooting and repairs.



JVD EXP'AIR Hand Dryer Installation and User Manual

Official installation and user manual for the JVD EXP'AIR hand dryer. Includes safety, installation, operation, maintenance, and technical specifications for commercial use. Available in multiple languages.



JVD DR50N-GD Glass Door Minibar | Technical Specifications & Features

Explore the JVD DR50N-GD, a 50-liter heat-absorption glass door minibar. This compact unit features a lock, LED interior light, and energy-efficient operation, perfect for keeping beverages cool. Detailed specifications and dimensions are provided.



JVD WAVE Stereo Alarm Clock, Bluetooth, Black - Model 8661691

Discover the JVD WAVE Stereo Alarm Clock (Model 8661691) in Black. Features wireless & USB charging, Bluetooth connectivity, FM radio, light dimming, and hotel mode functions. Compact dimensions and versatile features make it ideal for various settings.



Manuel d'utilisation JVD Shield : Purificateur d'air

Guide complet pour l'installation, l'utilisation et l'entretien du purificateur d'air JVD Shield. Découvrez les modes de fonctionnement, les précautions de sécurité et les caractéristiques techniques.