Gisaae LK-8330

Gisaae Head Shavers for Bald Men - Instruction Manual

Model: LK-8330

Gisaae

Introduction and Overview

This manual provides comprehensive instructions for the Gisaae Upgraded 7D Electric Razor, designed for bald men. It covers product features, setup, operation, maintenance, troubleshooting, and technical specifications to ensure optimal performance and longevity of your device.

The Gisaae Head Shaver is a versatile grooming tool equipped with a 7-blade system, offering precision and flexibility for both head and beard shaving. Its waterproof design allows for convenient wet and dry use, and the high-performance battery ensures extended operation.



Figure 1: Gisaae Upgraded 7D Electric Razor with included accessories.

Product Features

- **7D Electric Shaver:** Equipped with 7 shaving heads that adapt to facial contours for increased shaving area and efficiency. Features double-layer durable blades for accurate and safe hair capture, and a smart sensor system to prevent hair pinching.
- **Precision and Flexibility:** Innovative design for easy operation, fitting perfectly in hand for access to all areas of the face and head. Delivers close shaves and detailed trims.
- **High Performance Battery:** 800mAh battery provides up to 90 minutes of continuous use after a 2-hour charge. LED display indicates charge level. Portable for home or travel use.
- **IPX7 Waterproof Design:** Supports wet and dry shaving with creams or foams. Safe for use in the shower. Detachable head for easy rinsing under tap water.
- **Professional Shaving Kit:** Includes 7D shaving head, hair trimmer, 3 guide combs (3/5/7mm), USB cable, and

cleaning brush.



Figure 2: Visual representation of key product features.



Figure 3: Close-up of shaver head and its core functionalities.

Setup

1. **Unboxing:** Carefully remove all components from the packaging: the 7D shaving head, hair trimmer, 3 guide combs (3/5/7mm), USB cable, cleaning brush, and the main shaver body.
2. **Initial Charge:** Fully charge the shaver before its first use. Connect the USB cable to the shaver and a compatible USB power source. The LED display will indicate the charging status and battery level. A full charge takes approximately two hours.
3. **Attaching Heads:** The shaver body allows for interchangeable heads. To attach the 7D shaving head or the hair trimmer, align the head with the main body and gently push until it clicks securely into place.



Figure 4: For longer hair, use the hair trimmer attachment first to shorten hair before using the 7D shaving head.

Operating Instructions

1. **Power On/Off:** Press the power button to turn the shaver on or off. The LED display will show the remaining battery percentage.
2. **Wet Shave:** For a wet shave, wet the shaving head and apply shaving cream or gel to your skin. This can provide a smoother, more comfortable shave and reduce irritation.
3. **Dry Shave:** For a dry shave, ensure your skin is clean and dry.
4. **Shaving Technique:** Move the shaver gently over the skin in circular motions. The 7D floating heads are designed to automatically adapt to the contours of your head and face, ensuring a close and efficient shave.

5. **Using Attachments:**
    - **Hair Trimmer:** Attach the hair trimmer head for longer hair or to define sideburns and beard lines. Use the included guide combs (3/5/7mm) for desired hair length.
    - **Nose/Ear Trimmer (if applicable):** If your kit includes a nose/ear trimmer, attach it for precise trimming in sensitive areas.



Figure 5: The shaver supports both wet and dry shaving for versatile grooming.

Your browser does not support the video tag.

Video 1: Demonstration of the Gisaae Head Shaver's 7 blades providing a close shave. This video illustrates the shaver's efficient operation and how it conforms to facial and head contours for a smooth finish.

Maintenance

1. **Daily Cleaning:** After each use, rinse the shaving head directly under running tap water. The head is detachable for thorough cleaning.
2. **Deep Cleaning:** Periodically, or when performance decreases, remove the 7D blade head. First, use your nails to open the 6 outer blades, then turn the middle blade slightly to the right to detach it. Rinse all blades and the internal components under water. Use the provided cleaning brush to remove any stubborn hair or debris. Ensure all parts are dry before reassembling.
3. **Storage:** Store the shaver in a cool, dry place. Use the protective cover for the shaving head when not in use to prevent damage.



Figure 6: Step-by-step guide for disassembling and cleaning the shaver head under running water.

Your browser does not support the video tag.

Video 2: This video demonstrates the ergonomic design and cleaning process of the Gisaae Head Shaver, showing how to easily detach and rinse the blades.

Troubleshooting

Problem	Possible Cause	Solution
Shaver not turning on.	Low battery; travel lock engaged.	Charge the shaver fully. Long press the power button for 3 seconds to unlock travel mode.
Poor shaving performance.	Blades are dull or clogged with hair; insufficient charge.	Clean the shaving head thoroughly as per maintenance instructions. Ensure the shaver is fully charged.
Skin irritation after shaving.	Dry shaving on sensitive skin; applying too much pressure; dull blades.	Try wet shaving with shaving cream/gel. Use light pressure. Ensure blades are clean and sharp.
Shaver making unusual noise.	Debris caught in blades; damaged component.	Clean the shaver head thoroughly. If noise persists, contact customer support.

Specifications

Model Name: LK-8330

Product Dimensions: 4.33 x 3.15 x 3.15 inches

Item Weight: 9.91 ounces

Power Source: Battery Powered (1 Lithium Ion battery required)

Battery Capacity: 800mAh (approx. 90 minutes run time after 2 hours charge)

Waterproof Rating: IPX7 (100% Waterproof)

UPC: 671891719090

Manufacturer: WENZHOU LIKE ELECTRIC CO.,LTD

Warranty and Support

For warranty information, product support, or to purchase replacement parts, please visit the official Gisaae website or contact their customer service directly. Refer to the product packaging for specific contact details.

Safety Information: Please do not place the device in fire as it contains batteries.

© 2023 Gisaae. All rights reserved.