Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zunate Zunategkc29r0uvn-11

Zunate Jet Dry Mini Blower User Manual

Model: Zunategkc29r0uvn-11
Brand: Zunate

1. Introduction

Thank you for choosing the Zunate Jet Dry Mini Blower. This compact and powerful device is designed for various cleaning and drying tasks, offering high-speed airflow in a portable form factor. Please read this manual carefully before using the product to ensure safe and efficient operation.



Image 1.1: Zunate Jet Dry Mini Blower, main product view.

2. Safety Information

To prevent injury or damage to the product, always observe the following safety precautions:

- Keep the blower away from water and moisture.
- Do not operate the blower near flammable liquids or gases.
- Avoid directing the airflow directly at people or animals, especially eyes.
- Do not insert objects into the air inlet or outlet.
- Keep out of reach of children.
- Use only the provided charging cable and a compatible power adapter.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Store the device in a cool, dry place when not in use.

3. Package Contents

Verify that all items are present in the package:

- 1 x Zunate Jet Dry Mini Blower
- 1 x Nozzle
- 1 x Storage Bag
- 1 x User Manual (this document)





Image 3.1: Package contents including the blower, nozzle, and storage bag.

4. Product Overview

The Zunate Jet Dry Mini Blower is a compact and lightweight device designed for efficient cleaning and drying. It features a high-speed motor capable of 110,000 RPM, delivering an airflow of 25m/s.

Key Features:

- **Compact and Lightweight:** Designed for portability and ease of use in various settings.
- **High-Speed Airflow:** Delivers 25m/s airflow at a maximum rotation speed of 110,000 RPM for efficient cleaning.
- **Quick Charging:** Equipped with a Type-C charging interface for fast and convenient recharging.
- **Durable Construction:** Made from high-hardness, high-temperature resistant materials for longevity and low heat production.
- **Multipurpose Performance:** Suitable for cleaning outdoor equipment, vehicles, computers, keyboards, cameras, furniture, windows, plants, and removing pet hair.



Image 4.1: Front view of the Zunate Jet Dry Mini Blower, highlighting the air outlet.






Image 4.2: Examples of the blower's versatile applications, including cleaning floors, car interiors, and general dusting.

5. Setup

The Zunate Jet Dry Mini Blower comes pre-assembled. The only setup required is attaching the nozzle.

1. Unpack the blower and its accessories from the storage bag.
2. Align the nozzle with the air outlet on the front of the blower.
3. Gently push and twist the nozzle until it is securely attached. Ensure it clicks into place or feels firm to prevent it from detaching during operation.

6. Charging

Before first use, fully charge the Zunate Jet Dry Mini Blower.

1. Locate the Type-C charging port on the device.
2. Connect the provided Type-C charging cable to the blower and a compatible 15W Type-C power adapter (not included).
3. The charging indicator light will display blue and red colors during charging.
4. A full charge typically takes approximately 3 hours. Once fully charged, the indicator light will turn red.
5. If the battery voltage is low, the indicator light will display green, signaling that charging is required before use.

The built-in lithium battery has a capacity of 4000mAh and provides approximately 15 minutes of operation at maximum throttle when fully charged.

7. Operation

Follow these steps to operate your Zunate Jet Dry Mini Blower:

1. Ensure the blower is fully charged.
2. To turn on the device, **press and hold the power button for 2 seconds**. This prevents accidental activation.
3. Once powered on, the blower will start operating. You can adjust the airflow intensity if a control knob is present (refer to product images for specific controls).
4. Direct the nozzle towards the area you wish to clean or dry.
5. To turn off the device, **press and hold the power button for 2 seconds** again.

For efficient cleaning, use instantaneous key pressing to achieve maximum speed movement, allowing for quick task completion.

8. Maintenance

Proper maintenance ensures the longevity and optimal performance of your blower.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the blower. Do not use harsh chemicals or abrasive cleaners. Ensure the air inlet and outlet are free from dust and debris.
- **Storage:** When not in use, store the blower in its provided storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** For long-term storage, it is recommended to charge the battery to about 50% every few months to maintain battery health.

9. Troubleshooting

If you encounter issues with your Zunate Jet Dry Mini Blower, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blower does not turn on.	Battery is depleted. Power button not pressed correctly.	Charge the blower fully. Press and hold the power button for 2 seconds.
Blower does not charge.	Charging cable or adapter is faulty. Charging port is obstructed.	Try a different Type-C cable and adapter. Ensure the charging port is clean and free of debris.

Problem	Possible Cause	Solution
Weak airflow.	Battery is low. Air inlet/outlet is obstructed.	Recharge the blower. Clear any obstructions from the air inlet or outlet.
Unusual noise during operation.	Internal obstruction or damage.	Immediately turn off the device. Do not attempt to repair. Contact customer support.

If the problem persists after trying these solutions, please contact Zunate customer support for further assistance.

10. Specifications

Feature	Detail
Model Name	Zunategkc29r0uvn-11
Brand	Zunate
Color	Gray
Form Factor	Handheld
Special Features	Lightweight, Rechargeable
Max Rotation Speed	110,000 RPM
Airflow Speed	25 m/s
Battery Type	LS Lithium Battery x 2 (Built-in)
Battery Capacity	4000mAh
Battery Life (Max Throttle)	Approx. 15 minutes
Charging Interface	Type-C (15W fast charging)
Charging Time	Approx. 3 hours
Product Size	14.3 x 9.3 x 3.9 cm (5.63 x 3.66 x 1.54 inches)
Item Weight	366.00g (12.91 oz)



Image 10.1: Physical dimensions of the Zunate Jet Dry Mini Blower.

11. Warranty and Support

Zunate products are designed for reliability and performance. For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Zunate website. If you require assistance, please contact Zunate customer service with your product model number (Zunategkc29r0uvn-11) and purchase details.

You can find more information about Zunate products and support at the Zunate Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYLZ3XFN

More documents and user manuals: **https://manuals.plus/**