

[Manuals.plus](#) /

> [JLab](#) /

> JLab Go Sport+ Wireless Workout Earbuds User Manual - Model EBGSPRTPSND50WEB

JLab Go Sport+

JLab Go Sport+ Wireless Workout Earbuds User Manual

Model: Go Sport+ (EBGSPRTPSND50WEB)

Brand: JLab

INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your JLab Go Sport+ Wireless Workout Earbuds. Please read this guide thoroughly to ensure optimal performance and longevity of your device.




Image: JLab Go Sport+ Wireless Workout Earbuds and their charging case, highlighting key features.

WHAT'S IN THE BOX

- JLab Go Sport+ Earbuds
- Charging Case with Integrated USB-C Cable
- 3 Sets of Gel Eartips (Small, Medium, Large)



Image: The JLab Go Sport+ package contents, showing the earbuds, charging case with integrated cable, and various eartip sizes.

SETUP

1. Optimal Fit

Select the appropriate size of gel eartips for a secure and comfortable fit. The ergonomic over-ear hook design ensures the earbuds stay in place during physical activity. Experiment with all sizes to find your best fit.

CUSTOMIZE YOUR SOUND

Download the JLab app to tailor your listening experience further. Control touch functions, adjust Be Aware settings, and personalize sound preferences with EQ presets including JLab Signature, Balanced, or Bass Boost.



Image: A close-up view of a JLab Go Sport+ earbud securely fitted over a person's ear.

2. Initial Pairing (Bluetooth)

1. Remove the earbuds from the charging case. They will automatically power on and enter pairing mode.
2. Open your device's Bluetooth settings.
3. Select "JLab Go Sport+" from the list of available devices.
4. A voice prompt will confirm "Bluetooth Connected" once paired.

For Android devices, Google Fast Pair allows for effortless pairing and helps locate missing earbuds.

OPERATING INSTRUCTIONS

Touch Controls

Action	Left Earbud	Right Earbud
Volume	Single Tap (Down)	Single Tap (Up)
Play/Pause	Double Tap	Double Tap

Action	Left Earbud	Right Earbud
Track Control	Press & Hold 1+ sec (Back)	Press & Hold 1+ sec (Forward)
Voice Assistant	Double Tap (Siri/Google)	N/A
Answer Call	Single Tap	Single Tap
Hang Up Call	Double Tap	Double Tap
Reject Incoming Call	Press & Hold 1+ sec	Press & Hold 1+ sec
EQ Change	Triple Tap	Triple Tap

EQ Sound Settings

The earbuds feature 3 EQ sound settings: JLab Signature (amplified vocals and bass), Balanced (even sound), and Bass Boost (amplified bass and sub-bass). Triple tap either earbud to cycle through these modes.



Image: The JLab App interface, demonstrating how to customize sound preferences with various EQ presets.

Be Aware Mode

Activate Be Aware Mode to allow ambient noise in, enhancing your awareness of surroundings for safer listening. This feature is particularly useful during outdoor activities or in environments where situational awareness is important.



Image: A woman wearing JLab Go Sport+ earbuds while playing tennis, demonstrating the utility of Be Aware Mode for situational awareness.

C3 Clear Calling

Built-in MEMS microphones in each earbud deliver C3 Clear Calling technology for enhanced call quality. Use both earbuds for stereo calls or a single earbud for private conversations.



Image: A person engaged in a phone call using JLab Go Sport+ earbuds, emphasizing the clear call quality provided by C3 Clear Calling technology.

CHARGING

The earbuds offer 9+ hours of playtime per earbud, with an additional 26+ hours from the charging case, totaling over 35 hours. Return the earbuds to the case to recharge. The integrated USB-C cable allows for convenient charging of the case.



Image: The JLab Go Sport+ earbuds nestled in their charging case, showcasing the integrated USB-C charging cable for convenience.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid harsh chemicals.
- **Water Resistance:** The earbuds have an IP55 sweat resistance rating, protecting them from sweat and dirt. They are not designed for submersion in water.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are removed from the case and your device's Bluetooth is on. Try forgetting the device in your Bluetooth settings and re-pairing.
- **No sound:** Check volume levels on both your device and the earbuds. Ensure earbuds are properly connected via Bluetooth.
- **Charging issues:** Verify the integrated USB-C cable is securely connected to a power source. Ensure earbuds are correctly seated in the charging case.

SPECIFICATIONS

Feature	Detail
Brand	JLab
Model Name	Go Sport+
Model Number	EBGSPRTPSND50WEB
Color	Sand
Connectivity	Wireless (Bluetooth 5.0)
Bluetooth Range	10 Meters
Battery Life (Earbuds)	9+ Hours
Battery Life (Case)	26+ Hours (Total 35+ Hours)
Battery Charge Time	2.2 Hours
Water Resistance	IP55 Sweat Resistant
Control Type	Touch
Microphone	Built-in MEMS Microphone (C3 Clear Calling)
EQ Settings	JLab Signature, Balanced, Bass Boost
Ear Placement	In Ear (Earhook)
Material	Silicone
Item Weight	0.41 Grams

WARRANTY AND SUPPORT

The JLab Go Sport+ Wireless Workout Earbuds come with a **Two Year JLab Warranty**. For warranty claims or technical support, please visit the official JLab website or contact their customer service directly. For additional information and resources, you may visit the [JLab Store on Amazon](#).

