



---

[Manuals.plus](#) /

› [Hocteon](#) /

› Hocteon 4-Tier Rolling Storage Cart Instruction Manual

## Hocteon 4-Tier Rolling Storage Cart

# Hocteon 4-Tier Rolling Storage Cart Instruction Manual

Model: 4-Tier Rolling Storage Cart

## INTRODUCTION

---

Thank you for choosing the Hocteon 4-Tier Rolling Storage Cart. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage cart. Please read these instructions carefully before use and retain them for future reference.



Image: The Hocteon 4-Tier Rolling Storage Cart, showcasing its rustic brown wooden top and black mesh baskets, used as a side table in a living room.

## SAFETY INFORMATION

---

- Do not exceed the top shelf weight capacity of **110 lbs (50 kg)**.
- The bottom three tiers each have a maximum weight capacity of **44 lbs (20 kg)**.
- Use caution when moving the cart to prevent tipping, especially when loaded.
- Ensure all screws are securely tightened before use.
- Keep small parts away from children during assembly.

## PACKAGE CONTENTS

---

Before assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- 4 x Mesh Storage Baskets

- 1 x Rustic Brown Wooden Top Panel
- 4 x Lockable Wheels
- Assembly Hardware (screws, wrench)
- Instruction Manual

## ASSEMBLY INSTRUCTIONS

---

Assembly is required. Follow these steps carefully. It is recommended to assemble the cart on a soft, clean surface to prevent scratches.

1. **Unpack and Identify Parts:** Lay out all components and hardware. Refer to the included parts list to ensure everything is present.
2. **Attach Wheels:** Secure the four lockable wheels to the bottom of the metal frame using the provided hardware. Ensure they are firmly attached.
3. **Assemble Frame:** Connect the vertical metal frame pieces. Do not fully tighten screws at this stage.
4. **Insert Mesh Baskets:** Slide the mesh storage baskets into their designated slots on the frame. Insert them loosely first.
5. **Place Wooden Top:** Position the rustic brown wooden top panel onto the top of the frame.
6. **Tighten All Screws:** Once all components are in place, systematically tighten all screws using the provided wrench. Ensure the cart is stable and level.

Your browser does not support the video tag.

Video: An official Hocteon video demonstrating the assembly and features of the rolling storage cart, including lockable wheels, handle design, and multi-layer storage space.

## OPERATING INSTRUCTIONS

---

The Hocteon 4-Tier Rolling Storage Cart is designed for versatile use in various settings.

- **Mobility:** Utilize the 360° rotating wheels to easily move the cart between rooms or to different areas within a space.
- **Lockable Wheels:** To secure the cart in a stationary position, press down on the locking levers on two of the wheels. To unlock, lift the levers.
- **Storage:** Use the four mesh baskets for organizing items such as kitchen supplies, laundry essentials, office documents, or personal belongings. The top wooden panel can serve as an additional surface for display or temporary placement.
- **Handle:** The integrated handle design allows for easy pushing or pulling of the cart.



Image: Close-up details of the cart, highlighting the rustic wooden top, integrated handle, breathable mesh baskets, and lockable wheels.



Image: The storage cart positioned in a kitchen corner, demonstrating its use for organizing various food items and kitchen essentials.

## MAINTENANCE

- **Cleaning:** Wipe the cart surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Weight Limits:** Adhere strictly to the specified weight capacities for each shelf to prevent damage or injury.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Cart is wobbly or unstable.	Screws are loose. Uneven floor.	Tighten all assembly screws. Move the cart to a level surface.

Problem	Possible Cause	Solution
Wheels do not roll smoothly.	Wheels are locked. Debris in wheels.	Ensure wheel locks are disengaged. Clean any debris from the wheel mechanisms.
Items fall off the shelves.	Overloaded shelf. Items placed too close to edge.	Reduce weight on the shelf. Utilize the fall-proof wire stop to keep items secure.

## SPECIFICATIONS

Feature	Detail
Product Dimensions (D x W x H)	11.8" x 15.1" x 30.3" (29.97 cm x 38.35 cm x 76.96 cm)
Shelf Type	Metal Mesh
Frame Material	Metal
Top Panel Material	FSC-Certified Wood
Number of Shelves	4
Top Shelf Weight Capacity	Up to 110 lbs (50 kg)
Lower Shelves Weight Capacity (each)	Up to 44 lbs (20 kg)
Item Weight	3.65 Kilograms (8.05 lbs)
Color	Rustic Brown
Assembly Required	Yes

# Product Size

Unit: inch



Image: A detailed diagram illustrating the precise dimensions of the storage cart in inches.

## WARRANTY AND SUPPORT

Hoctieon is committed to providing quality products and customer satisfaction.

- **Warranty:** This product comes with a **1-year warranty** from the date of purchase, covering manufacturing defects.
- **Returns:** You may return the product within **30 days** of purchase for a refund or replacement, subject to the retailer's return policy.
- **Customer Support:** For any questions, concerns, or assistance with assembly or product issues, please contact Hoctieon customer service. Our support team is available **24 hours online** to assist you.

Please visit the official Hoctieon store or contact your retailer for specific contact information.