

[Manuals.plus](#) /

> [Vortopt](#) /

> Vortopt Water Filter Pitcher - 10-Cup Water Purifier Pitcher Instruction Manual

Vortopt L3

Vortopt L3 Water Filter Pitcher Instruction Manual

Model: L3



INTRODUCTION

Thank you for choosing the Vortopt L3 Water Filter Pitcher. This manual provides essential information for the safe and efficient use of your new water purifier. The Vortopt L3 is designed to improve the taste of your tap water by effectively reducing contaminants such as rust, sediments, chlorine, lead, and odor, ensuring clean and healthy drinking water.

PRODUCT OVERVIEW AND COMPONENTS

The Vortopt L3 Water Filter Pitcher consists of several key components:

- **Lid:** Covers the top of the pitcher, often with a pour spout.
- **Funnel:** Holds the filter cartridge and allows water to pass through.
- **Filter Cartridge:** The core filtration component.
- **Jug:** The main pitcher body that collects filtered water.
- **Handle:** For easy carrying and pouring.
- **Water Outlet:** Where filtered water is dispensed.

The pitcher is made of high-grade BPA-free plastic, ensuring safety and durability.



Figure 1: Exploded view of the Vortopt L3 Water Filter Pitcher components.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Ensure all parts listed in the "Product Overview" section are present.
2. **Wash Components:** Wash the pitcher, lid, and funnel with mild dish soap and warm water. Rinse thoroughly. *Do not wash the filter cartridge with soap.*
3. **Prepare Filter:** Submerge the new filter cartridge in cold water for 15 minutes to remove any air bubbles and activate the filter media.
4. **Insert Filter:** Firmly insert the prepared filter cartridge into the funnel. Ensure it is seated securely to prevent unfiltered water from bypassing the filter.
5. **Assemble Pitcher:** Place the funnel with the inserted filter into the pitcher. Place the lid on top of the pitcher.



Figure 2: Assembled Vortopt L3 Water Filter Pitcher.

OPERATING INSTRUCTIONS

1. **Fill with Water:** Open the lid and pour tap water into the funnel. The water will slowly filter through the cartridge into the main jug.
2. **Discard First Two Fillings:** For optimal performance, discard the first two full pitchers of filtered water. This helps to flush out any loose carbon particles and prepare the filter for regular use.
3. **Enjoy Filtered Water:** Once the water has filtered, it is ready for consumption. Pour from the pitcher's spout.
4. **Storage:** The pitcher's creative design allows it to be perfectly placed on most refrigerator doors.

Your browser does not support the video tag.

Video 1: Demonstration of filling and using the Vortopt L3 Water Filter Pitcher.

MAINTENANCE

Filter Replacement

The filter has a lifespan of up to 200 gallons or 3 months, whichever comes first. Regular replacement ensures continued filtration performance.

1. **Remove Old Filter:** Lift the funnel out of the pitcher and remove the old filter cartridge.
2. **Prepare New Filter:** Follow the "Prepare Filter" step from the Setup section for the new cartridge.
3. **Insert New Filter:** Insert the new filter firmly into the funnel.
4. **Discard Initial Water:** Discard the first two full pitchers of filtered water from the new filter.

Cleaning the Pitcher

Wash the pitcher, lid, and funnel regularly with mild dish soap and warm water. Rinse thoroughly. The pitcher is not dishwasher safe.

5X Greater Filtration Capacity than Others
3 months service life

Vortopt
200 Gallons

Other Brands
40 Gallons

VS

*The filter service life is affected by local water quality

The infographic features a large white Vortopt filter pitcher on a blue pedestal on the left. To its right, a blue circle with 'VS' in white is positioned between the pitcher and a row of five smaller, grey-outlined filter cartridges on a white pedestal. The background is a blue gradient with vertical lines and a spotlight effect on the pitcher.

Figure 3: The Vortopt filter offers a 200-gallon capacity, significantly longer than typical 40-gallon filters.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Slow Filtration Rate	Filter is clogged or needs priming.	Ensure the filter was properly submerged and soaked before first use. If the filter is old, replace it.
Water Taste Not Improved	Filter not properly installed or expired.	Check that the filter is securely seated in the funnel. Replace the filter if it has reached its 3-month or 200-gallon lifespan.
Black Specks in Water	Loose carbon particles from new filter.	This is normal for new filters. Discard the first two pitchers of water. If specks persist, re-soak the filter or replace it.
Pitcher Leaks	Components not assembled correctly.	Ensure the filter and funnel are correctly and firmly seated. Check for any cracks in the pitcher.

SPECIFICATIONS

Feature	Detail
Model Name	L3
Product Dimensions	9.21"L x 4.3"W x 9.84"H
Weight	2.14 Pounds
Capacity	10-Cup (2.5L)
Filter Lifespan	Up to 200 gallons or 3 months
Material	BPA-free plastic
Filtration Technology	Coconut shell activated carbon, highly efficient activated carbon fiber, ion exchange resin, PP cotton (4-stage filtration)
Certifications	CE Certified
Included in Box	1 Water Filter Pitcher System (includes 1 filter)

CE and FDA Certification

The material of filter element has passed the test of CE and FDA certification to ensure the safety of your drinking water.



Figure 4: Product dimensions and certification information.

Cost-effective Choice

1 Filter

1514 Bottles



The capacity of the bottle is about 16.9oz/0.5L.

Figure 5: Detailed view of the 4-stage filtration process.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Vortopt website or contact the seller directly through your purchase platform. Keep your proof of purchase for any warranty claims.

For additional information or to purchase replacement filters, visit the [Vortopt Store on Amazon](#).

