



[Manuals.plus](#) /

> [TUTOTAK](#) /

> TUTOTAK Bar Cart BC01BK034 Instruction Manual

## TUTOTAK BC01BK034

# TUTOTAK Bar Cart BC01BK034 Instruction Manual

Model: BC01BK034

## 1. INTRODUCTION

---

Thank you for choosing the TUTOTAK Bar Cart, Model BC01BK034. This mobile serving cart is designed to provide versatile storage and serving solutions for your home. Featuring a durable metal frame, three mirrored shelves, and smooth-rolling casters, it is suitable for use in kitchens, living rooms, dining areas, or offices. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your product.



Image 1.1: Fully assembled TUTOTAK Bar Cart BC01BK034.

## 2. SAFETY INFORMATION

Please read and understand all safety instructions before assembling or using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Stability:** Ensure the cart is placed on a level surface. When stationary, engage the brakes on the locking casters to prevent unintended movement.
- **Weight Capacity:** Do not overload the shelves. Distribute weight evenly to maintain stability. Refer to the specifications section for maximum weight limits per shelf.
- **Movement:** Use caution when moving the cart, especially on uneven surfaces, to prevent tipping. Avoid sudden stops or turns when the cart is heavily loaded.
- **Sharp Edges/Pinch Points:** Be careful during assembly and handling to avoid contact with sharp edges or pinch points.
- **Children and Pets:** Keep children and pets away from the cart during assembly. Do not allow children to climb on, play with, or hang from the cart.
- **Assembly:** Ensure all parts are properly secured and tightened before use. Periodically check all fasteners for tightness.

- **Cleaning:** Use only a dry cloth for cleaning. Avoid abrasive cleaners or harsh chemicals that may damage the finish or mirrored surfaces.

### 3. PACKAGE CONTENTS

---

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components (vertical supports, horizontal bars)
- Mirrored Shelves (3 pieces)
- Casters (4 pieces, 2 with brakes)
- Wine Rack
- Glass Holders
- S-Hooks (6 pieces)
- Assembly Hardware (screws, bolts, Allen wrench)
- Instruction Manual

### 4. ASSEMBLY INSTRUCTIONS

---

Assembly typically takes approximately 15 minutes. Follow these steps carefully. A Phillips head screwdriver may be required (not included).

#### Step 4.1: Attach Casters to Base Frame

Carefully attach the four casters to the designated holes on the bottom frame of the cart. Ensure that the two casters with brakes are positioned on the same side for easy access. Tighten securely with the provided wrench.



x2



x2

## 360° Rotating Casters

4pcs 360° rotating casters, 2 of which are equipped with brakes to prevent sliding when stopped.

Image 4.1: Casters with brakes for stability.

### Step 4.2: Assemble Frame Structure

Connect the vertical support bars to the base frame and then attach the upper frame components. Ensure all connections are aligned and hand-tighten screws initially. The handle should be at the top of one side.



Image 4.2: Ergonomic handle for easy control.

### **Step 4.3: Install Mirrored Shelves**

Carefully slide each mirrored shelf into its designated slot within the frame. The shelves are designed to rest securely on the horizontal supports. Ensure they are level and stable.

### **Step 4.4: Attach Wine Rack and Glass Holders**

Secure the wine rack and glass holders to the underside of the top shelf as indicated in the diagram. These components can be disassembled if not desired for use.



Image 4.3: Integrated glass holders.

### **Step 4.5: Add S-Hooks**

Attach the provided S-hooks to the side rail of the middle shelf. These hooks are ideal for hanging small utensils or towels.



Image 4.4: Convenient S-hooks for accessories.

### **Step 4.6: Final Tightening**

Once all components are in place, fully tighten all screws and bolts using the provided Allen wrench. Ensure the cart is stable and all parts are securely fastened before use.

## 5. OPERATING INSTRUCTIONS

---

The TUTOTAK Bar Cart is designed for ease of use and versatility.

- **Loading:** Place items on the shelves, distributing weight evenly. Utilize the wine rack for bottles and glass holders for stemware. The protective fence on the bottom shelf helps secure items.
- **Moving:** To move the cart, release the brakes on the casters. Use the handle to guide the cart to your desired location.
- **Stationary Use:** Once the cart is in position, engage the brakes on the two locking casters to prevent accidental movement.
- **Multifunctional Use:** This cart can serve various purposes beyond a bar cart, such as a kitchen cart, coffee cart, drink cart, or a mobile storage shelf for other rooms.

## 6. MAINTENANCE

---

Proper maintenance will extend the life and appearance of your bar cart.

- **Cleaning:** Wipe all surfaces, including the mirrored shelves and metal frame, with a soft, dry cloth. For stubborn marks on the metal, a slightly damp cloth followed by a dry cloth can be used. Avoid harsh chemicals or abrasive cleaning materials.
- **Mirrored Surfaces:** For streak-free mirrored shelves, use a glass cleaner specifically designed for mirrors and a microfiber cloth.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Casters:** Keep casters free of debris (hair, dust, etc.) to ensure smooth rolling.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your TUTOTAK Bar Cart, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cart is wobbly or unstable.	Loose fasteners; uneven surface; uneven weight distribution.	Check and tighten all screws and bolts. Move the cart to a level surface. Redistribute items evenly on shelves.
Casters do not roll smoothly.	Debris in casters; brakes engaged; damaged caster.	Clear any debris from the caster wheels. Ensure brakes are disengaged. If a caster is damaged, contact support for replacement.
Mirrored shelf appears scratched or damaged.	Improper cleaning; impact during use.	Use only soft, dry cloths and appropriate glass cleaner. Avoid placing sharp or heavy objects directly on the mirror without protection.
Wine rack or glass holders are loose.	Fasteners not fully tightened.	Ensure the screws securing these components are fully tightened.

## 8. SPECIFICATIONS

- **Model:** BC01BK034
- **Dimensions (Overall):** 13"D x 18.5"W x 33.7"H (33cm D x 47cm W x 85.6cm H)
- **Shelf Type:** 3-Tier Mirrored Shelf
- **Frame Material:** Metal
- **Color:** Black
- **Item Weight:** Approximately 15.71 pounds (7.13 kg)
- **Features:** 360° Rotating Casters (2 with brakes), Integrated Wine Rack, Glass Holders, 6 S-Hooks, Protective Fence on bottom shelf.
- **Care Instructions:** Wipe with Dry Cloth



Image 8.1: Product dimensions diagram.

## 9. WARRANTY AND SUPPORT

TUTOTAK products are manufactured with quality and care. For specific warranty details, please refer to the documentation included with your purchase or visit the official TUTOTAK website. If you have any

questions, require assistance with assembly, or need to report missing/damaged parts, please contact TUTOTAK customer support through the retailer where the product was purchased or via the contact information provided on our official website.

Please retain your proof of purchase for warranty claims.