

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Dripex](#) /

› [Dripex Foldable Playpen Model BP180 Instruction Manual](#)

## Dripex BP180

# Dripex Foldable Playpen Model BP180 Instruction Manual

Your Guide to Safe and Easy Setup

## 1. INTRODUCTION

Thank you for choosing the Dripex Foldable Playpen. This manual provides essential information for the safe assembly, operation, and maintenance of your playpen. Designed to offer a secure and spacious environment for your child, this playpen allows parents to manage household tasks while keeping their child within a safe, visible area. Please read all instructions carefully before assembly and use.

## 2. SAFETY INFORMATION

- Always ensure all panels are securely locked before placing a child inside the playpen.
- Do not leave children unattended in the playpen. Constant supervision is required.
- The zipper doors are designed to open only from the outside to prevent children from exiting unsupervised.
- Ensure the playpen is placed on a flat, stable surface. Non-slip suction cups are provided for stability.
- Keep the playpen away from open flames, heaters, and other heat sources.
- Regularly inspect the playpen for any signs of wear, damage, or loose parts. Discontinue use if any damage is found.
- The material used in this playpen has been certified by CPSC and SGS for safety.
- This playpen is designed for children who cannot climb out or reach a height of 27 inches.

## 3. PRODUCT COMPONENTS

Before assembly, verify that all the following components are present:

- Vertical Tubes: 16 pieces
- Cloth Cover with Upper Rod and Door: 2 pieces
- Cloth Cover with Upper Rod: 6 pieces
- Lower Rod: 8 pieces
- Handle Rings: 5 pieces (for child to pull up)



This diagram details the components included with the playpen: 16 vertical tubes, 2 cloth covers with upper rod and door, 6 cloth covers with upper rod, 8 lower rods, and 5 handle rings. The overall dimensions are approximately 71x71x27 inches.

## 4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Dripex Foldable Playpen:

- 1. Prepare Components:** Unpack all components and lay them out. Identify the vertical tubes, cloth covers (with and without doors), and lower rods.
- 2. Connect Rods to Panels:** Insert the vertical tubes into the designated sleeves of the cloth covers. Ensure the ends of the upper and lower rods are strictly aligned as shown in the diagram below.

### Installation Tips




#### Important:

Please align the ends of the upper and lower rods strictly, as shown in the picture.

Important installation tip: Ensure the ends of the upper and lower rods are strictly aligned as shown for proper assembly.

3. **Connect Panels and Lock:** Join the assembled panels together. For each connection point, ensure the panel is in the 'lock' state before connecting. To lock, slide the mechanism until it clicks into place. To unlock, press the button and slide.



Detailed steps for operating the panel locking mechanism, showing locked and unlocked states for secure assembly.



Visual guide for connecting panels: 1. Ensure upper and lower rod ends match. 2. Keep the panel in the 'lock' state during connection. 3. Press to unlock, then slide to connect/disconnect.

4. **Form Desired Shape:** Arrange the connected panels into your desired configuration (e.g., square, octagon, rectangle, L-shape). Ensure all connections are secure.



The Dripex Foldable Playpen configured as an octagon, providing a spacious and secure area for a child to play.

## 5. OPERATING INSTRUCTIONS

### 5.1 Adjusting Shape

The playpen's modular design allows for flexible configuration to suit your space. You can arrange the 8 panels into various shapes such as a square, L-shape, octagon, or rectangle. Simply unlock the necessary panels, reposition them, and then relock to secure the new shape.

## Adjustable Shape

Perfect for Your Home



The playpen can be adjusted into multiple shapes such as square, L-shape, octagon, or rectangle to fit different spaces and needs.

### 5.2 Using the Zipper Gate

The playpen features an innovative hangable zipper door. This design allows the mesh to be folded out of the way, preventing tripping hazards and protecting the zipper from damage. The zipper can only be opened from the outside, ensuring your child remains safely inside.



The exterior zippered door allows for practical entry and exit for children, and can only be opened from the outside for safety.

### 5.3 Folding and Storage

The playpen is designed for easy folding and compact storage. To fold, unlock the panels as needed and

collapse them. The playpen can be folded against a wall or stored in a car without removing all accessories.



This image illustrates the playpen's two folding modes: extended for use and collapsed into a compact form for storage, shown against a wall and next to a sofa.



The playpen can be folded against a wall for compact storage when not in use, demonstrating its space-saving design.

#### 5.4 Disassembly

To fully disassemble the playpen, follow these steps:

1. Push the stretchable circle at the bottom of each connection point.
2. Disconnect the bottom tube combination.

3. Ensure the panel is in the 'unlock' state before attempting to separate the rods.



Steps for disassembly: 1. Push the stretchable circle at the bottom. 2. Disconnect the bottom tube combination. 3. Keep the panel in the 'unlock' state.

## 6. MAINTENANCE

- Cleaning:** The 300D Oxford fabric and mesh can be cleaned with a damp cloth and mild soap. Allow to air dry completely before folding or storing. Do not use harsh chemicals or abrasive cleaners.
- Storage:** When not in use, fold the playpen compactly and store it in a dry, cool place away from direct sunlight.
- Inspection:** Periodically check all connections, fabric, and mesh for tears, loose stitching, or damage. Ensure the non-slip suction cups are intact and functioning correctly.

## 7. TROUBLESHOOTING

- Playpen is unstable:** Ensure all panel connections are securely locked. Verify that the non-slip suction cups are firmly pressed against a clean, flat surface.
- Difficulty assembling panels:** Double-check that the ends of the upper and lower rods are correctly aligned as per the assembly instructions. Ensure the locking mechanism is in the 'unlock' position when connecting, then slide to 'lock'.
- Zipper not functioning smoothly:** Ensure the fabric around the zipper is not caught. Avoid forcing the zipper; gently guide it.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	BP180
Product Dimensions (L x W x H)	71 x 69 x 27 inches
Floor Area	Approximately 34-35 Square Feet
Item Weight	25 pounds
Maximum Weight Recommendation	44 Pounds
Material Type	Alloy Steel (Frame)
Material Composition	300D Oxford Cloth (Fabric)
Color	Black

## Harmonious Design and Spaciousness

No multicolors disrupting your decor or baby's eyes and provides ample space



An illustration of the playpen's dimensions, indicating its spacious design with approximate measurements of 71 x 69 x 27 inches.

## Sturdy & Firm Structure



The playpen features a sturdy alloy steel frame capable of bearing up to 15kg and non-slip suction cups for enhanced stability.



Key features include padded head protection, an exterior zipper door for controlled access, thickened steel pipes for structural integrity, and breathable mesh for visibility and airflow.

## 9. CONTACT SUPPORT

For further assistance, questions, or concerns, please contact Dripex customer support through the retailer's platform or visit the official Dripex website.

## Related Documents - BP180

	<p><a href="#">Dripex Basketball Hoop Installation and Safety Guide</a></p> <p>Comprehensive instructions for assembling and safely using the Dripex Basketball Hoop, including parts list, safety warnings, and height adjustment guidance.</p>
	<p><a href="#">Dripex X Rowing Machine User Manual</a></p> <p>Comprehensive user manual for the Dripex X Rowing Machine, covering safety information, assembly instructions, parts list, monitor operation, fitness guide, and suggested stretches for home use.</p>
	<p><a href="#">Magnetic Elliptical Machine User's Manual</a></p> <p>Comprehensive user's manual for the Magnetic Elliptical Machine, covering safety information, parts list, assembly instructions, monitor usage, and maintenance tips.</p>
	<p><a href="#">Dripex Vibration Plate Machine: User Manual and Safety Guide</a></p> <p>Comprehensive instructions for the Dripex Vibration Plate Machine, covering technical data, safety guidelines, care, maintenance, functional description, and exercise postures for effective home workouts.</p>
	<p><a href="#">Dripex Vibration Plate Machine: User Manual and Safety Guide</a></p> <p>Comprehensive user manual for the Dripex Vibration Plate Machine, covering technical specifications, safety instructions, care and maintenance, functional description, and various exercise postures for effective full-body workouts.</p>
	<p><a href="#">DRIPEX DP364-A Vanity Makeup Mirror User Manual</a></p> <p>User manual for the DRIPEX DP364-A Vanity Makeup Mirror, covering assembly, operation, safety warnings, maintenance, and FCC compliance information.</p>

