

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [JIKADA](#) /

> [JIKADA 61 Key Keyboard Piano User Manual](#)

JIKADA JK-931

JIKADA 61 Key Keyboard Piano Instruction Manual

Model: JK-931

Brand: JIKADA

INTRODUCTION

Thank you for choosing the JIKADA 61 Key Keyboard Piano. This portable electric piano is designed for both beginners and experienced musicians, offering a rich set of features to enhance your musical journey. With its intuitive LCD screen, built-in speakers, and comprehensive accessories, you can explore a wide range of sounds and rhythms. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new instrument.

WHAT'S IN THE BOX

Upon opening your package, please ensure all the following components are present:

- 61-Key Electronic Keyboard Piano
- H-style Keyboard Stand
- Adjustable-Height Stool
- Headphones
- Microphone
- Music Rest
- Power Adapter

SUPPORT MULTIPLE DEVICES

Brings more functions to piano playing.



Figure 1: All included accessories for the JIKADA 61 Key Keyboard Piano.

SETUP GUIDE

1. Assembling the Keyboard Stand and Stool

Follow the instructions provided with the H-style keyboard stand and adjustable-height stool for proper assembly. Ensure all parts are securely fastened for stability.

2. Placing the Keyboard

Carefully place the 61-key keyboard onto the assembled stand. Ensure it is centered and stable.



Figure 2: The JIKADA 61 Key Keyboard Piano fully assembled and ready for use.

3. Powering the Keyboard

The keyboard can be powered in two ways:

- **Power Adapter:** Connect the included power adapter to the DC 9V input jack on the back of the keyboard and plug it into a standard wall outlet.
- **Batteries (Not Included):** For portable use, insert appropriate batteries (refer to the battery compartment for type and quantity) into the battery compartment on the underside of the keyboard.

4. Connecting Accessories

Connect the headphones to the "PHONES" jack for private practice. Plug the microphone into the "MIC" jack for vocal accompaniment. The music rest can be attached to hold sheet music or a tablet.

Everything You Need



Figure 3: Connection ports for USB MIDI, Audio Out, Microphone, and Headphones.

OPERATING INSTRUCTIONS

1. Power On/Off

Press the **POWER** button to turn the keyboard on or off. The LCD display will illuminate.

2. LCD Display

The LCD display provides clear information about the currently selected functions, tones, rhythms, and tempo settings. Refer to the display for real-time feedback on your selections.

LCD DISPLAY



Figure 4: The LCD display showing active functions and settings.

3. Selecting Tones and Rhythms

The keyboard features 300 different tones (instrument sounds) and 300 rhythms. Use the dedicated buttons or numerical keypad to select your desired tone or rhythm. The LCD display will show your current selection.

Additionally, there are 50 demo songs pre-loaded for listening or practicing along with.

Unlimited Possibilities

Clearly displaying the status of the functions you are using. Create your full masterpiece when you mix timbres and rhythms.



300
Timbres



300
Rhythms



50
Demo Songs



Figure 5: Overview of available Timbres, Rhythms, and Demo Songs.

4. Advanced Functions

- **Auto-Bass Chords:** Utilize single-fingered or fingered auto-bass chords for easy accompaniment.
- **Transpose & Tune:** Adjust the pitch of the keyboard to match other instruments or vocal ranges.
- **Split:** Divide the keyboard into two sections, allowing different tones to be played on each half.
- **Metronome:** Use the built-in metronome for timing practice.
- **Vibrato & Sustain:** Add expressive effects to your playing.
- **Record & Playback:** Record your performances and play them back to review and improve.

5. USB-MIDI Connection

Connect the keyboard to a Mac or PC via the USB-MIDI port. This allows you to use educational piano lesson software or other music production applications, expanding the keyboard's capabilities.

6. Full Size 61 Keys

The 61 full-size keys are designed to imitate the feel of a standard piano, providing a responsive playing experience that accurately reflects delicate changes in tone and quality, making your performances musically expressive.



Full Size 61 Keys

Imitate the feel of a standard piano, accurately reflect delicate changes in tone and quality, making your performances musically expressive.

Figure 6: The 61 full-size keys provide a realistic piano feel.

MAINTENANCE

Cleaning

Wipe the keyboard and stand with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water and a mild soap solution, then wipe dry immediately. Avoid using abrasive cleaners, solvents, or waxes, as these can damage the finish.

Storage

When not in use, store the keyboard in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If storing for an extended period, remove batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from keyboard.	Power off; Volume too low; Headphones connected; Speaker issue.	Ensure power is on. Increase volume. Disconnect headphones if using speakers. Check if speakers are enabled.
Keys not responding.	Keyboard in incorrect mode; Power issue.	Check the selected mode on the LCD. Turn the keyboard off and on again.
Distorted sound.	Volume too high; Loose connections.	Lower the volume. Ensure all cables (power, headphones, mic) are securely connected.

SPECIFICATIONS

Feature	Detail
Brand	JIKADA
Model Name	JK-931
Number of Keys	61
Product Dimensions (Keyboard)	35.4"W x 9.4"D x 2.8"H
Item Weight	21.8 pounds (approx. 9.89 kg)
Material	Plastic
Tones	300
Rhythms	300
Demo Songs	50
Connectivity Technology	USB-MIDI, 3.5mm Jack (Audio Out, Mic, Phones)
Power Source	Power Adapter or Batteries (not included)
Skill Level	Professional (suitable for all levels, including beginners)

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your JIKADA 61 Key Keyboard Piano, please refer to the contact details provided on the product packaging or the official JIKADA website. Keep your purchase receipt as proof of purchase for warranty claims.

