Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Agrestem YGPS10X13FT

Agrestem 10X13 FT Outdoor Polycarbonate Hardtop Gazebo

INSTRUCTION MANUAL

Sections:

Safety Information
Product Overview
Setup & Assembly
Operation
Maintenance
Troubleshooting
Specifications
Warranty & Support

1. Important Safety Information

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage.

- Regardless of the surface on which the gazebo is installed, it is essential to use ground nails, ropes, and expansion screws to ensure the stability of the gazebo. This is to prevent the gazebo from collapsing and causing harm to individuals inside or nearby, as well as property damage.
- Please do not use the gazebo in high winds, heavy snow, or severe weather conditions. The gazebo's design is not intended to withstand strong winds, heavy snow, or other severe weather. Precautions must be taken when wind speeds exceed 25 mph, and accumulated snow exceeds 2 inches.
- Before use, thoroughly inspect the gazebo to ensure all bolts, nuts, and fasteners are securely tightened and properly fastened.
- The polycarbonate roof only blocks UV rays and cannot withstand high temperatures and intense light.
- We recommend mutual assistance during assembly.

2. Product Overview

The Agrestem 10X13 FT Outdoor Polycarbonate Hardtop Gazebo is designed to provide a comfortable and protected outdoor space. It features a robust construction and thoughtful design elements for enhanced usability and durability.

Key Features:

- **Dual Hardtop Roof Design:** Crafted from polycarbonate, effectively blocking harmful UV rays. The dual-roof design promotes air circulation to resist wind force and reduce heat.
- **Sturdy Aluminum Frame:** Durable powder-coated aluminum frame prevents fading, rust, and corrosion. Equipped with pre-drilled base plates and ground nails for enhanced stability. Wind-resistant up to level 5-6 and snow-resistant up to 4 inches.
- **User-Friendly Design:** Features dual-track systems, two-sided zippers, and double-layer sidewalls (polyester fabric and mesh panels) for easy sliding and excellent ventilation. Includes three hooks for hanging lights or small fans.
- **Spacious Room:** Fully assembled dimensions of 10x13x8.9 ft, offering ample space for gatherings of 6-8 people. Ideal for backyards, patios, lawns, gardens, or other outdoor spaces.



Figure 1: Agrestem 10X13 FT Outdoor Polycarbonate Hardtop Gazebo in a patio setting.

3. Setup & Assembly

Assembly of the Agrestem Gazebo requires careful attention to detail and is best performed with at least two people. All necessary hardware and an installation manual are included with your purchase. For visual guidance, please

refer to the official installation video below.

Assembly Steps Overview:

1. **Prepare the Base:** Assemble the base plates to the main support posts. Ensure all connections are secure.
2. **Assemble the Frame:** Connect the horizontal beams to the vertical posts to form the main structure. Secure all corners and supports.
3. **Install Roof Supports:** Attach the upper roof frame components, ensuring they are properly aligned for the polycarbonate panels.
4. **Place Polycarbonate Panels:** Carefully slide and secure the polycarbonate roof panels into their designated slots. Ensure proper overlap and sealing.
5. **Attach Curtains and Netting:** Install the dual-track system for the curtains and netting. Hang the polyester fabric and mesh panels.
6. **Final Checks:** Verify all screws and fasteners are tightened. Ensure the gazebo is stable and properly anchored to the ground using ground nails or expansion screws.



Figure 2: Detail of the sturdy aluminum frame and base plate for secure installation.



Figure 3: Structural details of the aluminum frame and anchoring points.

Official Installation Video:

Your browser does not support the video tag.

Video 1: Hardtop Gazebo Installation Video. This video provides a step-by-step visual guide for assembling your gazebo, demonstrating the proper techniques for connecting components and securing the structure.

4. Operation

Your Agrestem Gazebo is designed for versatile use, providing shade and privacy as needed.

Curtains and Netting:

The gazebo features a dual-track system with two-sided zippers for easy management of the polyester fabric curtains and mesh panels. You can adjust them independently to control sunlight, airflow, and privacy.




Figure 4: Details of the double-layered curtain system for privacy and insect protection.



Figure 5: Various configurations of the removable curtains to suit different needs.

Integrated Hooks:

Three hooks are integrated into the canopy structure, allowing you to hang lights, small fans, or other decorative items to enhance your outdoor experience.



Figure 6: Multifunctional top design with integrated hooks for accessories.

Product Showcase Video:

Your browser does not support the video tag.

Video 2: Hardtop Polycarbonate Gazebo Showcase Video. This video highlights the key features and benefits of the gazebo, demonstrating its design and functionality in various settings.

5. Maintenance

Regular maintenance will ensure the longevity and optimal performance of your gazebo.

Cleaning:

- Clean the polycarbonate roof panels with a soft cloth and mild soapy water. Avoid abrasive cleaners or harsh chemicals that could damage the material.
- The aluminum frame can be wiped down with a damp cloth. For stubborn dirt, use a mild detergent.
- The polyester curtains and mesh panels can be spot cleaned with mild soap and water. For deeper cleaning,

follow care instructions on the fabric tags. Ensure they are completely dry before storing or closing for extended periods to prevent mildew.

Seasonal Care:

- During periods of high winds (exceeding 25 mph) or heavy snow accumulation (exceeding 2 inches), it is recommended to remove the roof panels and curtains to prevent damage to the structure.
- Regularly check all bolts, nuts, and fasteners for tightness, especially after severe weather conditions.
- Ensure proper drainage around the gazebo to prevent water accumulation at the base.



Figure 7: The gazebo is designed for four-season use, but requires attention during extreme weather.



Figure 8: The reasonably sloped roof ensures quick water drainage.

6. Troubleshooting

This section addresses common issues you might encounter with your gazebo.

Problem	Possible Cause	Solution
Gazebo feels unstable or wobbly.	Loose fasteners or inadequate anchoring.	Ensure all bolts and screws are securely tightened. Use ground nails or expansion screws to anchor the gazebo firmly to the ground.
Water pooling on the roof.	Improper panel installation or debris accumulation.	Verify roof panels are correctly installed and seated. Clear any leaves or debris from the roof and drainage channels.
Curtains/Netting do not slide smoothly.	Debris in tracks or misaligned tracks.	Clean the dual tracks of any dirt or obstructions. Check for proper alignment of the tracks.
Polycarbonate panels appear scratched or hazy.	Improper cleaning agents or abrasive materials used.	Always use a soft cloth and mild soapy water for cleaning. Avoid harsh chemicals or abrasive brushes.

7. Specifications

Detailed specifications for your Agrestem Gazebo:

Feature	Detail
Brand	Agrestem
Model Number	YGPS10X13FT

Feature	Detail
Product Dimensions	120"L x 156"W x 106.8"H (10x13x8.9 ft)
Material	Polyester, Aluminum, Polycarbonate
Frame Material	Aluminum
Roof Type	Dual Hardtop Polycarbonate
Water Resistance Level	Water Resistant
UV Protection	Yes
Wind Resistance	Up to Level 5-6
Snow Resistance	Up to 4 inches
Occupancy	8 people
Item Weight	96.6 pounds
Assembly Required	Yes

8. Warranty & Support

Agrestem is committed to customer satisfaction. Your gazebo comes with a standard return policy of 30 days for easy returns. For any questions or assistance with assembly, parts, or general inquiries, please contact Agrestem customer support. Installation videos are also provided for your convenience.

Protection Plans:

Additional protection plans are available for purchase to extend coverage beyond the standard policy:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly plan covering eligible purchases)

For detailed terms and conditions regarding warranty and protection plans, please refer to the documentation provided at the time of purchase or contact your retailer.

© 2025 Agrestem. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYQFKL1V

More documents and user manuals: **https://manuals.plus/**