

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw Smart Watch Bands User Manual

Lamshaw IDW17, IDW20, IDW21, IDW23, IDW25, IDW26 Smart Watch Bands

Lamshaw Smart Watch Bands User Manual

Model Compatibility: IDW17, IDW20, IDW21, IDW23, IDW25, IDW26 Smart Watches

INTRODUCTION

This user manual provides comprehensive instructions for the installation, care, and maintenance of your new Lamshaw Soft Silicone Sport Replacement Straps. These bands are designed for comfort, durability, and style, ensuring a perfect fit for your compatible smart watch models.

COMPATIBLE SMART WATCH MODELS

These replacement bands are specifically designed to be compatible with the following smart watch models:

- IDW17 Smart Watch
- IDW20 Smart Watch
- IDW21 Smart Watch
- IDW23 Smart Watch
- IDW25 Smart Watch
- IDW26 Smart Watch (1.83 Inches)

Important: Please confirm your smart watch model before attempting installation. These bands are not compatible with other watch models not listed above.

Compatible with Model



Figure 1: Visual representation of compatible smart watch models.

PRODUCT FEATURES

The Lamshaw Soft Silicone Sport Replacement Straps offer several key features for an enhanced user experience:

- **Premium Material:** Made from soft, flexible, and durable silicone material, ensuring comfort for extended wear. The material is eco-friendly and designed to prevent skin irritation.
- **Sweat & Water Resistant:** Engineered to withstand sweat and water, making them suitable for sports and daily activities.
- **Perfect Fit Design:** Equipped with connectors that seamlessly and securely integrate with the smart watch interface, providing a precise and secure lock even during vigorous exercise.
- **Easy Installation & Removal:** Designed for quick and simple attachment and detachment with a one-button removal mechanism.
- **Unique Color Choices:** Available in multiple unique colors, allowing for personalization and complementing various outfits.



Figure 2: Detailed view of band features including seamless connection and secure slot.



Figure 3: Illustration of the band's comfortable and skin-friendly properties.



Figure 4: Demonstration of the band's water resistance during swimming.

INSTALLATION GUIDE

Follow these steps to properly install or replace your Lamshaw Smart Watch Bands:

1. **Prepare the Watch:** Lay your smart watch face down on a soft, clean surface to prevent scratches.

2. **Remove Existing Band (if applicable):** If replacing an old band, locate the quick-release pins on the underside of the watch where the band connects. Slide the pin lever inward to release the band section. Repeat for both sides.
3. **Attach New Band:** Take one section of the new band. Locate the quick-release pin on the back of the band.
4. **Align and Insert:** Insert one end of the quick-release pin into the corresponding hole on the watch lug.
5. **Secure the Band:** While holding that end in place, slide the pin lever inward and align the other end of the pin with the opposite hole on the watch lug. Release the lever to snap the pin into place. Gently tug on the band to ensure it is securely attached.
6. **Repeat for Second Section:** Follow steps 3-5 for the other section of the watch band.



Figure 5: Lamshaw Smart Watch Bands in Black, Gray, and Blue.

Your browser does not support the video tag.

Video 1: Demonstration of how to install the silicone watch band onto a smart watch using the quick-release pins.

CARE AND MAINTENANCE

To ensure the longevity and appearance of your Lamshaw Smart Watch Bands, follow these care instructions:

- **Cleaning:** Regularly clean your bands with mild soap and water. Use a soft cloth to wipe away dirt and residue. Rinse thoroughly and dry completely before reattaching to your watch.
- **Avoid Harsh Chemicals:** Do not use strong detergents, abrasive cleaners, or solvents, as these can damage the silicone material.
- **Storage:** When not in use, store the bands in a cool, dry place away from direct sunlight to prevent discoloration or degradation of the material.
- **Water Exposure:** While the bands are water-resistant, prolonged exposure to saltwater or chlorinated water should be followed by a fresh water rinse to prevent material breakdown.

TROUBLESHOOTING

If you encounter any issues with your Lamshaw Smart Watch Bands, consider the following common solutions:

- **Band Not Attaching Securely:**
 - Ensure the quick-release pins are fully retracted and properly aligned with the watch lug holes.
 - Verify that the band is compatible with your specific watch model (refer to "Compatible Smart Watch Models" section).
- **Skin Irritation:**
 - Ensure the band is clean and dry. Residue from sweat or soap can sometimes cause irritation.
 - Adjust the tightness of the band. Wearing it too tight can restrict airflow and cause discomfort.
 - If irritation persists, discontinue use and consult a healthcare professional.
- **Discoloration:**
 - Clean the band regularly as per the "Care and Maintenance" section.
 - Avoid prolonged exposure to direct sunlight or harsh chemicals.

SPECIFICATIONS

Attribute	Detail
Product Type	Smart Watch Replacement Bands
Material	Soft Silicone
Compatibility	IDW17, IDW20, IDW21, IDW23, IDW25, IDW26 Smart Watches
Colors (Current Pack)	Black, Gray, Blue
Closure Type	Pin-and-tuck closure (or similar quick-release mechanism)
Water Resistance	Sweat & Water Resistant
Department	Unisex-adult
Metal Type	No Metal Type

WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or additional product support, please refer to the purchase platform or contact Lamshaw customer service directly. Contact details can typically be found on the product packaging or the seller's official website.

We are committed to providing high-quality products and support to our customers.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question