Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

oneisall N12-1

oneisall Standard Blade Accessory User Manual

Brand: oneisall | **Model:** N12-1

1. Product Overview

This manual provides essential information for the oneisall Standard Blade Accessory, designed as a replacement blade for compatible oneisall clippers, specifically model N12. This accessory ensures continued optimal performance of your grooming tool.

Key Features:

- **Sharp and Safe:** The blade is engineered to be sharp for effective cutting while maintaining safety during use. It is designed to prevent overheating and rust, ensuring a consistent and comfortable grooming experience for your pet.
- **Smooth Operation:** Designed to avoid getting stuck, providing a smooth and efficient haircut.
- **Easy Maintenance:** The blade is removable for straightforward cleaning and replacement, simplifying upkeep.



Image 1.1: The oneisall Standard Blade Accessory. This image displays the white housing and the precision-engineered metal cutting teeth of the replacement blade.

2. Safety Information

Please read and understand all safety instructions before installing or using the blade accessory. Improper handling can lead to injury or damage to the product.

- Always ensure the clipper is turned off and unplugged (if applicable) before attempting to remove or install the blade.
- Handle the blade with care to avoid accidental cuts from the sharp edges.
- Keep the blade out of reach of children and pets.
- Do not attempt to sharpen the blade yourself, as this may damage it and void any warranty.
- Store the blade in a dry, safe place when not in use.

Legal Disclaimer: *Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. (Note: This disclaimer appears to be generic and unrelated to the product. It is included as per the provided data but its relevance is questionable for a blade accessory manual.)*

3. Installation Guide

Follow these steps to correctly install the oneisall Standard Blade Accessory onto your compatible clipper (e.g., N12 model).

1. Ensure your oneisall clipper is powered off and disconnected from any power source.
2. Carefully remove the old blade from the clipper. Refer to your clipper's specific manual for detailed instructions on blade removal, as mechanisms may vary.
3. Align the new oneisall Standard Blade Accessory with the clipper's blade slot.
4. Gently push the blade into place until you hear a click, indicating it is securely fastened. Ensure it is flush with the clipper body.
5. Once installed, you may turn on the clipper briefly to confirm the blade is properly seated and operating smoothly.





Image 3.1: Blade installation illustration. This image demonstrates the compatibility and fitting process of the blade accessory with a oneisall clipper.

4. Maintenance and Care

Proper maintenance extends the life and performance of your blade accessory.

- **Cleaning:** After each use, remove the blade from the clipper. Use a small brush (often included with clippers) to remove any trapped hair or debris from between the teeth. You may also rinse the blade under running water if it is designed to be washable (refer to your clipper's manual for water resistance). Ensure the blade is completely dry before reattaching or storing.
- **Lubrication:** Apply a few drops of clipper oil (not included) to the blade teeth regularly, especially after cleaning. This helps reduce friction, keeps the blades sharp, and prevents rust.
- **Storage:** Store the blade in a clean, dry place away from direct sunlight and extreme temperatures.
- **Replacement:** Replace the blade when you notice a decrease in cutting performance, pulling of hair, or if the blade becomes dull or damaged.

5. Troubleshooting

If you encounter issues with your oneisall Standard Blade Accessory, consider the following:

- **Blade Not Cutting Effectively:**
  - Ensure the blade is clean and free of hair or debris.
  - Apply clipper oil to the blade.
  - Check if the blade is properly installed and securely fastened to the clipper.
  - If the blade is old or has been used extensively, it may be dull and require replacement.
- **Blade Overheating:**
  - Clean and lubricate the blade. Friction from dirt or lack of oil can cause overheating.
  - Ensure the blade is not damaged or bent.
- **Blade Not Fitting:**
  - Verify that you have the correct blade accessory for your specific oneisall clipper model (e.g., N12).
  - Ensure there are no obstructions in the clipper's blade slot.

6. Specifications

Attribute	Detail
Brand	oneisall
Model Number	N12-1
ASIN	B0CYT41QQ3
Color	White
Item Weight	0.02 Kilograms (0.63 ounces)
Package Dimensions	2.88 x 1.54 x 1.02 inches
Recommended Uses For Product	Body (for grooming)
Hair Type Compatibility	All
Manufacturer	oneisall
Date First Available	May 22, 2024

7. Warranty and Support

Warranty: The oneisall Standard Blade Accessory comes with a**2-Year Warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support: For any questions, concerns, or assistance with your product, oneisall offers**24-hour Customer Service**. Please visit the official oneisall website or contact their support team directly for prompt assistance.

You can find more information and contact details on theoneisall Amazon Store.

© 2024 oneisall. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYT41QQ3

More documents and user manuals: **https://manuals.plus/**