

[Manuals.plus](#) /

› [ESTINGO](#) /

› ESTINGO Heated Blanket Throw User Manual - Model YCDM-EB5060

ESTINGO YCDM-EB5060

ESTINGO Heated Blanket Throw User Manual

Model: YCDM-EB5060

INTRODUCTION

This manual provides essential information for the safe and effective use of your ESTINGO Heated Blanket Throw, Model YCDM-EB5060. Please read all instructions carefully before use and retain this manual for future reference.

The ESTINGO Heated Blanket Throw is designed to provide warmth and comfort. It features double-layered sherpa fabric, 5 heating levels, and an automatic 4-hour shut-off function for safety and convenience.

SAFETY INFORMATION

- This electric throw blanket has passed strict ETL and FCC safety certifications.
- It includes overheating protection and short-circuit protection. The blanket will automatically shut down if an abnormality occurs.
- Do not use if the blanket is wet.
- Do not use with infants, children, incapacitated individuals, or persons insensitive to heat.
- Do not use if the power cord or controller is damaged.
- Always disconnect the power cord from the outlet when not in use or before cleaning.

PRODUCT OVERVIEW



HEATED IN 5 MINUTES FAST HEATING



OVERHEAT
PROTECTION



EVENLY HEATS



SHORT-CIRCUIT
PROTECTION

Image: ESTINGO Heated Blanket Throw, Milk Coffee color, 50"x60" size.



Image: Close-up of the double-sided sherpa fabric, highlighting its soft and fluffy texture.

Key Features:

- **Material:** Double-layered Sherpa (100% Polyester) for softness and warmth.
- **Dimensions:** 50"L x 60"W (Throw size).
- **Heating Levels:** 5 adjustable heat settings (86-122°F).
- **Auto-Off Timer:** Automatically shuts off after 4 hours.
- **Fast Heating:** Heats up quickly within 5 minutes.
- **Safety Certifications:** ETL and FCC certified with overheating and short-circuit protection.
- **Controller:** Easy-to-use one-button control.

SETUP

1. **Unpack:** Carefully remove the heated blanket from its packaging.
2. **Inspect:** Check the blanket, power cord, and controller for any signs of damage. Do not use if damaged.
3. **Placement:** Lay the blanket flat on a bed, sofa, or chair. Ensure there are no folds or creases that could concentrate heat.
4. **Connect:** Plug the controller into the blanket's connector, ensuring a secure fit. Then, plug the power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

ONE BUTTON CONTROL

EASY TO USE



5 Heating Settings



4H Auto Off



10FT Wire



Image: The blanket's controller, showing the power button, 5 heat level indicators, and a 4-hour auto-off indicator.



Image: A diagram illustrating the simple one-button control for the blanket, indicating 5 heating settings, 4 hours auto-off, and a temperature range of 86-122°F.

1. **Power On:** Press the power button on the controller to turn on the blanket. The indicator lights will illuminate.
2. **Adjust Heat Level:** Press the power button repeatedly to cycle through the 5 heating levels. Each press will increase the heat level. The corresponding indicator light will show the selected level.
3. **Automatic Shut-off:** The blanket is designed to automatically shut off after 4 hours of continuous use. This is a safety feature. If you wish to continue using the blanket after it has turned off, simply press the power button again to restart it.
4. **Power Off:** To turn off the blanket manually, press and hold the power button until all indicator lights turn off. Always unplug the blanket from the wall outlet when not in use.

MAINTENANCE

Cleaning Instructions:

- Always disconnect the power cord and controller from the blanket before cleaning.
- The blanket is machine washable. Use a gentle cycle with cold water.
- Do not bleach or iron the blanket.
- Tumble dry on low heat or air dry. Ensure the blanket is completely dry before reconnecting the controller and using it again.
- Do not dry clean.

TROUBLESHOOTING

Common Issues and Solutions:

- **Blanket is not heating or not warm enough:**
 - Ensure the power cord is securely plugged into both the blanket and the wall outlet.
 - Verify that the controller is set to the desired heat level.
 - If using for the first time and it feels insufficiently warm, turn the blanket off for 12 hours, then restart it. This can significantly increase the temperature output due to an initial overheating protection setting.
 - Check for any visible damage to the blanket, cord, or controller. If damaged, discontinue use.

- **Blanket automatically turns off:**

- This is a normal safety feature. The blanket is designed to turn off after 4 hours. Simply press the power button to restart.
- If it turns off prematurely or repeatedly, unplug the blanket, wait a few minutes, and then plug it back in. If the issue persists, contact customer support.

SPECIFICATIONS

Brand	ESTINGO
Model Name	YCDM-EB5060
Material	Sherpa (100% Polyester)
Color	A-milk Coffee (variant)
Size	THROW-50x60 (50"L x 60"W)
Item Weight	3.08 pounds (1.4 Kilograms)
Heating Levels	5 (86-122°F)
Auto-Off Timer	4 Hours
Special Features	Heated, Overheating Protection
Certifications	ETL, FCC
Product Care	Machine Wash

WARRANTY AND SUPPORT

ESTINGO products are manufactured with quality and care. For warranty information, technical support, or any questions regarding your heated blanket, please refer to the contact information provided with your product packaging or visit the official ESTINGO website.

Please retain your proof of purchase for warranty claims.

PRODUCT VIDEOS

Video: Official product video demonstrating the double sherpa electric heated blanket. This video highlights the blanket's texture and features.

